

LE922A6 SW User Guide

1VV0301247 r0 – 2016-06-29



APPLICABILITY TABLE

PRODUCT
LE922A6-A1
LE922A6-E1

SW Version
24.00.201
24.00.221



- 5.3.3. Writing a New SMS to Storage61
- 5.3.4. Sending an SMS Previously Stored62
- 5.3.5. Sending a New SMS without Storing It.....63
- 5.3.6. Deleting an SMS.....64
- 5.3.7. Reading an SMS.....65
- 5.3.8. Listing a Group of SMSs67
- 5.3.9. Cell Broadcast Service.....69
- 5.3.10. Reading concatenated SMS70
- 5.4. Using General Purpose Input/output pins72
 - 5.4.1. GPIO pin setup72
 - 5.4.1.1. Setting GPIO pin as OUTPUT.....72
 - 5.4.1.2. Setting GPIO pin as INPUT.....73
 - 5.4.2. GPIO pin use73
 - 5.4.2.1. Querying GPIO pin status74
 - 5.4.2.2. Setting GPIO Pin Output Status.....75
 - 5.4.2.3. Using GPIO7 pin as ALARM OUTPUT (alternate function)76
- 5.5. Clock/Alarm Function76
 - 5.5.1. Clock Date/Time77
 - 5.5.1.1. Regulate the Clock77
 - 5.5.1.2. Read the Current Date/Time78
 - 5.5.2. Alarm Function.....79
 - 5.5.2.1. Regulate the Alarm Time & Behavior79
 - 5.5.2.2. Stop the Alarm Activity.....80
 - 5.5.2.2.1. Exit from the alarm status and shutdown.....81
 - 5.5.2.2.2. Exit from the alarm status and enter the normal operating mode.....81
 - 5.5.2.3. Querying the Alarm Status.....81
 - 5.5.2.3.1. Alarm operation example81
- 6. Packet Switched Data operations84**
 - 6.1. Introduction84
 - 6.2. Tethering Connection.....86
 - 6.2.1. Dial-Up Networking.....86
 - 6.2.2. Standard ECM/RNDIS86
 - 6.3. FTP AT Commands87
 - 6.3.1. FTP Configuration.....87
 - 6.3.2. FTP Open and Close88
 - 6.3.3. FTP Uploading file88
 - 6.3.4. FTP Appending file89
 - 6.3.5. FTP Downloading file(Online Mode)90



4. Basic Operations

4.1. Command Syntax

In the next paragraphs the following notations are used:

<cr> represents the Carriage Return Character (13)

<lf> represents the Line Feed Character (10)

<xx> represents a parameter with changing name is in place of the double x. (< and > characters are only for limiting the parameter and must not be issued to the terminal).

[<xx>] represents an optional parameter whatever name is in place of the xx.

[and] characters are only for limiting the optional parameter and must not be issued to the terminal).

4.2. Command Response Timeout

Every command issued to the Telit modules returns a result response if response codes are enabled (default). The time needed to process the given command and return the response varies, depending on the command type. Commands that do not interact with the SIM/UICC or the network, and involve only internal set up settings or readings, have an immediate response, depending on SIM/UICC configuration(e.g., number of contacts stored in the phonebook, number of stored SMS), or on the network the command may interact with. In the table below are listed only the commands whose interaction with the SIM/UICC or the network could lead to long response timings. When not otherwise specified, timing is referred to set command. For phonebook and SMS writing and reading related commands, timing is referred to commands issued after phonebook sorting is completed. For DTMF sending and dialing commands timing is referred to module registered on network (“AT+CREG/+CEREG?” answer is “+CREG/+CEREG: 0,1” or “+CREG/+CEREG: 0,5”).



NOTE:

In case no response is received after the timeout time has been elapsed, then try repeating the last command and if still no response is received until the timeout time, an Unconditional Shutdown MUST be issued and the device must be powered ON again.

Command	Time-Out (Seconds)
+COPS	125 (test command)
+CLCK	15 (SS operation)
	5 (FDN enabling/disabling)
+CPWD	15 (SS operation)
	5 (PIN modification)
+CLIP	15 (read command)
+CLIR	15 (read command)
+CCFC	15
+CCWA	15

Command	Time-Out (Seconds)
#SD	140 (DNS resolution + connection timeout set with AT#SCFG)
#CSURV	125
#CSURVC	125
#CSURVUC	125
#CSURVB	125
#CSURVBC	125
#CSURVP	125
#CSURVPC	125

4.3. Turning ON/OFF the LE922A6 family

Please refer to LE922A6 Hardware User Guide

4.4. Checking Device Functionality

After a proper power on, the device is ready to receive AT commands on the USB or serial port.
Several things must be checked in order to be sure that the device is ready to send and receive calls and SMS.

4.4.1. Baudrate

LE922A6 family does not support autobauding. Users have to set the right speed for serial communication before device initialization. If LE922A6 family set the right speed, the device responds with OK. The default baudrate is 115200.

- send command AT+IPR=<rate><cr>
- wait for OK response

where rate is the port speed and can be
300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, 921600, 3200000, 3947500 bps.



NOTE:

The USB or serial port suggested setting is: port speed 115200, character format 8N1 (8 bit per char, No parity bit, and 1 stop bit)

4.5. USB Configuration

The Telit LE922A6 family provides below USB compositions, USB composition can be configured by using #USBCFG command.



4.5.1. USB interface

Below table shows all the possible USB interfaces available on the Telit LE922A6 family.

Product ID	MI	Service Name
1040	0	DIAG
	1	ADB
	2	RMNET
	3	NMEA
	4	MODEM
	5	MODEM
	6	AUX
1041	0	DIAG
	1	ADB
	2,3	MBIM
	4	NMEA
	5	MODEM
	6	MODEM
	7	AUX
1042	0,1	RNDIS
	2	DIAG
	3	ADB
	4	NMEA
	5	MODEM
	6	MODEM
	7	AUX
1043	0	DIAG
	1	ADB
	2,3	ECM
	4	NMEA
	5	MODEM
	6	MODEM
	7	AUX
1044	0,1	MBIM
1045	0,1	RNDIS
	2	DIAG
	3	ADB
	4	NMEA
	5	MODEM
	6	MODEM
	7	AUX
	8,9,10	AUDIO

Now default USB composition is 1042(PID)



4.5.2. USB configuration setup

#USBCFG command sets USB composition.

AT#USBCFG=<mode>

For example:

set up the USB composition

command

AT#USBCFG=2

response

OK

read the current USB composition

AT#USBCFG?

response

#USBCFG: 2

4.6. SIM/UICC

4.6.1. SIM/UICC Presence and PIN Request

The following AT command checks if the device needs the PIN code:

AT+CPIN?

Examples

Assume that the SIM/UICC is inserted into the module and the PIN code is needed.

AT+CPIN?

+CPIN: SIM PIN

OK

Assume that the SIM/UICC is not inserted and Extended Error result code is not enabled.

Check if PIN code is needed, just to see the response command:

AT+CPIN?

ERROR

Assume that the SIM/UICC is not inserted and Verbose Extended error result code is enabled.

Check if PIN code is needed, just to see the response command:

AT+CPIN?

+CME ERROR: SIM not inserted



Assume that the SIM/UICC is not inserted and Numerical Extended error result code is enabled. Check if PIN code is needed, just to see the response command:

```
AT+CPIN?  
+CME ERROR: 10
```

4.6.2. Enter PIN code

Use the following AT command to enter the PIN code:

```
AT+CPIN=<pin>
```

Examples

Assume that the SIM/UICC is inserted into the module and the PIN code is needed.

```
AT+CPIN=1235  
OK
```

Now, enter the right PIN code:

```
AT+CPIN=1234  
OK
```

Enable Verbose Extended error result code:

```
AT+CMEE=2  
OK
```

Enter a wrong PIN code:

```
AT+CPIN=1235  
+CME ERROR: incorrect password.
```



NOTE:

after 3 PIN code failed attempts, the PIN code is no longer requested and the SIM/USIM is locked. Use SIM PUK to enter a new PIN code and unlock the SIM/USIM.

4.6.3. Enter PUK code

Enter the following AT command if PUK or PUK2 code is required:

```
AT+CPIN=<pin>[,<newpin>]
```



NOTE:

after 10 PUK code failed attempts, the SIM/UICC Card is locked and no longer available.

4.6.4. SIM/UICC Status

Use the following AT command to enable/disable the SIM/UICC Status Unsolicited Indication.

```
AT#QSS = <mode>
```



Example 1

Enable the unsolicited indication concerning the SIM/UICC status change.

```
AT#QSS=1 ← enable URCs: #QSS:0/1
OK
```

#QSS: 0 ← unsolicited indication: the SIM/UICC is extracted.

#QSS: 1 ← unsolicited indication: the SIM/UICC is inserted.

Example 2

```
AT#QSS=2 ← enable URCs: #QSS:0/1/2/3
OK
```

```
AT+IPR=19200 ← select the Main Serial Port speed = DTE speed
OK
```

```
AT+W0 ← store the setting on profile 0
OK
```

```
AT+P0 ← at Power on use profile 0
OK
```

Now, power off the module:

```
#QSS:0 ← unsolicited indication: SIM/UICC is extracted
```

Now, power on the module:

```
#QSS:1 ← unsolicited indication: : SIM/UICC inserted
```

```
AT+CPIN?
+CPIN: SIM PIN ← SIM/USIM is locked
OK
```

```
AT+CPIN=<PIN> ← enter PIN
OK
```

```
#QSS: 2 ← unsolicited indication: SIM/USIM is unlocked
```

```
#QSS: 3 ← unsolicited indication: SMS and Phonebook are accessible
```



NOTE:

the time interval between the two unsolicited indications (#QSS: 2 and #QSS: 3) depends from the number of SMS stored on the module and the Phonebook dimension.

4.6.5. SIM/UICC Detection Mode

Use the following AT command to manage the SIM/UICC Detection Mode:

```
AT#SIMDET=<mode>
```

Or



#SIMPR: 0, 0, 1 ← 0 : Disable URC, 0: Local SIM/UICC, 1: SIM/UICC inserted
 #SIMPR: 0, 1, 0 ← 0 : Disable URC, 1: Remote SIM/UICC, 0: Remote SIM/UICC not
 OK inserted

Now, extract/insert the SIM/UICC, no unsolicited indication appears on DTE!

Extract the SIM/UICC again

AT#SIMDET=1 ← simulate SIM/UICC inserted, but it is still physically extracted
 OK

AT#SIMDET?

#SIMDET: 1,0 ← 1 = simulate the status SIM/UICC inserted, 0 = SIM/UICC is physically
 OK not inserted

AT#SIMPR?

#SIMPR: 0, 0, 0 ← 0 : Disable URC, 0: Local SIM/UICC, 0: SIM/UICC is physically not
 inserted

#SIMPR: 0, 1, 0 ← 0 : Disable URC, 1: Remote SIM/UICC, 1: Remote SIM/UICC not
 inserted

OK

Now, insert/extract the SIM/UICC, no unsolicited indication appears on DTE!

AT#SIMPR=1 ← Enable URC

OK

Extract the SIM/UICC and set automatic SIM/UICC detection

#SIMPR: 0, 0 ← 0 : Local SIM/UICC, 0: SIM/UICC is physically not inserted

#SIMPR: 1, 0 ← 1 : Remote SIM/UICC, 0: Remote SIM/UICC is not connected from SAP

AT#SIMDET=2

OK

AT#SIMDET?

#SIMDET: 2,0 ← 2 = automatic SIM/UICC detection through SIMIN pin (Factory Setting),
 OK 0 = SIM/UICC not inserted

Now, insert/extract the SIM/UICC, unsolicited indication appears again on DTE!

#SIMPR: 0, 1 ← 0 : Local SIM/UICC, 0 SIM/UICC is physically inserted

#SIMPR: 1, 0 ← 1 : Remote SIM/UICC, 0: Remote SIM/UICC is not connected from SAP

#QSS: 1 ← unsolicited indication: SIM/UICC is logically activated

#QSS: 0 ← unsolicited indication: SIM/UICC is logically deactivated

4.6.6. SIM/USIM access File

Use the +CSIM command to read/write SIM/USIM files. The format of the +CSIM parameters and the sequence of the +CSIM commands must be in accordance with the required protocol device: SIM or USIM protocol. This distinction between SIM and USIM



or +CGREG: 1,2	network but is looking for a suitable one to register.	see if it has found a suitable network to register in.
+CGREG: 0,3 or +CGREG: 1,3	Mobile has found some networks but it is not allowed to register on any of them, no roaming was allowed.	Try in another place, and repeat procedure at par. 4.7.12
+CGREG: 0,4 or +CGREG: 1,4	Mobile is in an unknown network status	Repeat procedure at par. 4.7.12 to see if it has found a suitable network to register in
+CGREG: 0,5 or +CGREG: 1,5	Mobile has found some networks and is currently registered in roaming on one of them	Proceed ahead. Ready to call

4.7.1.3. PS network registration status in E-UTRAN

- send command AT+CREG?<cr>
- wait for response:

Response	Reason	Action
+CREG: 0,0 or +CREG: 1,0	SIM not present or damaged or SIM is present and PIN is required to continue operations	Check SIM/UICC or require UICC insertion and repeat from par. Error! Reference source not found. 6.1 or Repeat par. 4.6.2.
+CREG: 0,1 or +CREG: 1,1	Mobile is registered on its home network.	Proceed ahead. Ready to call
+CREG: 0,2 or +CREG: 1,2	Mobile is currently not registered on any network but is looking for a suitable one to register.	Repeat procedure at par. 4.7.13 to see if it has found a suitable network to register in.
+CREG: 0,3 or +CREG: 1,3	Mobile has found some networks but it is not allowed to register on any of them, no roaming was allowed.	Try in another place, and repeat procedure at par. 4.7.13
+CREG: 0,4 or +CREG: 1,4	Mobile is in an unknown network status	Repeat procedure at par. 4.7.13 to see if it has found a suitable network to register in
+CREG: 0,5 or +CREG: 1,5	Mobile has found some networks and is currently registered in roaming on one of them	Proceed ahead. Ready to call



NOTE:

When a response +CREG/+CGREG/+CREG: x,1 or +CREG/+CGREG/+CREG: x,5 is received, then the device is ready to place and receive a call or SMS. It is possible to jump directly to call setup procedures or SMS sending procedures.

4G only products like LE922A6-E1 does not support +CGREG command.



NOTE:

This command issues a network request and it may require quite a long time to respond, since the device has to wait the answer from the network (it can be as long as 60 seconds). Do not use this command if not necessary.

4.7.3. Signal Strength & Quality

Assume that the mobile is registered on a Network that can be: GERAN or UTRAN. The following AT command can be useful to know the received signal strength & quality to have an indication about the radio link reliability.

AT+CSQ

Examples

Assume that the antenna is not connected to the Telit Module or Network coverage is not present at all.

```
AT+CSQ
+CSQ: 99,99
OK
```

Now, the antenna is connected to the Telit Module and Network coverage is present. Enter again the previous AT command:

```
AT+CSQ
+CSQ: 17,0
OK
```

17 = <rsqi> = Received Signal Strength Indication

0 = <ber> = Bit Error Rate

Now, a wrong parameter is entered just to see the result format when Verbose Extended Error result is enabled

```
AT+CSQ?
+CME ERROR: operation not supported
```

4.7.4. Extended Signal Quality

Assume that the mobile is registered on a Network that can be: GERAN ,UTRAN and EUTRAN.

The following AT command can be useful to know the received signal strength & quality to have an indication about the radio link reliability.



AT+CESQ

Examples

Assume that the antenna is not connected to the Telit Module or Network coverage is not present at all.

```
AT+CESQ
+CESQ: 99,99,255,255,255,255
OK
```

Now, the antenna is connected to the Telit Module and GERAN Network coverage is present.

Enter again the previous AT command:

```
AT+CESQ
+CESQ: 61,5,255,255,255,255
OK
```

61 = <rxlev> = Received Signal Strength Level.

5 = <ber> = Bit error rate (in percent).

Now, the antenna is connected to the Telit Module and UTRAN Network coverage is present.

Enter again the previous AT command:

```
AT+CESQ
+CESQ: 99,99,940,47,255,255
OK
```

940 = <rscp> = Received Signal Code Power.

47 = <ecno> = Ratio of the received energy per PN chip to the total received power spectral density.

Now, the antenna is connected to the Telit Module and EUTRAN Network coverage is present.

Enter again the previous AT command:

```
AT+CESQ
+CESQ: 99,99,255,255,32,95
OK
```

32 = <rsrq> = Reference Signal Received Quality.

95 = <rsrp> = Reference Signal Received Power.

Now, a wrong parameter is entered just to see the result format when Verbose Extended Error result is enabled.



4.8.3. Audio Codec Information

This example is valid for GERAN and UTRAN standards. Use the following AT command to get codec information about a call.

```
AT#CODECINFO=<format>,<mode>
OK
```

Example

```
AT#CODECINFO=1,1 ← enable codec information
OK
```

```
ATD<phone number>;
OK
```

```
#CODECINFO: "HAMR","FR","EFR","HR","FAMR","HAMR"
```

```
NO CARRIER ← remote hang up
```

```
#CODECINFO: "None","FR","EFR","HR","FAMR","HAMR"
```



NOTE:

4G only products like LE922A6-E1 does not support this command

4G/3G only products like LE922A6-A1 does not support GERAN standard.

4.8.4. Setting Audio Codec

This example is valid for GERAN and UTRAN standards. Use the following AT command to select a codec during a call.

```
AT#CODEC=<codec>
OK
```

Example

```
AT#CODEC?
#CODEC: 0 ← all the codec are enabled
OK
```

```
AT#CODECINFO=1,1 ← enable codec information
OK
```

```
ATD<phone number>; ← establish the call
#CODECINFO: "HAMR","FR","EFR","HR","FAMR","HAMR"
OK
```

```
NO CARRIER ← remote hang up
```

```
#CODECINFO: "None","FR","EFR","HR","FAMR","HAMR"
```



AT#CODEC=1 ← select FR mode
OK

ATD<phone number>; ← establish the call
#CODECINFO: "FR", "FR"
OK

NO CARRIER ← remote hang up
#CODECINFO: "None", "FR"



NOTE:

4G only products like LE922A6-E1 does not support this command
4G/3G only products like LE922A6-A1 does not support GERAN standard.

4.8.5. Disconnect a Call

Use the following AT command to hang up the current Voice Call:

ATH
OK

4.8.6. Answering an Incoming Call

When an Incoming Call is recognized, the module sends an Unsolicited Code to DTE. Use the following AT command to answer to the call:

ATA
OK



5.1.1.1. Select Phonebook Memory Storage

Use the following AT command to select the Phonebook Memory Storage:

AT+CPBS=<storage>

Examples

AT+CPBS=? ← Read the supported range of Phonebook Storages
+CPBS: (“SM”, “FD”, “LD”, “MC”, “RC”) ← “MB” is not supported by the inserted SIM/UICC
OK

AT+CPBS? ← Read the current Phonebook Storage
+CPBS: “SM”,10,250
OK

AT+CPBS=“FD” ← Select “FD” phonebook storage
ERROR

AT+CMEE=2
OK

AT+CPBS=“FD”
+CME ERROR: SIM PIN2 required

AT+CPIN=PIN2 ← Enter PIN2
OK

AT+CPBS=“FD” ← Select “FD” phonebook storage
OK



NOTE:

the last two commands can be substituted by the following one:

AT+CLCK=“FD”,1,PIN2
OK

AT+CPBS=“MC” ← Select “MC” Phonebook Storage
OK

AT+CPBS? +CPBS: “MC”,0,20
OK



NOTE:

after module power on and PIN authentication, the module reads the data records stored on the SIM/UICC. During this activity the phonebook access is inhibited for a time interval depending on various factors. If Phonebook commands are entered during this interval the module returns an error message. In this case, retry the operations later.



5.1.4. Delete Phonebook Entry

First, the desired storage must be active (see par.5.1.1.1). Then:

Use the following AT command with only <index> parameter to delete a Phonebook entry:

AT+CPBW=<index>

Examples

Select the “SM” phonebook:

AT+CPBS=”SM”
OK

Delete record 7 on the “SM” phonebook:

AT+CPBW= 7
OK

Try to delete a non-existent record on the “SM” phonebook, just to see the format response:

AT+CPBF=9999999999
+CME ERROR: not found



NOTE:

The delete command overwrites the <index> record number with an empty record.

5.2. LTE Power Saving Function

The Telit LE922A6 family has a special function that reduces power consumption during idle time, thus allowing a longer standby time with a given battery capacity.

This function monitors the DTR line and USB VBUS line indicating that the OEM application is ready to send commands when DTR goes high and USB VBUS goes low (0V on USB). If so, the OEM application is not going to send any commands and the LE922A6 family module can save energy by shutting down its internal serial port or USB port.

When the OEM application becomes ready again, the line DTR is tied low (0V on UART) or VBUS is tied high; the LE922A6 family detect this condition and powers up the serial port or USB port.

If the power saving function is activated, then the serial port must support the DTR line since when this line is high (Data Terminal is NOT ready) and the USB port must support the VBUS line since when this line is Low the device goes into a sleep condition and will not respond to commands until the DTR is tied low (Data Terminal is ready) or the VBUS is tied high.

5.2.1. Enabling/Disabling the Power Saving Function

- send command **AT+CFUN=<fun><cr>**



where:

<fun> is the power saving function mode, the supported values are:

0 - minimum functionality, NON-CYCLIC SLEEP mode: in this mode, the AT interface is not accessible.

1 - mobile full functionality with power saving disabled (factory default)

4 - disable both TX and RX

5 - mobile full functionality with power saving enabled

- wait for response:

Response	Reason	Action
OK	The power save is now active	
ERROR	some error occurred	Enable extended result codes and retry with +CMEE
+CME ERROR: 4	operation not supported	Check command syntax and <fun> value.

5.2.2. Power Saving Mode

Power Saving Mode means that Device is in sleep mode with disabling the interface (UART/USB).

LE922A6 FAMILY makes it possible for DTE to receive the event such as incoming call/SMS/data while both DTE and Modem are in sleep mode with disabling all serial interfaces.

DTE must require below specification to achieve the reduction of power consumption.


- DSR/DTR/RI pin control on Main UART port.
- USB VBUS control

If DTE satisfies above requirement, LE922A6 FAMILY can provide the functionalities:

- Keep URC message.
- Keep Incoming data during data mode, until DTE wake up from sleep mode.
- LE922A6 FAMILY helps DTE to reduce their power consumption using below rules.
- Use RI on Main UART to wake up DTE from sleep mode. (DTE must always monitor RI pin during power saving mode).
- Use DTR on Main UART to place Modem in sleep mode or wake up Modem from sleep mode.



5.2.3. URC Message in Power Saving



The flow chart for URC message in power saving mode



Above figure illustrates the action flow to get URC messages are invoked while both DTE and modem in sleep mode.

LE922A6 FAMILY keeps the URC messages are listed in the table below and these URCs can be enabled or disabled by AT command.

URC message List

URC Message	Enable/Disable AT Command
RING	Always enabled
+CIEV	+CIND
+CEREG	+CEREG
+CMTI,+CMT,+CBM,+CDS,+CDSI	+CNMI
#TEMPMEAS	#TEMPMON
#MWI	#MWI
SRING	Always enabled
+CALA	+CALA
#QSS	#QSS

VBUS Control System

Product	VBUS Master
LE922A6 FAMILY	DTE (must turn off VBUS when entering to sleep mode and turn on VBUS when waking up from sleep mode)



NOTE:

DTE get URC messages kept on Main UART/Telit USB Modem/Aux in power saving mode. But LE922A6 FAMILY can't keep URC messages larger than 8K bytes. We recommend that DTE should get the URC message as soon as RI signal is generated on Main UART.

5.2.4. RI Signal for the Specific Event

DTE can wake up from sleep mode by monitoring RI pin, while it's in sleep mode. LE922A6 FAMILY provides different RI signal type to DTE, according to the specific event.

This paragraph deals with the following items:


- RI Signal for incoming call
- RI Signal for incoming SMS
- RI Signal for TCP connection request in server mode
- RI Signal for URC message during power saving mode

5.2.4.1. RI Signal for Incoming Call

RI signal for incoming call has different signal in accordance with the value of \R and RING message is sent to DTE the instance RI signal is going to is activated, periodically.

In case the value of \R is 0 or 1, RI signal and RING message like as the following figure is generated.





RI signal for \R0 or \R1


In case the value of \R is 2, RI signal and RING message is generated like as the following figure



RI signal for \R2

5.2.4.2. RI Signal for Incoming SMS

RI signal for incoming SMS has two types in accordance with the value of +CNMI or #E2SMSRI. In case +CNMI=3 (On-line data mode), the negative going pulse like as the following figure is generated, one time.



RI Signal for +CNMI=3 (On-line data mode)

In case #E2SMSRI = <x>, the negative going pulse like as the following figure is generated, one time.



5.3. SMS Handling

The Telit LE922A6 family supports the Short Message Service, it is possible to store, delete, write, send and receive a SMS, which is a short text message up to 160 characters long.

5.3.1. SMS Device setup

Before accessing the Short Message Service, the device has to be properly set up.

5.3.1.1. Select SMS Format Type

The LE922A6 family supports SMS in two different formats:

- PDU
- Text

The difference is that in the PDU mode the device returns and receives SMS encoded in the format ready to be sent to the network; in TEXT mode the device converts automatically the read PDU into text and vice versa. By using TEXT mode, the PDU data encoding knowledge is not needed and operations are easier. For this reason, we are using the TEXT mode to explain how to operate with SMS. If you are familiar with PDU encoding then you can operate with PDU by selecting that format and using appropriate command syntax.

- Send command `AT+CMGF=<mode><cr>`

Where:

`<mode>` is the SMS format type:

- 0 - PDU
- 1 - Text

- wait for response OK



NOTE:

This setting is stored and remains until the device is turned off. Hence, there is no need to issue it more than one time. For TEXT mode use `<mode>=1`.

For example:

1- Let us assume you want to set TEXT format for the SMS:

command

`AT+CMGF=1<cr>`

response:

OK



5.3.1.2. Check SMS Service Centre Number

The SMS are sent by the LE922A6 family to a service center (SMSC) where the message is dispatched towards its final destination or is kept until the delivery is possible. To ensure a correct behavior of this service the number of the service center must be the one your network operator supports.

To check which number is stored as the SMSC:

- send command `AT+CSCA?<cr>`
- wait for response in the format: `+CSCA: <number>,<type>`

OK

where:

`<number>` is the SMSC number

`<type>` is the SMSC number type:

145 - international numbering scheme (number begins with "+")

129 - national numbering scheme



NOTE:

This setting remains stored in the SIM/UICC card until it is changed or deleted, so this operation may be done only once if the SIM/UICC Card is not changed. The setting is maintained even after power down.

For example:

1- Let us assume you want to check your SMSC number:

command

`AT+CSCA? <cr>`

response:

`+CSCA: +393359609600`

OK

5.3.1.3. Add SMS Service Centre Number (only if required)

If your previously check for SMSC returned an empty field:

`+CSCA: ,129`

Or if the SMSC number stored does not correspond to the desired one, then the new number has to be stored. In this way, the previously stored number will be overwritten.

- send command `AT+CSCA=<number>,<type><cr>`

where:



<fo> - first octet of the message PDU

<mr> - message reference number

<ra> - recipient address, string type, represented in the currently selected character set (see +CSCS)

<tora> - type of number <ra>

<scts> - arrival time of the message to the SC

<dt> - sending time of the message

<st> - message status as coded in the PDU

2 - if a status report is stored, then the following unsolicited result code is sent:

+CDSI: <memr>,<index>

where:

<memr> - memory storage where the new message is stored

"SR"

<index> - location on the memory where SM is stored

<bfr> - buffered result codes handling method:

0 - TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode>=1..3 is entered (OK response must be given before flushing the codes)

1 - TA buffer of unsolicited result codes defined within this command is cleared when <mode>=1..3 is entered.

NOTE: Issuing AT+CNMI<CR> is the same as issuing the Read command.

NOTE: Issuing AT+CNMI=<CR> is the same as issuing the command AT+CNMI=0<CR>.

- wait for OK



NOTE:

In this command description the values that are always 0 are parameter reserved for future use, in the current software revision the only value supported is 0.

For example:

1- Let us assume you want to eliminate all the unsolicited codes that may be sent when receiving SMS & Status Report:

Command

AT+CNMI= 0,0,0,0,0<cr>

Response:

OK

For example about a new message indication:



SRR status report request

0 - status report not requested

1 - status report requested

UDHI user data Header Information

0 - No Header on PDU

1 - Header present on PDU

RP reply path

0 - RP not set

1 - RP set

Validity Period numerical if in relative format or string if in absolute format

This parameter represents the validity period for the SMS after which the message must be disregarded instead of being delivered.

If in relative format (see VPF parameter) it is an integer:

0 to 143 - corresponding to $(VP + 1) \times 5$ minutes

144 to 167 - corresponding to 12 hours + $((VP - 143) \times 30)$ minutes

168 to 196 - corresponding to $(VP - 166) \times 1$ day

197 to 255 - corresponding to $(VP - 192) \times 1$ week

If in absolute format it is a string in the format:

"gg/MM/YY,hh:mm:ss±tz"

where

gg day of expiration (2 characters)

MM month of expiration (2 characters)

YY year of expiration (2 characters)

hh hour of expiration (2 characters)

mm minute of expiration (2 characters)

ss second of expiration (2 characters)

± sign of the time zone (+ or -)

tz time zone (2 characters)

Protocol Identifier in numerical format: This parameter identifies the protocol used by the receiver entity and informs the SC that the conversion from SMS to that protocol must be done while delivering the message.

Protocol ID	Conversion towards
0	Implicit (default)
33	telex (or teletex reduced to telex format)
34	group 3 telefax



x3		#	3	C	S	c	s
x4		\$	4	D	T	d	t
x5		%	5	E	U	e	u
x6		&	6	F	V	f	v
x7		'	7	G	W	g	w
x8		(8	H	X	h	x
x9)	9	I	Y	i	y
xA	LF ²	*	:	J	Z	j	z
xB		+	;	K		k	
xC		,	<	L		l	
xD	CR ³	-	=	M		m	
xE		.	>	N		n	
xF		/	?	O	£	o	

¹ - SP stands for space character

² - LF stands for Line Feed character

³ - CR stands for Carriage Return character

For example:

1- Let us assume you want to find the IRA code for the character '&':

From the table you find:

- most significant Nibble: 2
- least significant Nibble: 6

Hence the IRA code for the '&' character is the hexadecimal 0x26.

2- Let us assume you have the IRA code 0x6B and you want to find the corresponding character:

From the table you find at the position

- most significant Nibble: 6
- least significant Nibble: B

Hence, the character corresponding to the 0x6B IRA code is 'k'.



NOTE:

With the command AT+CSCS is possible to select the character set; the available types are:

“GSM” - GSM 7 bit default alphabet

“IRA” - ITU-T.50

”8859-1” - ISO 8859 Latin 1

”PCCP437” - PC character set Code Page 437.

”UCS2” - 16-bit universal multiple-octet coded character set (ISO/IEC10646)

Please refer to the AT command specification for the full command description.



response:

+CMSS: 1

OK

In this case, the SMS was successfully sent to the destination and its network message reference number is 1.

5.3.5. Sending a New SMS without Storing It

A new SMS can be sent directly to the network without storing it.

- send command AT+CMGS="<da>"<cr>

where:

<da>: destination address

- wait for prompt ">"
- send SMS text
- end command with CTRL-Z character (0x1A hexadecimal) or abort command with ESC character (0x1B hexadecimal)
- wait for response:

Response	Reason	Action
+CMGS: <mr> OK	Message has been successfully sent. <mr> represents the message reference number.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report and retry.
+CMS ERROR: 330	SMSC address unknown	Insert SMSC address (see par. 5.3.1.3)
+CMS ERROR: 41	"Temporary Failure", may be that the device is not registered on any network	Check for signal strength and network registration
+CMS ERROR: 331	No network service	Check for signal strength and network registration
+CMS ERROR: 1	Unassigned number	The destination address number does not exist. Check it and repeat command.
+CMS ERROR: 42	network congestion	Retry later
+CMS ERROR: 96	Mandatory information missing	Check for destination address in the SMS, overwrite it and retry.
OK	command aborted by user	you issued a ESC char

For example:



<dc>,<sc>,<to>,<length>]<CR><LF><data>

Output format for sent messages:

+CMGR: <stat>,<da>,<alpha>[,<to>,<fo>,<pid>,<dc>,,
<sc>,<to>,<length>]<CR><LF><data>

Output format for message delivery confirm:

+CMGR: <stat>,<fo>,<mr>,,,<sc>,<dt>,<st>

where:

<stat> - status of the message

"REC UNREAD" - new received message unread

"REC READ" - received message read

"STO UNSENT" - message stored not yet sent

"STO SENT" - message stored already sent

<fo> - first octet of the message PDU

<mr> - message reference number

<sc> - arrival time of the message to the SC

<dt> - sending time of the message

<st> - message status as coded in the PDU

<pid> - Protocol Identifier

<dc> - Data Coding Scheme

<oa> - Originator address, string type represented in the currently selected character set (see +CSCS)

<da> - Destination address, string type represented in the currently selected character set (see +CSCS)

<alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS.
NB: this optional field is currently not supported.

<sc> - Service Centre number

<to>,<toa>,<toa>,<toa> - type of number <oa>,<da>,<sc>

129 - number in national format

145 - number in international format (contains the "+")

<length> - text length

<data> - TP-User_data

If <dc> indicates that GSM03.38 default alphabet is used, each character of GSM alphabet will be converted into current TE character set (see +CSCS)



If **<dc>** indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal numbers (e.g. octet 0x2A will be converted as two characters 0x32 0x41)

Note: in both cases if status of the message is 'received unread', status in the storage changes to 'received read'. An error result code is sent on empty record **<index>**.

For example:

1- Let us assume you want to read the SMS that is stored at the position index 4. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

Command

AT+CMGR=4

Response:

+CMGR: "STO UNSENT", "+393351234565"

Telit Test Message for Text Mode SMS.

OK

In this case the SMS was successfully read, the text contained was:

"Telit Test Message for Text Mode SMS."

The message was written to the storage by user (STO) but still not sent (UNSENT) to the destination address with the number +393351234565

2- Let us assume you want now to read the SMS that is stored at the position index 5:

Command

AT+CMGR=5

Response:

+CMGR: "REC UNREAD", "+393381234567890", "29/06/01,12:30:04+01"

Telit Test Message for Text Mode SMS RECEIVING.

OK

In this case the SMS was successfully read, the text contained was:

"Telit Test Message for Text Mode SMS RECEIVING."

The message was received (REC) from the number +393381234567890 at 12:30:04 the day 29/06/01 in the European time zone +1. After this read command the message at index 5 becomes REC READ.

5.3.8. Listing a Group of SMSs

The SMS can be grouped into 5 different groups depending on their status:

- REC UNREAD received messages still not read
- REC READ received messages already read



- STO UNSENT written messages not yet sent
- STO SENT written messages already sent
- ALL all types of messages

It is possible to have the list of all the messages in one group:

- send command **AT+CMGL=<stat><cr>**

Where:

<stat> - status group of the message

"REC UNREAD" - new message

"REC READ" - read message

"STO UNSENT" - stored message not yet sent

"STO SENT" - stored message already sent

"ALL" - all messages

- wait for response in the format:

For every message in the group:

+CMGL: <index>,<stat>,<oa/da> [,,,<toa/toda>,<length>]

<CR><LF><text>

where:

<index> - message index position on the storage

<stat> - status of the message

"REC UNREAD" - new message

"REC READ" - read message

"STO UNSENT" - stored message not yet sent

"STO SENT" - stored message already sent

<oa/da> - sender number/destination number

<toa/toda> - type of number <oa/da>

145 - international number (contains "+" character)

129 - national number

<length> - length of the message text in characters

<text> - message text

Note: If status of the message is 'received unread', status in the storage changes to 'received read'.

For example:

1- Let us assume you want to list all the SMS received read that are stored. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:



5.4. Using General Purpose Input/output pins

The Telit LE922A6 family provides various General Purpose Input/output pins, these pins can be configured via AT commands as Inputs, Outputs and two of them as "alternate function".

The "alternate function" is supported by pins GPIO7, which can be configured to become an alarm output pin that reflects the alarm status.

With these pins your application can control external hardware directly using the Telit LE922A6 family pins, with little or even no hardware added.

5.4.1. GPIO pin setup

Before using the GPIO pin, you must configure them to select their direction or alternate function

5.4.1.1. Setting GPIO pin as OUTPUT

When you set a GPIO as output, you must specify also the value that the pin output must take:

- send command **AT#GPIO=<pin>,<value>,1<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 - GPIO1	6 - GPIO6
2 - GPIO2	7 - GPIO7
3 - GPIO3	8 - GPIO8
4 - GPIO4	9 - GPIO9
5 - GPIO5	10 - GPIO10

<value> is the GPIO pin value that the pin will assume:

- 0 - LOW
- 1 - HIGH

- wait for response **OK**



NOTE:

The #GPIO setting is not saved and will be lost on power off, so at start-up repeat pin initialization commands. At start-up the setting for GPIO7 instead is maintained even after a shutdown to permit alarm feature to work always.

For example:

1- Let us assume you want to set GPIO3 pin as Output and you want it to be in LOW status:

command

AT#GPIO=3,0,1<cr>

response:



OK

In this case, the GPIO3 pin was successfully put in output direction and its status has been set to LOW.

5.4.1.2. Setting GPIO pin as INPUT

When you set a GPIO as input, you must specify also a dummy value for the pin state:

- send command **AT#GPIO=<pin>,<dummy_value>,0<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 - GPIO1	6 - GPIO6
2 - GPIO2	7 - GPIO7
3 - GPIO3	8 - GPIO8
4 - GPIO4	9 - GPIO9
5 - GPIO5	10 - GPIO10

<value> is a dummy value can be either:

- 0 - dummy value
- 1 - dummy value

- wait for response **OK**



NOTE:

The **#GPIO** setting for all GPIO except from GPIO7 is not saved and will be lost on power off, so at start-up repeat pin initialization commands.

At start-up all the GPIOs except from GPIO7 are configured by default as INPUT, but the setting for GPIO7 instead is maintained even after a shutdown to permit alarm feature to work always.

For example:

1- Let us assume you want to set GPIO4 pin as Input:

command

AT#GPIO=4,0,0<cr>

response:

OK

In this case, the GPIO4 pin was successfully put in input direction.

5.4.2. GPIO pin use

After having set-up the GPIO pin direction you can query the input status of an INPUT pin or set the output status of an OUTPUT pin.



5.4.2.1. Querying GPIO pin status

To query for the pin status:

- send command **AT#GPIO=<pin>,2<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 - GPIO1	6 - GPIO6
2 - GPIO2	7 - GPIO7
3 - GPIO3	8 - GPIO8
4 - GPIO4	9 - GPIO9
5 - GPIO5	10 - GPIO10

- wait for response in the format:

#GPIO: <dir>,<stat>

OK

where:

<dir> - GPIO<pin> direction setting

<stat> - status of the pin

0 - LOW

1 - HIGH



NOTE:

In case the GPIO pin direction is set to ALTERNATE FUNCTION (2), then the reported <stat> has no meaning and must not be kept as valid, but must be treated as a dummy value.

The query reports depending on the pin direction:

- the read pin status in case the direction is input;
- the previously set pin status in case the direction is output.

In any case, you can know if the pin at the query moment is high or low and the pin direction.

For example:

1- Let us assume you want to query the GPIO3 pin for its status:

command

AT#GPIO=3,2<cr>

response:

#GPIO: 0,1

OK



In this case, the GPIO3 pin was set in input direction and its status has been measured to be HIGH.

2- Let us assume you want to query the GPIO4 pin for its status:

command

AT#GPIO=4,2<cr>

response:

#GPIO: 1,0

OK

In this case, the GPIO4 pin was set in output direction and its status is LOW.

3- Let us assume you want to query the GPIO7 pin for its status:

command

AT#GPIO=6,2<cr>

response:

#GPIO: 2,0

OK

In this case, the GPIO7 pin was set in "alternate function" direction and therefore works as alarm output. The reported status = LOW has no meaning.

5.4.2.2. Setting GPIO Pin Output Status

To set the pin status (when pin is set as OUTPUT):

- send command **AT#GPIO=<pin>,<value>,1<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 - GPIO1	6 - GPIO6
2 - GPIO2	7 - GPIO7
3 - GPIO3	8 - GPIO8
4 - GPIO4	9 - GPIO9
5 - GPIO5	10 - GPIO10

<value> is the pin value to be set and can be:

- 0 - LOW
- 1 - HIGH

- wait for response **OK**



For example:

1- Let us assume you want to set the GPIO3 pin HIGH:

command

AT#GPIO=3,1,1<cr>

response:

OK

In this case, the GPIO3 pin was set in output direction and its status has been set to HIGH.

5.4.2.3. Using GPIO7 pin as ALARM OUTPUT (alternate function)

When you set the GPIO7 pin as alarm output function, the pin reports the alarm state following the +CALA settings. To set the pin in alternate function you must specify also a dummy value for the pin state:

- send command **AT#GPIO=7,<dummy_value>,2<cr>**

where:

<value> is a dummy value can be either:

0 - dummy value

1 - dummy value



NOTE:

Remember that the alternate function places the GPIO7 pin always in OUTPUT direction and since the GPIO7 pin value is controlled by the internal software, the corresponding function (+CALA) must be setup properly.

The #GPIO7 direction setting is saved and will be kept after a power off.

- wait for response **OK**

For example:

1- Let us assume you want to set GPIO7 pin as ALARM OUTPUT:

command

AT#GPIO=7,0,2<cr>

response:

OK

In this case, the GPIO7 pin was successfully put in alarm output direction.

5.5. Clock/Alarm Function

The Telit LE922A6 family provides a Real Time Clock and Alarm embedded in the product; it is therefore possible to set-up the proper time, check the actual time, set-up an alarm time at which the alarm will be triggered with various behavior depending on the +CALA setting.



yy - year (two last digits are mandatory), range is 00..99

MM - month (two last digits are mandatory), range is 01..12

dd - day (two last digits are mandatory), range is 01..31 (if the month MM has less than 31 days, the clock will be set for the next month)

hh - hour (two last digits are mandatory), range is 00..23

mm - minute (two last digits are mandatory), range is 00..59

ss - seconds (two last digits are mandatory), range is 00..59

±zz - time zone (indicates the difference, expressed in quarter of an hour, between the local time and GMT; two last digits are mandatory), range is -47..+48

Note: If the parameter is omitted the behavior of Set command is the same as Read command.

- wait for response **OK**



NOTE:

Remember that the string time has to be encapsulated in double brackets.

The time will start immediately after the time setting command.

For example:

1- Let us assume you want to regulate your clock to 7 November 2002 at 12h 24m 30s for the time zone +01h central Europe:

Command

AT+CCLK="02/11/07,12:24:30+04"<cr>

Response:

OK

In this case, the time was successfully set.

5.5.1.2. Read the Current Date/Time

- send command **AT+CCLK?<cr>**
- wait for response in the format:

+CCLK: <time>

OK

Note: the three last characters of <time> are not returned by **+CCLK?** Because the **ME** doesn't support time zone information.

For example:

1- Let us assume you want now to read the current time:

Command



3 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE starts playing the alarm tone on the selected path for the ringer (see command **#SRP**)

The device keeps on playing the alarm tone until a **#WAKE** or **#SHDN** command is received or a 90s timeout occurs. If the device is in "alarm mode" and it does not receive the **#WAKE** command within 90s then it shuts down.

4 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE brings the pin **GPIO7** high, provided its **<direction>** has been set to alarm output, and keeps it in this state until a **#WAKE** or **#SHDN** command is received or a 90s timeout occurs. If the device is in "alarm mode" and it does not receive the **#WAKE** command within 90s then it shuts down.

5 - the MODULE will make both the actions as for **<type>=2** and **<type>=3**.

6 - the MODULE will make both the actions as for **<type>=2** and **<type>=4**.

7 - the MODULE will make both the actions as for **<type>=3** and **<type>=4**.

8 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE sets **High** the **RI** output pin. The **RI** output pin remains **High** until next **#WAKE** issue or until a 90s timer expires. If the device is in "alarm mode" and it does not receive the **#WAKE** command within 90s. After that it shuts down.

<text> - unsolicited alarm code text string. It has meaning only if **<type>** is equal to 2 or 5 or 6.

- Wait for response OK



NOTE:

If you use the GPIO7 pin as ALARM OUTPUT, then you **MUST** set its direction to "alternate function" (see par. 3.7.2.4) otherwise the pin does not respond to the alarm settings.

In case the alarm mode is equal to 1,3,7 then a dummy empty text is inserted "".

If you use the unsolicited codes **+CALA: <text>**, then you must fix the port speed rate (see par. 2.7.1) and store it in the active profile (see command **&W**), in order to make the Telit LE922A6 family boot with the desired port speed, otherwise at the alarm wakeup, the module starts with the default port speed that may differ from yours.

Remember that the string time has to be encapsulated in double brackets, furthermore the Alarm time is computed for different time zone, therefore the alarm time always refers to the same time zone as the clock setting regardless the time zone set in the **+CALA** command.

Note: LE922A6 doesn't support playing the alarm tone.

5.5.2.2. Stop the Alarm Activity

When the alarm time expires, the module starts the alarm activity according to the alarm behavior parameter **<type>** selected.



For example:

1- Let us assume you have a battery powered device, a meteorological unit that measures every hour the conditions and therefore needs to send a new SMS every hour to the central server, for example indicating the weather status just measured. Let say your application must consume the absolute minimum power to achieve the job, since it will be placed in a remote position where its battery must last as long as possible and therefore it must shutdown completely and wake up every hour for just the time needed to measure & send the weather, successively shutdown.

set up the time in the internal clock (only the first time)

command

AT+CCLK="02/11/07,12:24:30+01"<cr>

response

OK

set up the next alarm in order to raise the GPIO7 pin to power up the controlling application too.

command

AT+CALA="02/11/07,13:24:30+01",0,6,"TIME TO MEASURE & SMS...!"<cr>

response

OK

- shutdown the LE922A6 family and successively the controlling application.

command

AT#SHDN<cr>

response

OK

... after an hour..

The LE922A6 family will turn itself ON in "Alarm Mode" and contemporarily both raise the GPIO7 pin which turns on the power to the controlling application and issue every 3s an unsolicited code +CALA: TIME TO MEASURE & SMS...!

turn on the keep alive line in the controlling application that keeps itself ON.

stop the alarm activity in the LE922A6 family (recognized by the +CALA unsolicited code) and bring the LE922A6 family in operating mode

command

AT#WAKE=0<cr>

response

OK

take the weather measure

send the SMS with the weather data (see Sending a New SMS without Storing It par. 5.3.5).



read the current time.

command

AT+CCLK?<cr>

response

+CCLK="02/11/07,13:24:47"<cr>

OK

calculate & set up the next alarm in order to raise the GPIO7 pin to power up the controlling application too.

command

AT+CALA="02/11/07,14:24:47+01",0,6,"TIME TO MEASURE & SMS...!"<cr>

response

OK

shutdown the LE922A6 family and successively the controlling application.

command


AT#SHDN<cr>

response

OK



- DHCP
- IP Firewall
- VPN Passthrough
- Port Forwarding
- Connection management
- Private IP address is assigned to the TE as following figures.



6.3. FTP AT Commands

This product provides application with FTP capability using a sequence of Telit FTP commands. The FTP capability is implemented inside this module so that application has to send AT command to control Telit FTP and can be received or sent user data through serial interface(USB or UART)

Mainly, following FTP functions are now available

- FTP Put
- FTP Get
- FTP Append

6.3.1. FTP Configuration

FTP parameters can be configured using following AT command. Before running FTP, it is required that customer changes FTP parameters if it is needed.

AT#FTPCFG=<tout>,<IPPignoring>,<FTPSEn>,<FTPext>



If **<connMode>** is specified “online mode”, user data can be entered on the serial port and then those data are uploaded to FTP server. To complete FTP uploading, enter escape sequence character set +++ and then FTP data connection is closed.

If **<connMode>** is specified “command mode”, user data can be uploaded using below additional AT command. After running below command, enter the **<bytestosend>** size of data on the serial port and then those data will be uploaded to FTP server

AT#FTPAPPEXT=<bytestosend>,<eof>

<bytestosend> : Specify number of bytes to be sent

<eof> : Determine if FTP uploading is to finish or not after completing to send the number of data specified by **<bytestosend>** parameter.

If **<eof>** is 0 (“normal sending of data chunk”), FTP connection for uploading triggered by #FTPPUT command is maintained even if all **<bytestosend>** size of data are sent. In this status, other FTP operation (like FTP get or append operation) could not work because FTP put operation is in progress. To finish FTP put operation, refer to the case that **<eof>** is 1.

If **<eof>** is 1 (“close data port after sending data chunk”), FTP connection for uploading is finished once all **<bytestosend>** number of data are sent. Afterwards, other FTP operation is now available.

It is possible to check if uploading file is done successfully by issuing #FTPLIST command. It requests the list of contents of specified directory and properties of the specified file.

AT#FTPLIST=<name>

<name> : Name of directory or file.

If the **<name>** is not specified, content of current working directory is requested.

6.3.4. FTP Appending file

Using this command, can open FTP data connection and append data to existing file to the FTP server.

AT#FTPAPP=<filename>,<connMode>

<filename> : Specify file name existing at FTP server

<connMode> : Select serial interface mode between module and DTE. Depending on this mode, the method how to append a file is different.



The module's different behavior per **<connMode>** is same as the one of #FTPPUT command. So, please refer to #FTPPUT command for more detail information how to use this command.

6.3.5. FTP Downloading file(Online Mode)

Using this command, can open FTP data connection, followed by downloading a specified file from FTP server. The received data is transferred on the serial port which is operated at online mode.

First of all, check if the file is existed in the FTP server or not

AT#FTPLIST=<name>

After checking the file through #FTPLIST command, run #FTPGET command.

AT#FTPGET=<filename>

<filename> : Specify existing file name at FTP server

6.3.6. FTP Downloading file in command mode

Using this command, can open FTP data connection and start downloading a file from FTP server while serial interface is remained in command mode. Because this command triggers FTP downloading in command mode, received data are buffered inside this module.

To retrieve the received data to application through serial interface, it is needed to run additional AT command(AT#FTPRECV)

AT#FTPLIST=<name>

AT#FTPGETPKT=<filename>,<viewMode>

<filename> : Specify file name existing in the FTP server

<viewMode> : Determine the format of showing received data to application. If it is 0(text format), module sends received data as plain text to application. If it is 1(hexadecimal format), module sends received data as hexadecimal text to application

To check if file transfer is completed or not, query command is useful.

AT#FTPGETPKT?

#FTPGETPKT:<remotefile>,<viewMode>,<eof>



send AT command to control Telit HTTP and can be received or sent user data through serial interface(USB or UART)

Mainly, following HTTP functions are now available

- HTTP Query
- HTTP Request
- HTTP Receive

6.5.1. HTTP Configuration

HTTP parameters should be configured with using the following AT command before running HTTP operations.

AT#HTTPCFG=<prof_id>,<server_address>,<server_port>,<auth_type>,<username>,<password>,<ssl_enable>,<timeout>,<cid>,<pkt_size>

Using this command, be able to configure following parameters

- <prof_id>** : The profile identifier
- <server_address>** : Indicating IP address of the HTTP server
- <server_port>** : Indicating the TCP remote port of the HTTP server
- <auth_type>** : The HTTP authentication type. 0 is for using authentication / 1 is for using basic authentication
- <username>** : The user identification for using authentication
- <password>** : The authentication password
- <ssl_enable>** : SSL security for HTTP operation
- <timeout>** : The time interval to wait for receiving data from HTTP server.
- <cid>** : The PDP Context Identifier.
- <pkt_size>** : send(#HTTPSND) or recv(#HTTPRCV) size for data sending or receiving.

6.5.2. HTTP Query

Using the following command, it is possible to send a HTTP GET, HEAD or DELETE operation to HTTP server.

AT#HTTPQRY=<prof_id>,<command>,<resource>,<extra_header_line>

- <prof_id>** : The profile identifier.



<command> : Indicating the command requested to HTTP server. 0 is for HTTP GET / 1 is for HTTP HEAD / 2 is for HTTP DELETE.

<resource> : Indicating the HTTP resource(URI).

<extra_header_line> : String parameter to be included within the optional HTTP header line.

If sending ends successfully, the response is OK, otherwise an error code is reported.

When the HTTP server answer is received, this product sent the following URC through serial interface(USB or UART)

#HTTPRING:<prof_id>,<http_status_code>,<content_type>,<data_size>

<prof_id> : The profile identifier that is defined above.

<http_status_code> : The numeric status code received from the server(refer to RFC2616).

<content_type> : The string is in the "Content-Type" header line from the server(refer to RFC2616).

<data_size> : The byte amount of the requested content received from the server. if server does not report size in the "Content-Length:" header line, this parameter value is 0.

6.5.3. HTTP Request

Using the following command, it is possible to send a HTTP POST or PUT operation to HTTP server.

AT#HTTPSND=<prof_id>,<command>,<resource>,<data_len>,<post_param>,<extra_header_line>

<prof_id> : The profile identifier.

<command> : Indicating the command requested to HTTP server. 0 is for HTTP POST / 1 is for HTTP PUT.

<resource> : Indicating the HTTP resource(URI).

<data_len> : Indicating the data length to input in bytes.

<post_param> : Indicating the HTTP Content-Type identifier used only for POST command.

<extra_header_line> : String parameter to be included within the optional HTTP header line.

The format of **<post_param>** is "Numeric[:extension]". the module supports 4 content types.

"0[:extension]" - "application/x-www-form-urlencoded" with optional extension.



"1[:extension]" - "text/plain" with optional extension.

"2[:extension]" - "application/octet-stream" with optional extension.

"3[:extension]" - "application/form-data" with optional extension.

For example, if **<post_param>** is "1:charset=UTF-8", the module converts "1" to "text/plain" and also converts ":charset=UTF-8" to "; charset=UTF-8".

So the module adds "text/plain; charset=UTF-8" into the Content-Type of HTTP Header.

If sending ends successfully, the response is OK, otherwise an error code is reported.

When the HTTP server answer is received, the module sent the URC(refer to #HTTTPRING URC in 6.4.2).

Note : When using the AT#HTTTPSND command, the HTTP header always include "Connection: close" line and it can not be removed.

6.5.4. HTTP Receive

When notified #HTTTPRING URC, it is possible to read data from HTTP server to use the AT#HTTTPRCV command.

AT#HTTTPRCV=<prof_id>,<maxByte>

<prof_id> : The profile identifier.

<maxByte> : Max number of bytes to read at once. Range is 0, 300-1500(default is 0 which means infinite size).

Note : If the data are not present or the #HTTTPRING <http_status_code> parameter has value 0, an error code is reported.

6.6. IP Easy Extension – Multisocket AT Commands


6.6.1. Overview

The IP Easy feature allows the **Telit module** users to contact a device on internet and establish with it a raw data flow over the UMTS/HSPA/LTE and Internet networks.

This feature can be seen as a way to obtain a "virtual" serial connection between the Application Software on the Internet machine involved and the controller of the **Telit module**, regardless of all the software stacks underlying.

An example of the protocol stack involved in the devices is reported:





This specific implementation allows the devices to interface to the **Telit module** via UMTS/HSPA/LTE and Internet packets without the need of an internal TCP/IP stack since this function is already embedded inside the module.

As a new functionality of Telit modules, multisocket is an extension of the Telit IP Easy feature, which allows the user to have more than 1 activated PDP context (this means multiple different IP address), more than one socket connection -- with a maximum of 6 connections -- and simultaneous FTP client and EMAIL client services.

The basic idea behind multisocket is the possibility of suspending an active socket connection with the escape sequence +++ and resuming the connection if needed.

With the #SKTD command it is possible to open a socket connection and get online. When the online activities are fulfilled, the +++ sequence is used to close the connection (see the figure below).



The green part represents the module command mode while the red part is the online mode.

- request the context to be activated
- request the socket connection to be opened
- exchange data
- close the TCP connection while keeping the context active

All these steps are achieved through AT commands. As far as the common modem interface, two logical statuses are involved: command mode and data traffic mode.

- In Command Mode (CM), some AT commands are provided to configure the Data Module Internet stack and to start up the data traffic.
- In data traffic mode (Socket Mode, SKTM), the client can send/receive a raw data stream which will be encapsulated in the previously configured TCP / IP packets which will be sent to the other side of the network and vice versa. Control plane of ongoing socket connection is deployed internally to the module.

6.6.2.1.1. Configuring the UMTS/HSPA/LTE access

The access configuration is done by setting:

- the number of PDP context parameter (see +CGDCONT command)
- the Authentication parameters: User Name and Password (see command #SGACT)

6.6.2.1.2. Configuring the embedded TCP/IP stack

The TCP/IP stack behavior must be configured by setting:

- the packet default size
- the data sending timeout
- the socket inactivity timeout

Before opening a connection we have to set the socket parameters with the new #SCFG command. It is possible to set all the timeout values and packet size for each socket connection with a single AT command. The command syntax is:

AT#SCFG = <Conn Id>, <Cntx Id>, <Pkt sz>, <Max To>, <Conn To>, <Tx To>

Where:

- **Conn Id** - the connection identifier



AT#SGACTAUTH=<type>
 0 – no authentication
 1 – PAP authentication(factory default)
 2 - CHAP authentication

It's also possible to enable automatic activation/reactivation of a specified PDP context in case of switching off/on, in case of deactivation from Network and in case of SIM/UICC removal.

NOTE: at least one IPEasy socket has to be previously associated to this context by command AT#SCFG. The command syntax is:

AT#SGACTCFG=<Cntx Id>,<retry>[,<delay>[,<urcmode>]]

Where:

- **<Cntx Id>**(1-5) is the context that we want to automatic activate/reactivate
- **<retry>**(0-15) is the number of activation/reactivation attempts(if it fails)
- **<delay>**(180-3600) is the delay(sec) between two successive attempts
- **<urcmode>**(0-1) enable unsolicited result code of the local IP address obtained from the network

Example:

AT#SGACTCFG=1,3 ← activation/reactivation set on context 1 with 3 attempts.

No previous setting through #SCFG is needed in this case, because socket connection identifiers **<Conn Id>** 1,2,3 are already associated to **<Cntx Id>** 1 by default.

Furthermore it is possible to abort a context activation attempt, while waiting for AT response, by sending a char on the serial port.

To enable this feature on a **<cid>** new #SGACTCFGEXT command has been implemented.

The command syntax is:

AT#SGACTCFGEXT=<cid>,<abortAttemptEnable>

By setting **<abortAttemptEnable>** on **<cid>**, attempt pre-emption is allowed.

For more details, please refer to refer to the AT Commands Reference Guide.

6.6.2.1.4. Open the connection with the internet host

With the AT command #SD (socket Dial) the TCP/UDP request to connect with the internet host starts:

- DNS query is done to resolve the IP address of the host name internet peer if required



(+++)
OK

OK is returned after the escape sequence, it means that the socket has been suspended correctly.

Now the connection number 3 is suspended and the module is in command mode so we can give another #SD command.

AT#SD = 2 ,0,80,“www.google.com”
CONNECT
(send, receive data...)

(+++)
OK

If we try to open a connection while the **ConnId** is in suspended state or online an error will be occur.

If a suspended connection receives some data the user will receive an unsolicited SRING indication from the module. In case we receive some data from the suspended connection with Telit server we'll receive this unsolicited message:

SRING: 3

where 3 is the number of the **ConnId** with data pending.



NOTE:

The unsolicited SRING indication appears only in command mode.

6.6.2.1.5. Resuming a suspended connection with #SO

This is the new command to resume a suspended connection, the command syntax is:

AT#SO = <Conn Id>

Example:

AT#SD=2,0,80,“www.google.com”
CONNECT
← data sending

(+++)
OK




```
AT#SD=2,0,80,"www.google.com"  
CONNECT  
← data sending
```

(+++)

OK

```
AT#SH=2  
OK
```

Now the connection is closed. If we send this command with an idle Connection Id we obtain in any case an OK message.



NOTE:

If there is an escape sequence in the raw data to be sent, then the TE must work it out and sent it in a different fashion to guarantee that the connection is not closed.

The pause time is defined in the parameter S12. To avoid sending of the escape sequence a command AT#SKIPESC should be set at the beginning.

6.6.2.1.7. Sending and receiving base64 encoded data

Through new #BASE64 command is possible to enable base64 encoding/decoding of data sent/received on a socket.

The command syntax is: AT#BASE64=<connId>,<enc>,<dec> where <enc> and <dec> enable respectively encoding and/or decoding on <connId> socket.

<enc> and <dec> can be set to 1 or 2 depending on MIME line feeds setting required (please refer to the AT Commands Reference Guides)

Encoding: if enabled, all data are encoded base64 while they are received from serial port, before to be sent on <connId> socket.

Decoding: if enabled, all data are decoded base64 while they are received from <connId> socket, before to be sent on the serial port.

Example:

```
AT#SKIPESC=1  
OK
```

```
AT#SD=1,0,<port>,"IP"  
CONNECT
```



Data received from serial port are sent directly on the socket

+++ (suspension)

AT#BASE64=1,1,0
OK

AT#SO=1
CONNECT

Data received from serial port are encoded

base64 before to be sent on the socket

+++ (suspension)

AT#BASE64=1,0,1
OK

AT#SO=1
CONNECT

Data received from socket are decoded base64 before to be sent on the serial port

+++ (suspension)

NOTE:



It is also possible to use new feature in command mode (Please refer to AT Commands Reference Guides).

6.6.2.2. IP Easy Incoming Connection

The IP Easy feature provides a way to accept incoming TCP/UDP connections and keep the same IP address after a connection, leaving the context active.

The steps that will be required to open a socket in listen, waiting for connection requests from remote hosts and accept these request connections only from a selected set of hosts, then close it without closing the context are:

- configuring the GPRS/UMTS/HSPA/LTE Access
- configuring the embedded TCP/IP stack behavior (see par.6.7.2.1.2)
- defining the Internet Peer that can contact this device (firewall settings) (see par.6.7.2.2.1)
- request the context to be activated (see par.6.7.2.1.3)



- request the socket connection to be opened in listen (see par. 6.7.2.2.2)
- receive connection requests (see par.6.7.2.2.3)
- exchange data
- close the TCP connection while keeping the context active (see par.6.7.2.1.6)

All these steps are achieved through AT commands. As for common modem interface, two logical statuses are involved: command mode and data traffic mode.

- In Command Mode (CM), some AT commands are provided to configure the Data Module Internet stack and to start up the data traffic.

In data traffic mode (Socket Mode, SKTM), the client can send/receive a raw data stream which will be encapsulated in the previously configured TCP / IP packets which will be sent to the other side of the network and vice versa. Control plane of ongoing socket connection is deployed internally to the module.

6.6.2.2.1. Defining the Internet Peer that can contact this device (firewall settings)

The Telit module has an internal Firewall that controls the behavior of the incoming connections to the module. The firewall applies for INCOMING (listening) connections; OUTGOING connections will be always done regardless of the firewall settings.

Firewall General policy is DROP, therefore all packets that are not included into an ACCEPT chain rule will be silently discarded.

When packet incomes from the IP address <incoming IP>, the firewall chain rules will be scanned for matching with the following criteria:

$$\langle \text{incoming IP} \rangle \ \& \ \langle \text{net mask} \rangle \ = \ \langle \text{ip_address} \rangle \ ?$$

if the result is yes, then the packet is accepted and the rule scan is finished, otherwise the next chain is taken into account until the end of the rules when the packet is silently dropped if no matching was found.

For example, let's assume we want to accept connections only from our devices which are on the IP addresses ranging from 197.158.1.1 to 197.158.255.255

We need to add the following chain to the firewall:

```
AT#FRWL=1,"197.158.1.1","255.255.0.0"
```

6.6.2.2.2. Request the socket connection to be opened in listen

The new listen command is now extended to 6 connections; it's possible to set from 1 to 6 socket listening on a specific port for the incoming connections. Another difference with the



old IP Easy is that now we receive an unsolicited indication when someone tries to connect, so we can decide to accept (**AT#SA**) or refuse (**AT#SH**) the incoming connection.



NOTE:

In case you decide to reject an incoming connection request the listening socket will be closed and if you want to re-open it the AT command **AT#SL** needs to be re-issued.

The command syntax is:

AT#SL = <Conn Id>, <Listen state>, <Listen port>[, <Closure Type>]

It's not possible to have two **ConnId** listening on the same port.

Example:

Suppose that we want to listen on port 6543 Connection Id number 2

```
AT#SL = 2, 1, 6543
OK
```

Now the module is listening for incoming connection on port 6543 with Connection Id number 2, if a remote host is trying to connect we'll receive a SRING unsolicited indication with the listening Connection Id:

```
SRING: 2
```

6.6.2.2.3. Accept an incoming connection with #SA

After receiving the SRING indication for an incoming connection we can decide to refuse the remote host connection with #SH command or accept the connection with #SA command.

The command syntax is:

AT#SA = <conn Id>

Example:

We are listening on Connection Id 3 and port 6543

```
AT#SL = 3, 1, 6543
OK
```

A remote host is trying to connect, we receive the unsolicited indication.

```
SRING: 3
```



Now we accept the connection

```
AT#SA = 3
CONNECT
```

We pass in online mode and the connection is established. With the escape sequence we suspend the socket and the module is back to command mode. To resume the suspended connection we can use the #SO command described above.



NOTE:

It's also possible to accept automatically the incoming connection if the <ListenAutoRsp> parameter has been set through the command AT#SCFGEXT(for the specific connId); see also par. 6.7.3.2.2.

In this case no unsolicited indication is received, but the connection is automatically accepted: the CONNECT indication is given and the modem goes into online data mode.

It's also possible to open a socket listening for an incoming UDP connection on a specified port.

The command syntax is:

AT#SLUDP=<connId>, <listenState>, <listenPort>

Also in this case it's possible to receive SRING unsolicited and decide to accept (AT#SA) or refuse (AT#SH).

It is also possible to accept automatically incoming connection depending on <ListenAutoRsp> settings.

6.6.2.2.4. Checking the socket status with #SS

With the old IP Easy socket connection the possible states were: online state or closed, while with multi-socket suspension we have other socket states. With the new command AT#SS we can see the status of all the six sockets.

The command syntax is:

AT#SS
[=<connId>]

Suppose that we have suspended some sockets and we are in command mode, in order to verify which Connection Id has been opened, we can use AT#SS command to have a snapshot of sockets status.



The command result is:

#SS: <ConnId>,<Status>,<Local IP>,<Local Port>,<Remote IP>,<Remote Port>

For every Connection Id with have the information about our local IP address, local port, remote IP and port if we are connected.

The Status field represents the socket status:

- 0 – Socket Closed.
- 1 – Socket with an active data transfer connection.
- 2 – Socket suspended.
- 3 – Socket suspended with pending data.
- 4 – Socket listening.
- 5 – Socket with an incoming connection. Waiting for the user accept or shutdown command.
- 6 - Socket in opening process. The socket is not in closed state but still not in Active or Suspended or Suspended with pending data state.

Example:

```
AT#SS
#SS: 1,4,217.201.131.110,21
#SS: 2,2,217.201.131.110,1033,194.185.15.73,10510
#SS: 3,3,217.201.131.110,1034,194.185.15.73,10510
#SS: 4,1,217.201.131.110,1035,194.185.15.73,10510
#SS: 5,0
#SS: 6,0
```

OK

In this case we can see Connection Id 1 in listen mode on port 21, number 2 suspended with no data pending, number 3 suspended with pending data and number 1 is online. The last two connections are closed

By issuing **AT#SS=<connId>** it's possible to get status only of the corresponding socket.

6.6.3. Command Mode Connections




6.6.3.1. Overview

6.6.4. This feature allows Telit’s modules to establish a socket connection in command mode.

The “classic” online mode connection is described in the figure below:



With command mode feature now we have:



This means that the socket connection is created, but the user can give AT commands as usually in command mode. If we receive some data on a socket a SRING message is raised.

6.6.4.1. Commands Overview

This paragraph describes the configuration and the activation of a command mode connection and the AT commands implemented to use the new configuration socket parameters. For anything concerning outgoing and incoming connections, you can refer to the chapter “Enhanced IP Easy Extension“: there are no differences at sockets level.



NOTE:

For more detailed AT commands and parameters definitions consult the AT Commands Reference Guide.

6.6.4.1.1. Opening a socket connection in command mode



To open a socket in command mode we must use the multiset commands AT#SD or AT#SA.

After a PDP context activation with AT#SGACT it is possible to open all sockets associated to this PDP context in command mode using:

AT#SD=<connId>,<txProt>,<rPort>,<IPaddr>[,<closure type>[,<IPort>],1,[<userIpType>]]]

In case of listening, after an unsolicited indication for an incoming connection

SRING: <connId>

we have to use:

AT#SA = <connId>,1

where the last parameter of AT#SD and AT#SA is <ConnMode>. Default value is 0 which means “classic” online mode, 1 is used for command mode.

Examples:

Open a command mode socket on connection Id number 1:

```
AT#SD=1,0,10510,"88.37.127.146",0,0,1
```

OK

After an unsolicited indication for an incoming connection on a listening connId:

SRING: 1

```
AT#SA = 1,1
```

OK

In “classic” online mode, if the connection is successful we have a CONNECT message, in this case we have only an OK message in case of success and we are still in command mode.

To check if the connection is really established we can use the AT#SS command to control socket status.

```
AT#SS
```

```
#SS: 1,2,217.202.12.22,38158,88.37.127.146,10510
```

```
#SS: 2,0
```

```
#SS: 3,0
```

```
#SS: 4,0
```

```
#SS: 5,0
```

```
#SS: 6,0
```

We can see that connection Id 1 is opened in suspended state.

6.6.4.1.2. Configuring extended socket parameters

Before opening socket connections it is possible to set extended configuration parameters on each of six sockets available with multiset.



Examples:

- *AT#SCFGEXT = 1,1,0,0* - Socket 1 set with SRING data amount
- *AT#SCFGEXT = 1,2,1,0* - Socket 1 set with SRING view data mode in hex.
- *AT#SCFGEXT = 1,2,1,0,0,1* – Socket 1 set also with hex data mode for sending data
- *AT#SCFGEXT = 1,3,1,0* - Socket 1 set with SRING view UDP data mode in hex.



NOTE:

With AT command #SCFGEXT2 is possible to set other configuration parameters.

The command syntax is:

AT#SCFGEXT2 = <connId>,<bufferStart>,[,<abortConnAttempt> [,<unused_B> >,<unused_C> [>,<unused_D>]]]]

Where:

- **<connId>** is the connection identifier of the socket on which settings take effect

- **<bufferStart>** sets new behavior for data sending timer

(which timeout <Tx To> is set through #SCFG):
restart every time new bytes are received from the serial port.

Note: when enabled, old behavior for data sending timer is automatically disabled to avoid overlapping.

- **<abortConnAttempt>** enables connection attempt abort (#SD/#SKTD/#SKTOP) before CONNECT(online mode) or OK(command mode).

It is possible to abort attempt and give back control to AT interface by pressing any key.

As soon as the control has been given to the AT interface the ERROR message will be received on the interface itself.

To get more details on which settings are available on different chipsets, please consult the AT Commands Reference Guide.



6.6.4.1.3. Send data in command mode connections

To send data in command mode we can use the command AT#SSEND.

At the prompt we can write data and send immediately on the socket with CTRL-Z sequence. Maximum number of bytes is 1500, if more characters are written they are truncated in upload. The command syntax is:

AT#SSEND = <connId>

Where <connId> is the connection Id of the socket that we want to use to send data (socket must be opened otherwise an error is raised).

Example:

We send the string “hello” on an echo socket with SRING mode set to Data amount.

```
AT#SSEND=1
> hello<CTRL-Z>
OK
```

SRING: 1,5



NOTE:

Through new AT#SENDEXT command it is possible to include all bytes within data to send, including special characters(ESC, Ctrl-Z and BS) previously reserved with #SEND.

The command syntax is:

AT#SENDEXT = <connId>,<bytestosend>

When <bytestosend> bytes have been sent to the serial port, operation is automatically completed.

6.6.4.1.4. Receive data in command mode connections

To receive data in command mode it is possible to use the AT#SRECV.

If we receive an unsolicited message SRING we can extract the data from the socket buffer in command mode. The syntax of the command is:

AT#SRECV=<connId>,<maxByte>

Where :

- <connId> is the connection Id of the socket with data pending
- <maxbytes> is the number of pending bytes we want to extract (maximum value is 1500).



Example:

We receive a SRING data amount and then we extract all the five bytes pending with SRECV.

SRING: 1,5

```
at#srecv=1,5
#SRECV: 1,5
hello
```

OK

6.6.4.1.5. Socket Information command

It is possible to have additional information on every socket with the AT#SI command.
The command syntax is:

AT#SI [= <connId>]

Where connId is an optional parameter, we can see info on a specific socket or for all sockets.
The information shown by the command are:

- Data sent on the socket.
- Data extracted from the socket buffer.
- Data pending on the socket buffer.
- Data not acknowledged by the remote.

AT#SI

```
#SI: 1,123,400,10,50
#SI: 2,0,100,0,0
#SI: 3,589,100,10,100
#SI: 4,0,0,0,0
#SI: 5,0,0,0,0
#SI: 6,0,98,60,0
```

OK

Sockets 1,2,3,6 are opened with some data traffic.

For example socket 1 has 123 bytes sent, 400 bytes received, 10 byte waiting to be read and 50 bytes waiting to be acknowledged from the remote side.

6.6.4.2. Examples

6.6.4.2.1. Open a command mode connection with Classic SRING



Open a connection on an Echo port:

```
AT#SD=2,0,10510,"88.37.127.146",0,0,1
OK
```

```
AT#SSEND=2
> hello
OK
```

SRING: 2

```
AT#SSEND=2
> hello
OK
```

...

Only one SRING unsolicited also if we have other data pending, the user is informed only once.

6.6.4.2.2. Open a command mode connection with Data amount SRING

Open a connection on an Echo port:

```
AT#SD=2,0,10510,"88.37.127.146",0,0,1
OK
```

```
AT#SSEND=2
> hello
OK
```

```
SRING: 2,5
AT#SSEND=2
> hello
OK
```

SRING: 2,10

SRING data amount unsolicited is updated every time new data arrives on the socket.

Now we use AT#SI to see info on connection Id 2:

```
AT#SI=2
#SI: 2,10,0,10,0
```

Ten bytes sent and ten pending on the socket.

6.6.4.2.3. Open a command mode connection with Data view SRING

We configure connection Id 1 for data view in text mode:

```
AT#SCFGEXT = 1,2,0,0
OK
```



We configure connection Id 2 for data view in hex mode for received data:

```
AT#SCFGEXT = 2,2,1,0
OK
```

Open the two echo connections in command mode:

```
AT#SD=1,0,10510,"88.37.127.146",0,0,1
OK
```

```
AT#SD=2,0,10510,"88.37.127.146",0,0,1
OK
```

Send some data on the first, text mode:

```
AT#SEND=1
> hello
OK
```

SRING: 1,5,hello

Send some data on the second, hex mode for received data:

```
AT#SEND=2
> hello
OK
```

SRING: 2,5,68656C6C6F

Data are extracted directly from the socket buffer. Now we send more than the maximum number of chars for a SRING, this will cause two unsolicited SRING.

```
AT#SEND=1
> testtesttesttesttesttesttesttesttesttesttesttesttesttesttesttest
OK
```

SRING: 1,64,testtesttesttesttesttesttesttesttesttesttesttesttesttesttesttest

SRING: 1,4,test

The first unsolicited contains the first 64 bytes of the socket buffer, the remaining 4 are extracted with the second unsolicited message.



NOTE:

it's also possible to send data in hex data mode representation.

This is possible through setting #SCFGEXT <sendDataMode> parameter to 1. The data shall be hexadecimal format (each octet of the data is given as two IRA character long hexadecimal number) and given in one line.

Example:



We configure connection Id 1 for data view in hex mode for received data and also for sending data:

```
AT#SCFGEXT = 1,2,1,0,0,1
OK
```

```
AT#SD=1,0,10510,"88.37.127.146",0,0,1
OK
```

Send some data in hexadecimal format:

```
AT#SSEND=1
> 68656C6C6F
OK
```

```
SRING: 1,5,68656C6C6F
```

6.6.4.2.4. Open a command mode UDP connection with Data view UDP SRING

We configure connection Id 1 for UDP data view in text mode:

```
AT#SCFGEXT = 1,3,0,0
OK
```

We configure connection Id 2 for data view in hex mode for received data:

```
AT#SCFGEXT = 2,3,1,0
OK
```

Open the two echo UDP connections in command mode:

```
AT#SD=1,1,10510,"88.37.127.146",0,0,1,0
OK
```

```
AT#SD=2,1,10510,"88.37.127.146",0,0,1,0
OK
```

Send some data on the first, text mode:

```
AT#SSEND=1
> hello
OK
```

```
SRING: "88.37.127.146",10510,1,5,0,hello
```

Send some data on the second, hex mode for received data:

```
AT#SSEND=2
> hello
OK
```

```
SRING: "88.37.127.146",10510,2,5,0,68656C6C6F
```



6.6.4.2.7. ICMP / PING handling

Through AT#ICMP command it's possible to enable ICMP Ping ECHO_REPLY to a subset (#FRWL setting) of IP addresses pinging the module.

The command syntax is:

AT#ICMP=<mode>

- 0 – disable ICMP Ping support(default)
- 1 – enable Ping ECHO_REPLY to the subset of IP addresses set by #FRWL
- 2 – enable Ping ECHO_REPLY to every IP addresses pinging the module



NOTE:

Through AT#PING command is possible to send PING Echo Request messages to a specified host(IP address or DNS host name) and to receive the corresponding Echo Reply.

The command syntax is:

AT#PING=<Ipaddr>[,<retryNum>[,<len>[,<timeout>[,<ttd>]]]]

Where:

- **<Ipaddr>** remote host address(IP address in dotted decimal notation or DNS host name)
- **<retryNum>** retries of PING Echo Request
- **<len>** length of PING Echo Request
- **<timeout>** timeout waiting for a single Echo Reply
- **<ttd>** time to live

NOTE:

To use AT#PING the context has to be previously activated by AT#SGACT=1,1. To receive the Echo Replies it's not necessary to use AT#ICMP before AT#PING.

Example:

After #PING command:

AT#PING="www.telit.com"

The Echo replies will be received like following string:

```
#PING: 01,"xxx.xxx.xxx.xxx",6,50
```

Where:

<Echo Reply number>,<IP address of the remote host>,<replyTime>(100 ms units),<ttd>

Subsequent Echo replies are received as follows:



7. Service and Firmware Update

The Telit Modules firmware is updated through the USB Interface normally used for the AT Commands.

It is suggested to provide an USB interface on the User Printed Circuit Board (where the Telit Module is soldered) to perform the physical connection between the Telit module and a Windows-based PC. That simple circuitry makes the firmware updating easy when a new firmware version is released.

During the User Application development or evaluation phase of the Telit module, the USB port implemented on the **Telit Evaluation Kit (EVK2)** [6] can be used to connect the Telit module to a Windows-based PC on which a dedicated tool for firmware updating is running.

Telit provides the User with two tools to update the firmware of the module. The following paragraphs describe them.



NOTE:


1. GT terminals are complete encased modems. They do not need the Telit Evaluation Kit (EVK2) to perform testing, evaluation and Firmware Update.
-

7.1. Step-by-Step Upgrade Procedure (TFI)

The firmware update can be done with a specific software tool provided by Telit that runs on Windows based PCs.

First the program will erase the content of flash memory, and then the program will write on the flash memory. To update the firmware of the module, we suggest the following procedure:

- *LE922A6_xxx_TFI.exe* includes binary image
- Tool title is :
ex): TFI V1.x – LE922A6_xxx / xxx
- Run the file *LE922A6_xxx_TFI.exe*. The following window must be displayed, select the language preferred by pressing the correspondent button.




- The End User License Agreement will appear. Please, read it and accept the terms if you are going to proceed.




7.2.1. Step-by-Step Upgrade Procedure

To update the Telit Module firmware, follow the procedure:


1. collect information about the Telit Module and Software version using the following AT commands:
 - **AT+CGMR<cr>**, returns the Software version information;
 - **AT+CGMM<cr>**, returns the Telit Module identification.
2. Run the 'Xfp.exe', the following windows are displayed.



3. After pressing OK button on the screen is displayed only the following windows.



- If you want to upgrade over the usb, please select “USB” in port combobox. if you want to upgrade over the UART, please select COM port, speed and stream file(stream files holds new firmware) through Browse button.



- After press Program button, a flashing blue bar will be increased during upgrade. The following window is displayed on the screen.



6. The following window is displayed on the screen when the module is successfully programmed.



8. Document History

Revision	Date	Changes
0	2016-06-29	Initial version

