

5.3.	DTMF TONES	55
5.4.	GSM/WCDMA POWER SAVING FUNCTION	55
5.5.	POWER SAVING MODE	56
5.5.1.	<i>URC Message in Power Saving</i>	58
5.6.	SMS HANDLING	59
5.6.1.	<i>SMS Device setup</i>	60
5.6.2.	<i>IRA Character Set</i>	74
5.6.3.	<i>Writing a New SMS to Storage</i>	75
5.6.4.	<i>Sending an SMS Previously Stored</i>	77
5.6.5.	<i>Sending a New SMS Without Storing It</i>	78
5.6.6.	<i>Deleting an SMS</i>	79
5.6.7.	<i>Reading an SMS</i>	81
5.6.8.	<i>Listing a Group of SMSs</i>	83
5.7.	USING GENERAL PURPOSE INPUT/OUTPUT PINS	85
5.7.1.	<i>GPIO pin setup</i>	85
5.7.2.	<i>GPIO pin use</i>	88
5.8.	CLOCK/ALARM FUNCTION	92
5.8.1.	<i>Clock Date/Time</i>	93
5.8.2.	<i>Alarm Function</i>	94
6.	PACKET SWITCHED DATA OPERATIONS	100
6.1.	INTRODUCTION	100
7.	GPS OPERATIONS (HE863-XXG ONLY)	104
7.1.	INTRODUCTION	104
7.2.	HE863-XXG SERIAL PORTS	104
7.3.	WGS 84	104
7.4.	NMEA 0183	104
7.4.1.	<i>GGA - Position System Fixed Data</i>	104
7.4.2.	<i>GSV - GNSS Satellites in View</i>	105
7.5.	CONTROLLING GPS RECEIVER	106
7.5.1.	<i>Power Control of GPS Receiver</i>	106
7.5.2.	<i>GPS Reset</i>	107
7.5.3.	<i>GPS Antenna Management</i>	108
7.5.4.	<i>GPS Parameters Save</i>	108
8.	SERVICE AND FIRMWARE UPDATE	109
8.1.	STEP-BY-STEP UPGRADE PROCEDURE (TFI)	109



1. Introduction

The information presented in this document is believed to be accurate and reliable. However, no responsibility is assumed by Telit Communications S.p.A. for its use, nor any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent rights of Telit Communications S.p.A. other than for circuitry embodied in Telit products. This document is subject to change without notice.

1.1. Scope

The scope of this document is to provide a hardware description of the Telit HE863-Series.

1.2. Audience

This document is intended for customers integrating HE863-FAMILYmodules in their project.

1.3. Contact Information, Support

For general contact, technical support, to report documentation errors and to order manuals, contact Telit's Technical Support Center (TTSC) at:

TS-EMEA@telit.com
TS-NORTHAMERICA@telit.com
TS-LATINAMERICA@telit.com
TS-APAC@telit.com

Alternatively, use:

<http://www.telit.com/en/products/technical-support-center/contact.php>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

To register for product news and announcements or for product questions contact Telit's Technical Support Center (TTSC).

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.



1.4. Document Organization

This document contains the following chapters:

“Chapter 1: “Introduction” provides a scope for this document, target audience, contact and support information, and text conventions.

“Chapter 2: “Overview” gives an overview of the features described in the document.

“Chapter 3: “HE863 Family Products Specification” describes in details the characteristics of the product, providing information such as power supply requirements, mechanical dimensions and interfaces specifics.

“Chapter 4: “Basic operations” : gives an overview on the basic operations using AT command: switch on/off, formatting, response, placing a voice call, etc.

“Chapter 5: “Advanced operations” : gives an overview on the advanced operations: access to phonebook, call handling, messages, GPIO setting, alarms, power consumption management etc.

“Chapter 6: “Packet switched data operations”: deals on the GPRS data managemet. It describes Enhanced Easy GPRS features.

“Chapter 7: “GPS operations”: describes GPS handling for HE863. It provides an overview on NME sentences, message formatting, GPS power management and serial ports for communications.

“Chapter 8: “Service and firmware update” describers the procedure and software tools used to update the firmware of HE863.

1.5. Text Conventions



Danger – This information MUST be followed or catastrophic equipment failure or bodily injury may occur.



Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.



2. Overview

The purpose of this document is the description of some common AT command procedures that may be used with the Telit HE863 family module. In this document, all the basic functions of a mobile phone are taken into account and for each one of them, a proper command sequence will be suggested. In the Advanced operation section the more useful services and features of the GSM and WCDMA network supported by the Telit HE863 family module is taken into account and some command sequence and usage are provided for each one of them. This document and its suggested command sequences must not be considered mandatory; instead, the information given must be used as a guide for properly using the Telit module. For further commands and features that may not be explained in this document refer to the HE863 family Product Description document where all the supported AT commands are reported.



NOTE:

The integration of the HE863-FAMILYcellular module within user application shall be done according to the design rules described in this manual

The information presented in this document is believed to be accurate and reliable. However, Telit Communications S.p.A. assumes no responsibility for its use, nor any infringement of patents or other rights of third parties, which may result from its use. No license is granted by implication or otherwise under any patent rights of Telit Communications S.p.A. other than for circuitry embodied in Telit products. This document is subject to change without notice.



3. HE863 family Product Specification

ITEM	FEATURE					
	HE863-EUD	HE863-EUR	HE863-EUG	HE863-NAD	HE863-NAR	HE863-NAG
Air interface	<ul style="list-style-type: none"> ▪ Dual-band UMTS/HSPA 2100/900 ▪ Quad-Band GSM 850/900 /1800/1900 ▪ Data only 	<ul style="list-style-type: none"> ▪ Dual-band UMTS/HSPA 2100/900 ▪ Quad-Band GSM 850/900 /1800/1900 	<ul style="list-style-type: none"> ▪ Dual-band UMTS/HSPA 2100/900 ▪ Quad-Band GSM 850/900 /1800/1900 ▪ Standalone GPS 	<ul style="list-style-type: none"> ▪ Dual-band UMTS/HSPA 1900/850 ▪ Quad-Band GSM 850/900 /1800/1900 ▪ Data only 	<ul style="list-style-type: none"> ▪ Dual-band UMTS/HSPA 1900/850 ▪ Quad-Band GSM 850/900 /1800/1900 	<ul style="list-style-type: none"> ▪ Dual-band UMTS/HSPA 1900/850 ▪ Quad-Band GSM 850/900 /1800/1900 ▪ Standalone GPS
Size	41.4(L)X31.4(W)X2.9(T)					
Data Service	<ul style="list-style-type: none"> ▪ HSPA UL 5.8Mbps, DL 7.2Mbps ▪ EDGE UL 118kbps, DL 236.8Kbps, ▪ GPRS UL 42.8kbps, DL 85.6 Kbps 					
Interface	<ul style="list-style-type: none"> ▪ 189 Balls Grid Array interface ▪ 22 general I/O ports maximum including multi-functional I/Os ▪ Status LED output ▪ 3 A/D converters ▪ 1 D/A converter (PWM output) ▪ Full RS232 CMOS UART: baud rate up to 6Mbps ▪ Reserved two wires CMOS UART for debugging ▪ USB 2.0, baud rate up to 480Mbps ▪ 1.8V/3V SIM interface 					
Antenna	External Antenna					
Audio	<ul style="list-style-type: none"> ▪ 2 pairs of analog audio interface (Balanced type) ▪ PCM interface for Digital audio (Audio only for HE863-EUG/EUR/NAG/NAR/AUG) 					
Message	SMS (MO/MT)					
SIM Card	Support 1.8 and 3V UICC					



4. Basic Operations

4.1. Command Syntax

In the next paragraphs the following notations are used:

<cr> represents the Carriage Return Character (13)

<lf> represents the Line Feed Character (10)

<xx> represents a parameter with changing name is in place of the double x. (< and > characters are only for limiting the parameter and must not be issued to the terminal).

[<xx>] represents an optional parameter whatever name is in place of the xx.

[and] characters are only for limiting the optional parameter and must not be issued to the terminal).

4.2. Command Response Timeout

Every command issued to the Telit modules returns a result response if response codes are enabled (default). The time needed to process the given command and return the response varies, depending on the command type. Commands that do not interact with the SIM or the network, and involve only internal set up settings or readings, have an immediate response, depending on SIM configuration (e.g., number of contacts stored in the phonebook, number of stored SMS), or on the network the command may interact with.

In the table below are listed only the commands whose interaction with the SIM or the network could lead to long response timings. When not otherwise specified, timing is referred to set command. For phonebook and SMS writing and reading related commands, timing is referred to commands issued after phonebook sorting is completed. For DTMF sending and dialing commands timing is referred to module registered on network (“AT+CREG?” answer is “+CREG: 0,1” or “+CREG: 0,5”).

4.3. Turning ON/OFF the HE863 family

Please refer to HE863 Hardware User Guide

4.4. Checking WCDMA Device Functionality

After a proper power on, the device is ready to receive AT commands on the USB or serial port.



Several things must be checked in order to be sure that the device is ready to send and receive calls and SMS.

4.4.1. Baudrate

HE863 family does not support autobauding. Users have to set the right speed for serial communication before device initialization. If HE863 family set the right speed, the device responds with OK. The default baudrate is 115200.

- send command `AT+IPR=<rate><cr>`
- wait for OK response

where rate is the port speed and can be 1200,2400,4800,9600,19200,38400,57600,115200,230400,460800,500000,750000,921600,1843200,3000000,3250000,6000000 bps.



TIP:

The USB or serial port suggested setting is: port speed 115200, character format 8N1 (8 bit per char, No parity bit, 1 stop bit).

4.4.2. SIM Presence Checking

The first thing to check is the SIM presence and PIN code insertion. This can be done with the following commands:

4.4.2.1. Enable the Extended Error Result Codes

- send command `AT+CMEE=1<cr>`
- wait for **OK** response
- or if you prefer the verbose format instead of the numerical format then: send command `AT+CMEE=2<cr>`
- wait for **OK** response
- Query SIM Presence and Status
- send command `AT+CPIN?<cr>`
- wait for response:

Response	Reason	Action
+CPIN: SIM PIN	SIM is present and PIN is required to continue operations	Proceed to par. 4.4.2.2
+CPIN: SIM PUK	SIM is present and 10 attempts to give SIM PIN have failed, so SIM is blocked	Send command <code>AT+CPIN=<SIM PUK></code>
+CPIN: SIM PIN2	SIM is present and 3 attempts to give SIM	Proceed to par. 4.4.2.2



	PIN2 have failed, so SIM PUK2 is required	
+CPIN: SIM PUK2	SIM is present and 10 attempts to give SIM PUK2 have failed, so SIM PIN2 cannot use anymore.	Send command AT+CPIN=<SIM PUK>
+CPIN: READY	SIM is present and no PIN code is required to proceed	Proceed ahead
+CME ERROR: 10	SIM is not inserted	Insert SIM or require SIM insertion and repeat from par. •
+CME ERROR: 13	SIM is failure	Check SIM insertion or require a new SIM not defected and repeat from par. •
+CME ERROR: 14	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM or UMTS SIM(USIM).

4.4.2.2. Provide SIM PIN (only if required see point •)

- send command **AT+CPIN="****"<cr>** where **** stands for the SIM PIN code (e.g. 1234)
- wait for response:

Response	Reason	Action
OK	SIM PIN was correct	Proceed ahead
ERROR	the PIN code inserted is not correct	Retry from par. •



NOTE:

When receiving the ERROR message, repeat Query SIM presence and status since after 3 failed attempts SIM PIN is not requested anymore, but SIM PUK is requested instead. You may need to go through procedure 4.4.2.3

4.4.2.3. Provide SIM PUK (only if required see par. •)

- send command **AT+CPIN="*****", "<newpin>"<cr>** where ***** stands for the SIM PUK code (e.g. 12345678) and <newpin> (e.g. 1234) will replace the old pin in the SIM.
- wait for response:

Response	Reason	Action
OK	SIM PUK was correct	Proceed ahead
ERROR	the SIM PUK code inserted is not correct	Retry from par. 4.4.2.3



TIP:



When receiving the ERROR message, be careful to check if the SIM PUK is correct before trying again. After 10 failed attempts to provide the SIM PUK the SIM Card will lock and will not be usable anymore.

4.4.3. Network Checking

4.4.3.1. Query Network Status

- send command **AT+CREG?<cr>**
- wait for response:

Response	Reason	Action
+CME ERROR: 10	SIM not present or damaged	Check SIM or require SIM insertion and repeat from par. •
+CME ERROR: 11	SIM is present and PIN is required to continue operations	Repeat par. 4.4.2.2
+CREG: 0,0 or +CREG: 1,0	No network is found	Check for antenna cable connection (antenna may be disconnected or damaged) or change position if the antenna is OK. Repeat par. 4.4.3.1 until a network is found.
+CREG: 0,1 or +CREG: 1,1	Mobile is registered on its home network.	Proceed ahead. Ready to call
+CREG: 0,2 or +CREG: 1,2	Mobile is currently not registered on any network but is looking for a suitable one to register.	Repeat procedure at par. 4.4.3.1 to see if it has found a suitable network to register in.
+CREG: 0,3 or +CREG: 1,3	Mobile has found some networks but it is not allowed to register on any of them, no roaming was allowed.	Try in another place, and repeat procedure at par. 4.4.3.1
+CREG: 0,4 or +CREG: 1,4	Mobile is in an unknown network status	Repeat procedure at par. 4.4.3.1 to see if it has found a suitable network to register in
+CREG: 0,5 or +CREG: 1,5	Mobile has found some networks and is currently registered in roaming on one of them	Proceed ahead. Ready to call



TIP:

When a response **+CREG: x,1** or **+CREG: x,5** is received, then the device is ready to place and receive a call or SMS. It is possible to jump directly to call setup procedures or SMS sending procedures.



4.4.3.2. Network Operator Identification

Once the mobile has registered on some network (or even if it has returned +CREG:x,3), it is possible to query the mobile for network identifications, codes and names:

- send command **AT+COPS=?<cr>**
- wait for response in the format:

+COPS: : [list of supported (<stat>,long alphanumeric <oper>,short alphanumeric <oper>,numeric <oper>,< AcT>)]s]

[,,(list of supported <mode>s),(list of supported <format>s)]

where:

<stat> - operator availability

0 - unknown

1 - available

2 - current

3 - forbidden

<AcT> access technology selected:

0 GSM

2 UTRAN



NOTE:

Since with this command a network scan is done, this command may require some seconds before the output is given.

For example:

command

AT+COPS=?<cr>

Answer:

+COPS: (2,"I WIND","WIND","22288",2),(1,"SI MOBITEL GSM","", "29341",0),(1,"Vodafone IT","OMNITEL","22210",2), (3,"I TIM","TIM","22201",0),,(0-4),(0-2)

OK



In this case the mobile is registered on the network "I WIND" which is a network from Italy, code: 222 and Network ID: 88. There is also another network available for registration:

"SI MOBITEL GSM" which is a network from Slovenia, code: 293 and Network ID: 41 ,
"SI.MOBIL" which is a network from Slovenia, code: 293 and Network ID: 40 and
Vodafone IT from Italy with Nation code 22 and Network 10.

The other network is not available for registration:



NOTE:

This command issues a network request and it may require quite a long time to respond, since the device has to wait the answer from the network (it can be as long as 60 seconds). Do not use this command if not necessary.

"I TIM" from Italy, code: 222 and Network ID: 01 - FORBIDDEN



TIP:

In this case a "I TIM" logo might be reproduced on the MMI to give the user the information that is registered on that network.

4.4.3.3. Check for Received Signal Strength & Quality

Once the mobile has registered on one network, it may be useful to know the received signal strength & quality to give the user an indication of the reliability of the network.

send command **AT+CSQ<cr>**

wait for response in the format:

<WCDMA network >

+CSQ: <rss>,99

OK

<GSM network>

+CSQ: <rss>,<ber>

OK

where:

<rss> is an integer from 0 to 99 that indicates the received signal strength:

<rss> value	Signal Strength	Indication
0	-113 dBm or less	Signal is VERY low: at the extreme sensibility limit
1	-111 dBm	MMI may indicate only 1 antenna bar



2	-109 dBm	MMI may indicate only 1 antenna bar
3	-107 dBm	MMI may indicate only 1 antenna bar
4	-105 dBm	MMI may indicate only 1 antenna bar
5	-103 dBm	MMI may indicate only 1 antenna bar
6	-101 dBm	MMI may indicate 2 antenna bars
7	-99 dBm	MMI may indicate 2 antenna bars
8	-97 dBm	MMI may indicate 2 antenna bars
9	-95 dBm	MMI may indicate 2 antenna bars
10	-93 dBm	MMI may indicate 3 antenna bars
11	-91 dBm	MMI may indicate 3 antenna bars
12	-89 dBm	MMI may indicate 3 antenna bars
13	-87 dBm	MMI may indicate 3 antenna bars
14	-85 dBm	MMI may indicate 3 antenna bars
15	-83 dBm	MMI may indicate 4 antenna bars
16	-81 dBm	MMI may indicate 4 antenna bars
17	-79 dBm	MMI may indicate 4 antenna bars
18	-77 dBm	MMI may indicate 4 antenna bars
19	-75 dBm	MMI may indicate 4 antenna bars
20	-73 dBm	MMI may indicate 4 antenna bars
21	-71 dBm	MMI may indicate 4 antenna bars
22	-69 dBm	MMI may indicate 4 antenna bars
23	-67 dBm	MMI may indicate 4 antenna bars
24	-65 dBm	MMI may indicate 4 antenna bars
25	-63 dBm	MMI may indicate 4 antenna bars
26	-61 dBm	MMI may indicate 4 antenna bars
27	-59 dBm	MMI may indicate 4 antenna bars
28	-57 dBm	MMI may indicate 4 antenna bars
29	-55 dBm	MMI may indicate 4 antenna bars
30	-53 dBm	MMI may indicate 4 antenna bars
31	-51 dBm or more	MMI may indicate 4 antenna bars
99	not detected	MMI may indicate flashing antenna bars



NOTE:

When **<rssi>** is less than 6, with only 1 MMI antenna bar, the quality of a call will be poor and the call may even drop.

<ber> is an integer from 0 to 7 and 99 that reports the received signal quality measured on the radio traffic channel.



NOTE:

The quality is measured on the traffic channel. It is available only during a conversation. In Idle the reported value must not be considered.



In conversation the quality decreases with the increase of the **<ber>** number.

NOTE:

The **<ber>** value refers strictly to the GSM radio channel and is a very technical parameter. It can be used to monitor the voice call quality since the voice quality is inversely proportional to the **<ber>** number. HE863 family doesn't support ber in WCDMA network so the return value fixed as 99.

NOTE:

For Data calls the signal quality reported is not directly connected to the connection quality. The reported signal quality refers only to the GSM radio channel link and not to the whole path from the caller to the receiver, so it may happen that the quality on the GSM radio link is very good and hence the reported **<ber>** is 0 (good quality) but the quality of the remaining path to the other party is very bad and the final data connection quality is very poor.

For this reason the signal quality indicator **<ber>** must not be taken into account to monitor data calls quality.

4.4.3.4. Quick Network Status Checking

Once the mobile has registered on one network, it may be useful to know the received signal strength and the network on which the mobile is registered. These information can be gathered with the commands **+CREG**, **+COPS** and **+CSQ**, which are part of the standard 3gpp GSM 07.07/27.007 commands as seen before, unfortunately these commands are not so fast in the response due to network response time, especially the **+COPS** command. If You want to keep your software as general as possible you can follow the indications given before and forget this part; instead if you need or want a faster way to check at the mobile network information, the HE863 family provides a special command **#MONI** which can be used to gather all the information needed in a faster and simpler way:

- send command **AT#MONI=0<cr>**
- wait for **OK** response
- send command **AT#MONI?<cr>**
- wait for response in the format:
When extracting data for the serving cell and the network name is known the format is:

(GSM network)

**#MONI: <netname> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id>
ARFCN:<arfcn> PWR:<dBm> dBm TA: <timadv>**

(WCDMA network)



**#MONI: <netname> PSC:<psc> RSCP:<rscp> LAC:<lac> Id:<id>
EcIo:<ecio> UARFCN:<uarfcn> PWR:<dBm> dBm DRX:<drx> SCR:<scr>**

When the network name is unknown, the format is:

(GSM network)

**#MONI: Cc:<cc> Nc:<nc> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id>
ARFCN:<arfcn> PWR:<dBm> dBm TA: <timadv>**

(WCDMA network)

**#MONI: Cc:<cc> Nc:<nc> PSC:<psc> RSCP:<rscp> LAC:,<lac> Id:<id>
EcIo:<ecio> UARFCN:<uarfcn> PWR:<dBm> dBm DRX:<drx> SCR:<scr>**

When extracting data for an adjacent cell, the format is:

(GSM network)

#MONI: Adj Cell<n> [LAC:<lac> Id:<id>] ARFCN:<arfcn> PWR:<dBm> dBm

(WCDMA network)

**#MONI: PSC:<psc> RSCP:<rscp> EcIo:<ecio> UARFCN:<uarfcn>
SCR:<scr>**

where:

<netname> - name of network operator

<cc> - country code

<nc> - network operator code

<n> - progressive number of adjacent cell

<bsic> - base station identification code

<qual> - quality of reception

0..7

<lac> - localization area code

<id> - cell identifier

<arfcn> - assigned radio channel

<dBm> - received signal strength in dBm

<timadv> - timing advance

<psc> - primary synchronisation code

<rscp> - Received Signal Code Power in dBm

<ecio> - chip energy per total wideband power in dBm

<uarfcn> - UMTS assigned radio channel



This command must be used only to gather information on network name and signal strength, to check if mobile is registered or is looking for a suitable network to register. Always use the **+CREG** command. This is due to the fact that if the network signal is too weak and mobile loses the registration. Until a new network is found the **#MONI** command reports the last measured valid values and not the real ones. The **TA** (timing advance parameter) is valid only during a call.

TIP:

To properly use this feature, check network registration with command **+CREG** as seen on par. 2.7.3.1 and when mobile is registered query the mobile for network operator name and signal strength with **#MONI** command.

4.5. Placing a Voice call

Before a voice call can be placed, it is recommended to check if the mobile is registered on a network (see par. 4.4.3.1) and if the signal strength is enough to ensure a call can be made.

4.5.1. Voice Call Device Setup

4.5.1.1. Set the Device in Voice Mode

- send command **AT+FCLASS=8<cr>**
- wait for **OK** response



NOTE:

This command may be omitted if the modifier ";" is added at the end of the **ATD** command after the dialed number.

4.5.1.2. Set the Desired Audio Path Active

The HE863 family has three different audio paths:

- internal microphone/ear (MT)
- external microphone/ear (HF)
- PCM microphone/ear(PCM)

Usually the internal path is used for a handset function, while the external is used for handsfree function. There are two ways to switch between these two paths:

- **SOFTWARE:** by using the command **AT#CAP= <n>** (with n=1 OR n=2)



- **HARDWARE:** by setting **AT#CAP=0** and setting the AXE input high (internal MT) or low (external HF).

If only one path is needed, then it is preferable to use the internal one (MT).



TIP:

When Hardware control is not needed AXE pin can be left unconnected.

TIP:

The audio paths can also be switched in both ways during a call.

- send command **AT#CAP=<n><cr>**

where:

<n> = 0 for **HARDWARE** control with AXE input

<n> = 1 for external HF path (regardless of the AXE input status)

<n> = 2 for internal MT path (regardless of the AXE input status)

- wait for **OK** response

For example:

1 - Let us assume that the desired audio path is always the internal MT

command

AT#CAP=2<cr>

answer

OK

2 - Let us assume that the desired audio path has to be determined by **HARDWARE** pin AXE

command

AT#CAP=0<cr>

answer

OK

Now set the hardware pin AXE in the desired status.

Set the desired volume on the active audio path speaker output

This setting is not strictly necessary; it is also possible to keep the default volume setting.

- send command **AT+CLVL=<vol><cr>**



where:

<vol> is a number between 0 and 10 representing the volume setting:

0 - minimum volume

10 - maximum volume

- wait for **OK** response



NOTE:

The volume setting refers to the ACTIVE path ear line and is stored each time. When changing audio path, the volume setting will be reset to the previously stored value for that audio path.

4.5.1.3. Check for Microphone Mute Setting

The microphone of the active path can be muted with an AT command; to be sure that it is not muted, it is suggested to check it with this command

- Send command **AT+CMUT?<cr>**
- wait for response in the format:

+CMUT: <mute>

OK

where:

<mute> is the muting setting for the microphone:

0 - microphone active

1 - microphone muted



NOTE:

The mute setting is different from Volume setting: it refers to both the audio paths, the mute setting will remain even when changing audio path.

4.5.2. Phone Number Dialing

4.5.2.1. Dial a Given Phone Number

Send command **ATD <PhoneNumber><cr>**

where:

<PhoneNumber> is the phone number to be dialed

wait for response:



Response	Reason	Action
OK	The call has been placed	Wait for the other party to lift the receiver
BUSY	The line called is busy	retry later
NO ANSWER	The receiver did not answer the call	retry later
NO CARRIER	Call placing has not been successful	check for mobile registration and signal strength

For example:

1- Let us assume you have to call the national number 040 - 4192111,

command

ATD 0404192111<cr>

response

OK

2- Let us assume you have to call the national number but in international format +39-40-4192111,

command

ATD +39404192111<cr>

response

OK

3- Let us assume you have to call the international number +386-40-4192111 without previously setting the +FCLASS=8 (voice),

command

ATD +386404192111;<cr>

response

OK

4.5.3. Closing the Voice Call

4.5.3.1. Hang up the Voice Call

- send command **AT+CHUP<cr>**
- wait for response **OK**





TIP:

During the voice call the device remains in command mode, so the escape sequence (+++) must not be issued before sending commands.

4.6. Placing a Circuit Switched Data (CSD) call

Before a data call can be placed, it is recommended to check if the mobile is registered on a network (see par. 2.7.3.1) and if the signal strength is enough to ensure that a call can be made.

4.6.1. CSD Call Device Setup

4.6.1.1. Set the Device in Data Mode

- send command `AT+FCLASS=0<cr>`
- wait for **OK** response



TIP:

The **+FCLASS** setting is maintained in the memory and there is no need to repeat this command if **+FCLASS** setting is not changed.

4.6.1.2. Set the Desired Modulation and Speed for the Connection

The data connection can be made using different modulations at different speeds. This connection mode can be selected with the command **+CBST**. The syntax for the command is: `AT+CBST=<speed>,<name>,<ce>`

<speed> : data rate

- 0 - autobauding (automatic selection of the speed)
- 4 - 2400 bps (V.22bis)
- 5 - 2400 bps (V.26ter)
- 6 - 4800 bps (V.32)
- 7 - 9600 bps (V.32)
- 12 - 9600 bps (V.34)
- 14 - 14400 bps (V.34)
- 15 - 19200 bps (V.34)
- 16 - 28800 bps (V.34)
- 17 - 33600 bps (V.34)
- 39 - 9600 bps (V.120)
- 43 - 14400 bps (V.120)
- 47 - 19200 bps (V.120)



- 48 - 28800 bps (V.120)
- 49 - 38400 bps (V.120)
- 50 - 48000 bps (V.120)
- 51 - 56000 bps (V.120)
- 68 - 2400 bps (V.110 or X.31 flag stuffing)
- 70 - 4800 bps (V.110 or X.31 flag stuffing)
- 71 - 9600 bps (V.110 or X.31 flag stuffing)
- 75 - 14400 bps (V.110 or X.31 flag stuffing)
- 79 - 19200 bps (V.110 or X.31 flag stuffing)
- 80 - 28800 bps (V.110 or X.31 flag stuffing)
- 81 - 38400 bps (V.110 or X.31 flag stuffing)
- 82 - 48000 bps (V.110 or X.31 flag stuffing)
- 83 - 56000 bps (V.110 or X.31 flag stuffing)
- 84 - 64000 bps (X.31 flag stuffing)
- 115 - 56000 bps (bit transparent)
- 116 - 64000 bps (bit transparent)
- 120 - 32000 bps (PIAFS32k)
- 121 - 64000 bps (PIAFS64k)
- 130 - 28800 bps (multimedia)
- 131 - 32000 bps (multimedia)
- 132 - 33600 bps (multimedia)
- 133 - 56000 bps (multimedia)
- 134 - 64000 bps (multimedia)

<name> : bearer service
 0 - data circuit asynchronous (UDI or 3.1 kHz modem)
 1 - data circuit synchronous (UDI or 3.1 kHz modem)
 4 - data circuit asynchronous (RDI)
 5 - data circuit synchronous (RDI)

<ce> : connection element
 0 - transparent
 1 - non-transparent
 2 - both, transparent preferred
 3 - both, non-transparent preferred

Once selected the appropriate **<speed >**, **<name>** and **<ce>** parameters

- send command **AT+CBST=<speed>,<name>,<ce><cr>**
- wait for **OK** response

4.6.2. Phone number dialing (data call)

4.6.2.1. Dial a Given Phone Number

- send command **ATD <PhoneNumber><cr>**
 where:



- **<PhoneNumber>** is the phone number to be dialed
- wait for response:

Response	Reason	Action
CONNECT 9600	The called modem is now on line.	exchange data
BUSY	The line called is busy	retry later
NO ANSWER	The receiver did not answer the call	retry later
NO CARRIER	The modem handshaking has not been successful	Check for mobile registration and signal strength and eventually retry.



TIP:

The response to the ATD command is returned after the modem handshaking, this takes about 30 seconds, so allow this time before doing anything.

TIP:

When the device is doing the handshake the issue of any character closing the handshake aborts the call.

For example:

1- Let us assume you have to call the national number 040 - 4192111,

command

ATD 0404192111<cr>

response

CONNECT 9600

2- Let us assume you have to call the national number but in international format +39-40-4192111,

command

ATD +39404192111<cr>

response

CONNECT 9600

3- Let us assume you have to call the international number +386-40-4192111,

command

ATD +386404192111<cr>

response



CONNECT 9600

4.6.3. Closing the Data call

4.6.3.1. Exit the data mode and enter the command mode

- send escape sequence +++
- wait for response OK



TIP:

During the data call the device remains in data (on line) mode, the escape sequence (+++) hangs up data call with the setting value of &D2.

In case of &D0 and &D1, recognize the escape sequence (+++) as the user data.



4.7. Answer an incoming Call

When an incoming call is detected, the device reports an unsolicited code, which may be:

Unsolicited code	Reason
RING	The extended format of incoming call indication is disabled and a call (voice or data) is incoming.
+CRING: VOICE	The extended format of incoming call indication is enabled and a voice call is incoming.
+CRING: ASYNC	The extended format of incoming call indication is enabled and an asynchronous transparent data call is incoming.
+CRING: REL ASYNC	The extended format of incoming call indication is enabled and an asynchronous reliable (not transparent) data call is incoming.
+CRING: SYNC	The extended format of incoming call indication is enabled and a synchronous transparent data call is incoming.
+CRING: REL SYNC	The extended format of incoming call indication is enabled and a synchronous reliable (not transparent) data call is incoming.
+CRING: FAX	The extended format of incoming call indication is enabled and a fax call is incoming.

To answer the call:

- send command **ATA<cr>**
- wait for response:

Response	Reason	Action
CONNECT 9600	The incoming call was a DATA one and called modem is now on line.	exchange data
ERROR	No incoming call is found, call may have been lost	call lost
NO CARRIER	The incoming call was a DATA one and the modem handshaking has not been successful	check for mobile registration and signal strength and modem settings.
OK	The incoming call was a VOICE call and is now active.	proceed ahead



TIP:

The call is answered with the appropriate type (VOICE or DATA) regardless of the **+FCLASS** active setting. To distinguish between Data and Voice see the command response or the extended format incoming call indication.



4.8. Data Flow Control

The Telit HE863 family provides the flow control method to avoid the unexpected data loss, while data communication is activating via serial interface such as UART and USB.

Below table describes the flow control method can be selected in serial interface

	S/W Flow control (Xon/Xoff)	H/W Flow control (RTS/CTS)	No Flow control	Remark
UART1		0		Only support fro HW Flow control
USB0	0			S/W handshaking with NACK/ACK
USB3	0			S/W handshaking with NACK/ACK



5. Advanced Operations

5.1. Accessing the Phonebook

The HE863 family can access the phonebook storage of the SIM card inserted, by using specific AT commands it is possible to store and recall phone numbers and their associated name.

5.1.1. Preliminary Phonebook Setup

The HE863 family supports several SIM phonebook storages:

- **"FD" - SIM/USIM** fixed dialing-phonebook. If a SIM card is present or if a UICC with an active GSM application is present, the information in EF_{FDN} under $EF_{Telecom}$ is selected. If a UICC with an active USIM application is present, the information in EF_{FDN} under ADF_{USIM} is selected.
- **"LD" - SIM/UICC** last-dialing-phonebook **"MC" - MT** missed(unanswered received) calls list (+CPBW may not be applicable for the storage) **"ME" - MT** phonebook
- **"ON" - SIM(or MT)** own numbers (MSISDNs) list (reading of this storage may be available through +CNUM also). When storage information in the SIM/UICC, if a SIM card is present or if a UICC with an active USIM application is present, the information in EF_{MSISDN} under $DF_{Telecom}$ is selected. If a UICC with an active USIM application is present, the information in EF_{MSISDN} under ADF_{USIM} is selected.
- **"SM" - SIM/UICC** phonebook. If a SIM card is present or if a UICC with an active GSM application is present, EF_{ADN} under $DF_{Telecom}$ is selected. If a UICC with active USIM application is present, the global phonebook, $DF_{PHONEBOOK}$ under $DF_{Telecom}$ is selected.
- **"BL"** Blacklist phonebook (delete only)
- **"EC" - SIM/USIM (or MT)** emergency-call-codes phonebook (+CPBW is not be applicable for this storage)
- **"AP"** Selected application phonebook.
- **"BN"** SIM barred-dialling-number phonebook (only valid with PIN2)
- **"SN"** SIM service-dialling-number phonebook

In order to access the storage, you have to choose which one will be active. This must be always the first PB operation. Once the storage is selected, it is not needed anymore to select it again until the desired storage remains the one active and the device is not turned off.



5.1.1.1. Selecting PB Storage Active

- send command AT+CPBS=<storage>[<,passwrod>]<cr>

where:

<storage> is the desired PB storage:

“FD” - SIM/USIM fixed dialing phonebook

“LD” - SIM/USIM last dialing phonebook

“ON” - SIM (or MT) own numbers (MSI storage may be available through +CNUM also).

“SM” - SIM/UICC phonebook

“BL” - Blacklist phonebook (delete only)

“EC” - SIM emergency-call-codes phonebook (read only)

“AP” - Selected application phonebook.

“BN” - SIM/USIM barred-dialling-number phonebook (only valid with PIN2)

“SN” - SIM/USIM service-dialling-number phonebook

<password>: string type value representing the PIN2-code required when selecting PIN2-code locked <storage>s above, e.g. “FD” or the hidden key to be verified in order to access to the hidden phonebook entries in the SIM/USIM or any other phonebook with hidden entries.

- wait for response:

Response	Reason	Action
OK	selected PB is now active	Proceed ahead
ERROR	some error occurred	Enable extended result codes (see par. 4.4.2.1) and retry.
+CME ERROR: 10	SIM not present	Check SIM or require SIM insertion and repeat from par. •
+CME ERROR: 11	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 4.4.2.2)
+CME ERROR: 12	SIM is present and PUK is required to continue operations	insert SIM PUK (see par. 4.4.2.3)
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. •
+CME ERROR: 14	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM or UMTS SIM(USIM).
+CME ERROR: 17	PIN2 is required to continue	Enable FD facility with +CLCK (see



operations, since FD facility is not enabled. par.5.1.1.2) and retry.



NOTE:

After power up & PIN authentication the device reads all the SIM for a backup, hence SIM access is inhibited (SIM is busy after the issue of the PIN or after power up if PIN request is disabled) for a time varying from few seconds to about a minute, depending on the percentage of written records in the SIM phonebook. If Phonebook commands are issued during this time the device returns an error message. If this happens, the operations will start again later.

NOTE:

Due to the particular features of the **FD** storage, when selecting the **FD** storage the PIN2 must be inserted or the **FD** facility must be enabled.

If **+CPBS** command reports **+CME ERROR: 17** then enable the facility with command **+CLCK** (see par. 5.1.1.2)

For example:

1- Let us assume you want to select the "SM" normal phonebook for operations, command

AT+CPBS="SM"<cr>

response

OK

2- Let us assume you want to select the "EC" emergency-call_codes phonebook list for operations,

command

AT+CPBS="EC"<cr>

response

OK

3. Let us assume you want to select the "FD" fixed dialing phonebook for operations command

AT+CPBS="FD", "0000"<cr>

response

OK



5.1.1.2. Enable Fixed Dialing Phonebook Facility (only for FD PB)

- send command `AT+CLCK="FD",1,<PIN2><cr>`

where:

`<PIN2>` is the PIN2 code of the SIM.

- wait for response:
-

Response	Reason	Action
OK	FD facility is now enabled	Return to select PB (see par. 5.1.1.1)
ERROR	some error occurred	Enable extended result codes (see par. 4.4.2.1), check if the PIN2 is correct and retry.
+CME ERROR: 17	the inserted PIN2 is wrong	Check PIN2 code and retry.



NOTE:

When receiving the ERROR or +CME ERROR message, repeat Query SIM presence and status since after 3 failed attempts SIM PIN2 is not requested anymore, SIM PUK2 is requested instead. You may need to go through procedure 4.4.2.4 (but insert PUK2 instead of PUK1)

5.1.2. Phonebook Entry Search by Name

First, you must select the "SM" storage as active (see par.5.1.1.1).

- send command `AT+CPBF=<text><cr>`

where:

`<text>` is the desired string to be found in the name field of the PB record.

- wait for response in the format:

syntax: `[+CPBF:<index1>,<number>,<type>,<text>[,<hidden>][,<group>][,<adnumber>][,<adtype>][,<secondtext>][,<email>]]`

`<CR><LF>+CPBF:`

`<index2>,<number>,<type>,<text>[,<hidden>][,<group>][,<adnumber>][,<adtype>][,<secondtext>][,<email>]]`

where:

`<index1>`, `<index2>`, `<index>`: integer type values in the range of location numbers of phonebook memory



- <number> string type phone number of format <type>
- <type> type of address octet in integer format (refer TS 24.008 [8] subclause 10.5.4.7)
- <text> string type field of maximum length <tlength>; character set as specified by command Select TE Character Set +CSCS
- <group> string type field of maximum length <glength>; character set as specified by command Select TE Character Set +CSCS
- <adnumber> string type phone number of format <adtype>
- <adtype> type of address octet in integer format (refer TS 24.008 [8] subclause 10.5.4.7)
- <secondtext> string type field of maximum length <slength>; character set as specified by command Select TE Character Set +CSCS
- <email> string type field of maximum length <elength>; character set as specified by command Select TE Character Set +CSCS
- <nlength> integer type value indicating the maximum length of field <number>
- <tlength> integer type value indicating the maximum length of field <text>
- <glength> integer type value indicating the maximum length of field <group>
- <slength> integer type value indicating the maximum length of field <secondtext>
- <elength> integer type value indicating the maximum length of field <email>
- <hidden> indicates if the entry is hidden or not
 - 0 phonebook entry not hidden
 - 1 phonebook entry hidden

For example:

1- Let us assume you want to select the "SM" normal phonebook for operations, command

AT+CPBS="SM"<cr>

response

OK

Now you might want to look for the entries with the name starting with: "Fa"

command

AT+CPBF="Fa"<cr>

the response may look like:



```
+CPBF= 7,"39404192369",145,"Fabio",0
+CPBF= 9,"0404192111",129,"Fabrizio",0
OK
```

Now you might want to look for the entries with the name starting with: "FAUSTO" but no record contains this name:

```
command
AT+CPBF="FAUSTO"<cr>
response
OK
```

5.1.3. Phonebook Entry Read by Index

First, you must select the desired storage as active (see par. 5.1.1.1). Then:

- send command **AT+CPBR=<index>[,<index2>]<cr>**

where:

<index> is the index number of the desired PB record to be read.

- wait for response in the format:

```
+CPBR: (list of supported
<index>s),[nlength],[tlength],[<glength>],[<alength>],[<slength>],
[<elength>]
```

OK

where:

<index> integer type values in the range of location numbers of phonebook memory

<nlength> integer type value indicating the maximum length of field **<number>**

<tlength> integer type value indicating the maximum length of field **<text>** {40}.

<glength> integer type value indicating the maximum length of field **<group>**

<alength> integer type value indicating the maximum length of field **<anr>**

<slength> integer type value indicating the maximum length of field **<secondtext>**

<elength> integer type value indicating the maximum length of field **<email>**For

example:

1- Let us assume you want to select the "SM" normal phonebook for operations, command



AT+CPBS="SM"<cr>

response

OK

Now you might want to look for the entry at the position index = 7

command

AT+CPBR=7<cr>

the response may look like

+CPBR= 7,"+39404192369",145,"Fabio",0

OK

Now you might want to look for the entries at the positions from 7 to 9 and for example the position at index 8 is empty

command

AT+CPBR=7,9<cr>

the response may look like

+CPBR= 7,"+39404192369",145,"Fabio"

+CPBR= 9,"0404192111",129,"Fabrizio"

OK

5.1.4. Phonebook Entry Write

First you must select the desired storage as active (see par. 5.1.1.1). Then:
send command **AT+CPBW=[<index>][,<number>[,<type>[,<text>[,<group>[,<adnumber>[,<adtype>[,<secondtext>[,<email>[,<sip_uri>[,<tel_uri>[,<hidden>]]]]]]]]]]<cr>**

where:

- <index>** integer type values in range of location numbers of phonebook memory
- <number>** string type phone number of format <type>
- <type>** type of address octet in integer format
- <text>** string type field of maximum length <tlength>
- <hidden>** indicates if the entry is hidden or not ? only available, if a UICC with an active USIM application is present
 - 0 phonebook entry not hidden
 - 1 phonebook entry hidden format (refer TS 24.008[8] subclause 10.5.4.7)
- <group>** string type field of maximum length <glength>



- <adnumber> string type phone number of format <adtype>
- <adtype> type of address octet in integer format (refer TS 24.008[8] subclause 10.5.4.7)
- <secondtext> string type field of maximum length <slength>
- <email> string type field of maximum length <elength>

- wait for response:

Response	Reason	Action
OK	Record has been successfully written	Proceed ahead
ERROR	some error occurred	Enable extended result codes (see par. 4.4.2.1), and retry.
+CME ERROR: 10	SIM not present	Check SIM or require SIM insertion and repeat from par. •
+CMS ERROR: 310	SIM not present	Check SIM or require SIM insertion and repeat from par. •
+CME ERROR: 11	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 4.4.2.2)
+CMS ERROR: 311	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 4.4.2.2)
+CME ERROR: 12	SIM is present and PUK is required to continue operations	insert SIM PUK (see par. 4.4.2.3)
+CMS ERROR: 316	SIM is present and PUK is required to continue operations	insert SIM PUK (see par. 4.4.2.3)
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. •
+CMS ERROR: 313	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. •
+CME ERROR: 14	SIM is busy	retry later
+CMS ERROR: 314	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM or UMTS SIM(USIM).
+CMS ERROR: 315	SIM is wrong type	Check SIM, it must be a GSM SIM or UMTS SIM(USIM).
+CME ERROR: 21	invalid index	Change index number or leave it empty and retry.
+CME ERROR: 20	memory full	PB storage is full.
+CMS ERROR: 322	memory full	PB storage is full.

For example:

- 1- Let us assume you want to select the "SM" normal phonebook for operations, command



AT+CPBS="SM"<cr>

response

OK

Now you might want to write a new record on the PB:

Command

**AT+CPBW=1,"1234892356",129,"Fabio","Friends","123456789",129,"VIP",
"admin@email.com"<cr>**

response

OK

Now you may want to check if the operation has really succeeded and where the new record has been written (obviously the operation was successful, since the device returned OK).

command

AT+CPBF="Fa"<cr>

response

**+CPBF: 1,"1234892356",129,"Fabio",0,"Friends","123456789",129,"VIP",
"admin@email.com"**

OK

The new record was written at the position index 8. (The first free record index found).

5.1.5. Phonebook Entry Delete

First, the desired storage must be active (see par.5.1.1.1). Then:

- send command **AT+CPBW=<index><cr>**

where:

<index> is the index number of the desired PB record to be deleted.

- wait for response:

Response	Reason	Action
OK	Record has been successfully	proceed ahead



	deleted	
ERROR	some error occurred	Enable extended result codes (see par. 4.4.2.1), and retry.
+CME ERROR: 21	invalid index, out of PB storage limits	check index number and retry.
+CME ERROR: 10	SIM not present	Check SIM or require SIM insertion and repeat from par. •
+CMS ERROR: 310	SIM not present	Check SIM or require SIM insertion and repeat from par. •
+CME ERROR: 11	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 4.4.2.2)
+CMS ERROR: 311	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 4.4.2.2)
+CME ERROR: 12	SIM is present and PUK is required to continue operations	insert SIM PUK (see par. 4.4.2.3)
+CMS ERROR: 316	SIM is present and PUK is required to continue operations	insert SIM PUK (see par. 4.4.2.3)
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. •
+CMS ERROR: 313	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. •
+CME ERROR: 14	SIM is busy	retry later
+CMS ERROR: 314	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM or UMTS SIM(USIM).
+CMS ERROR: 315	SIM is wrong type	Check SIM, it must be a GSM SIM or UMTS SIM(USIM).



TIP:

The delete operation simply overwrites the record number <index> with an empty record.

If the record to be deleted was already empty, no error messages will be shown, but it will be only filled again with empty values.

5.1.6. Phonebook Entry Dial

You may want to dial a number previously stored in the phonebook. First, you must find the desired phone number index position, to do it use **the +CPBF** command.



Once the <index> number is known, set up the device for the type of call you want to dial. Then:

- send command **ATD> <index><cr>**

where:

<index> is the index number of the desired PB record to be dialed.

- wait for response according to the call type you issued.

For example:

1- Let us assume you want to make a Voice call on the internal audio path MT to "Fabio" whose number is stored on the SIM PB:

- Select the PB as active storage

command

AT+CPBS="SM"<cr>

response

OK

Now find the index number where "Fabio" is recorded:

command

AT+CPBF="Fabio"<cr>

the response may look like

+CPBF= 7,"+39404192369",145,"Fabio"

OK

the first field is the index position: 7 in this case.

Now set up Voice call:

command

AT+FCLASS=8<cr>

response:

OK

AT#CAP=2 <cr>

OK

AT+CLVL=8<cr>

OK

AT+CMUT? <cr>



```
+CMUT: 0
and dial
ATD> 7<cr>
OK
```

5.2. Distinguish Calls

5.2.1. Identify the Call Type

The HE863 family is able to identify the call type before answering it. It is possible to have different ring indications (unsolicited codes) depending on the call type:

Unsolicited code	Reason
RING	The extended format of incoming call indication is disabled and a call (voice or data) is incoming.
+CRING: VOICE	The extended format of incoming call indication is enabled and a voice call is incoming.
+CRING: ASYNC	The extended format of incoming call indication is enabled and an asynchronous transparent data call is incoming.
+CRING: SYNC	The extended format of incoming call indication is enabled and a synchronous transparent data call is incoming.
+CRING: REL ASYNC	The extended format of incoming call indication is enabled and an asynchronous not transparent data call is incoming.
+CRING: REL SYNC	The extended format of incoming call indication is enabled and a synchronous not transparent data call is incoming.
+CRING: FAX	The extended format of incoming call indication is enabled and a fax call is incoming.

In order to use this feature you must enable the extended format of incoming calls

5.2.1.1. Set the Extended Incoming Call Indication

- send command **AT+CRC=<n><cr>**

where:

<n> is the operation mode selected:

0 - extended results Disabled (device reports RING only)



- 1 - extended results Enabled (device reports +CRING: <type> indication)
 - wait for **OK** response

5.2.2. Identify the Caller

The HE863 family is able to identify the caller number and give indication of it before the call is answered. The calling number is presented after each **RING** or **+CRING** indication in the format:

+CLIP: "<number>",<type>["<subaddress>",<satype>["<alpha>["<CLI validity>]]]

OK

where:

<Number> is the phone number;

<type> is the type of number:

145 - international numbering scheme

129 - national numbering scheme

<subaddress> is the subaddress of the calling party

<satype> is the type of subaddress

<alpha> is an optional string type alphanumeric representation of <number> corresponding to the entry found in phonebook;

<CLI validity> is the validity status of CLI presentation:

0 CLI valid.

1 CLI has been withheld by the originator.

2 CLI is not available due to interworking problems or limitation or originating network.

In order to use this feature you must enable the caller ID indication presentation, if feature is disabled then no **CLI** indication is given after the **RING** or **+CRING** code.

5.2.2.1. Set Caller line ID Indication Presentation

- send command **AT+CLIP=<n><cr>**

where:

<n> is the operation mode selected:

0 - Calling Line Indication Presentation Disabled

1 - Calling Line Indication Presentation Enabled



- wait for **OK** response

For example:

1- Let us assume you receive a call from the national number 1234567890 and extended incoming calls indication is disabled while CLIP is enabled, you can see:

ring indication:

RING

+CLIP: "1234567890", 129

2- Let us assume you receive a call from the international number +391234567890 and extended incoming calls indication is disabled while CLIP is enabled, you can see:

ring indication:

RING

+CLIP: "+391234567890", 145



NOTE:

This does not mean that the incoming call is an international one, it simply means that the numbering scheme used to identify the caller is international.

5.2.3. Restricting Calling Line Indication

The HE863 family is able to send the calling line indication (CLI) to the other party through the network when an outgoing call is made. This indication can be restricted (CLIR) in various ways:

- CLI sent always
- CLI never sent
- CLI temporary sent (normally not sent)
- CLI temporary not sent (normally sent)

5.2.3.1. CLIR Service Status Query

- send command **AT+CLIR?<cr>**
- wait for response in the format: **+CLIR: <n>,<m>**

OK

where:

<n> is the facility status on the Mobile

0 - CLIR facility according to CLIR service network status



- 1 - CLIR facility active (CLI not sent)
 - 2 - CLIR facility not active (CLI sent)
- <m> is the facility status on the Network
- 0 - CLIR service not provisioned (service unavailable)
 - 1 - CLIR service provisioned (service available)
 - 2 - unknown (e.g. no network present, etc.)
 - 3 - CLI temporary mode presentation restricted
 - 4 - CLI temporary mode presentation allowed



NOTE:

The <m> parameter reports the status of the service at network level.
If the CLIR service is not provisioned, then it is not possible to use this service and changing the first parameter <n> will not change the CLI presentation to the other party behavior of the network.

For example:

1- Let us assume you want to check your CLIR settings:

command

AT+CLIR? <cr>

response

+CLIR: 2,4

In this case the CLIR service is temporary mode allowed on the network and the mobile sends the CLI when calling. (CLI Restriction not active).

5.2.3.2. Restrict/Allow Caller Line ID Indication

- send command AT+CLIR=<n><cr>

where:

<n> is the operation mode selected:

- 0 - Calling Line Indication to the other party According to Network service status.
- 1 - Calling Line Indication Restriction Enabled (CLI not sent)
- 2 - Calling Line Indication Restriction Disabled (CLI sent)

- wait for **OK** response

For example:



1- Let us assume you want to disable the CLI presentation to the other party permanently:

command

AT+CLIR=1<cr>

response:

OK

5.2.4. Call Barring Control

Call barring is a GSM/WCDMA service that allows the user to block certain types of calls:

- barring all outgoing calls
- barring outgoing International calls
- barring outgoing International calls except to home country
- barring all incoming calls
- barring incoming calls when roaming outside the home country
- all barring services (applicable only for disabling command)
- all outgoing barring services (applicable only for disabling command)
- all incoming barring services (applicable only for disabling command)

The service can be queried, enabled and disabled.



NOTE:

The call barring service is handled by the network, hence all the relative commands issue a network request and it may take several seconds to get response from the network.

Furthermore, all call barring service commands must be issued when the mobile is registered on some Network, otherwise an error code is returned (no network service).

5.2.4.1. Call Barring Service Status Query

- send command **AT+CLCK=<fac>,2<cr>**

where:

<fac> is the facility to be queried:

"A0" - Barring All Outgoing Calls

"OI" - Barring Outgoing International Calls



- “OX” - Barring Outgoing International Calls except to Home Country
- “AI” - Barring All Incoming Calls
- “IR” - Barring Incoming Calls when Roaming outside the home country
- “AB” - All barring services (applicable only for disabling command)
- “AG” - All outgoing barring services (applicable only for disabling command)
- “AC” - All Incoming barring services (applicable only for disabling command)
 - wait for response:

Response	Reason	Action
+CLCK: 0	facility is disabled	calls are allowed
+CLCK: 1	facility is enabled	calls are barred
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax and service code
+CME ERROR: 30	no network service	Check for registration (see par. 4.4.3.1) and signal strength.



NOTE:

The call barring service is handled by the network, hence all the relative commands issue a network request and it may take several seconds to have the response from the network.

Furthermore all the Barring service commands must be issued when the mobile is registered on some network, else an error code is returned (no network service).

For example:

1- Let us assume you want to check whether the incoming calls when roaming outside Home Country are barred or not:

command

AT+CLCK="IR",2<cr>

response

+CLCK: 0

In this case, the incoming (received) calls ARE NOT BARRED when in Roaming outside the Home Country.

2- Let us assume you want to check whether the Outgoing (originated) international calls are barred or not:

command

AT+CLCK="OI",2<cr>



response:

+CLCK: 1

In this case, the outgoing international calls ARE BARRED.

5.2.4.2. **Barring/Unbarring All Incoming Calls**

- send command **AT+CLCK="AI",<en>,<pwd><cr>**

where:

<en> is the operation selected:

0 - Call Barring Disable (Unbarring)

1 - Call Barring Enable (Barring)

<pwd> is the network password required to change facility status

- wait for response:
-

Response	Reason	Action
OK	Barring is now enabled/disabled	all incoming calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.4.4.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 4.4.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let us assume you want to bar all the incoming calls and the network password of your operator is 0000:

command

AT+CLCK="AI",1,"0000"<cr>

response

OK



5.2.4.3. Barring/Unbarring Incoming Calls When in International Roaming

- send command `AT+CLCK="IR",<en>,<pwd><cr>`

where:

<en> is the operation selected:

0 - Call Barring Disable (Unbarring)

1 - Call Barring Enable (Barring)

<pwd> is the network password required to change facility status

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all incoming calls when is international Roaming will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.4.4.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 4.4.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let us assume you want to bar all the incoming calls when the mobile is roaming outside its home country and the network password of your operator is 0000:

command

`AT+CLCK="IR",1,"0000"<cr>`

response

OK

5.2.4.4. Barring/Unbarring All Outgoing Calls

- send command `AT+CLCK="AO",<en>,<pwd><cr>`

where:

<en> is the operation selected:

0 - Call Barring Disable (Unbarring)



1 - Call Barring Enable (Barring)

<pwd> is the network password required to change facility status

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all outgoing calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.4.4.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 4.4.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let us assume you want to bar all the outgoing calls (originated by mobile) and the network password of your operator is 0000:

command

AT+CLCK="AO",1,"0000" <cr>

response

OK

5.2.4.5. Barring/Unbarring All Outgoing International Calls

- send command **AT+CLCK="OI",<en>,<pwd><cr>**

where:

<en> is the operation selected:

0 - Call Barring Disable (Unbarring)

1 - Call Barring Enable (Barring)

<pwd> is the network password required to change facility status

- wait for response:



HE863 Family Software User Guide

1vv0300893 Rev.1 – 02-25-2011

		codes report (see par. 4.4.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 4.4.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let us assume you want to bar all the outgoing international calls except the ones towards the Home Country and the network password of your operator is 1234:



command

AT+CLCK="OX",1,"1234" <cr>

response:

OK

5.2.4.7. Unbarring all the Calls

- send command **AT+CLCK="AB",0,<pwd><cr>**

where:

<pwd> is the network password required to change facility status

- wait for response:

Response	Reason	Action
OK	Barring is now disabled	all calls will be allowed (unbarred)
ERROR	some error occurred	Enable the extended error codes report (see par. 4.4.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 4.4.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let us assume you want to disable all the barring services you might have previously activated and the network password of your operator is 0000:

command

AT+CLCK="AB",0,"0000" <cr>

response:

OK



condition and will not respond to commands until the DTR is tied low (Data Terminal is ready) or the VBUS is tied high.

5.4.1.1. Enabling/Disabling the Power Saving Function

- send command `AT+CFUN=<fun><cr>`

where:

`<fun>` is the power saving function mode, the supported values are:

0 - minimum functionality, NON-CYCLIC SLEEP mode: in this mode, the AT interface is not accessible.

1 - mobile full functionality with power saving disabled (factory default)

4 - disable both TX and RX

5 - mobile full functionality with power saving enabled

- wait for response:

Response	Reason	Action
OK	The power save is now active	
ERROR	some error occurred	Enable extended result codes (see par. 4.4.2.1), and retry.
+CME ERROR: 4	operation not supported	Check command syntax and <code><fun></code> value.

5.5. Power Saving Mode

Power Saving Mode means that Device is in sleep mode with disabling the interface (UART).

HE863 family makes it possible for DTE to receive the event such as incoming call/SMS/other URC events while both DTE and Modem are in sleep mode with disabling all serial interfaces.

DTE must require below specification to achieve the reduction of power consumption.

- DSR/DTR/RTS/CTS/RI Pin control on Main UART port.

If DTE satisfies the requirement, DTE can control the power saving functionality by the rule described, below:

- Use DTR on Main UART to place Modem in sleep mode or wake up Modem from sleep mode. (not available in 11.00.xx0, planned)



HE863 Family Software User Guide

1vv0300893 Rev.1 – 02-25-2011

- Use RI on Main UART to wake up DTE from sleep mode. (DTE must always monitor RI pin during power saving mode). (not available in 11.00.xx0, planned)
- Use RTS on Main UART to control the flow from Modem to DTE. (Hardware flow control must be used in power saving mode).



5.5.1.

URC Message in Power Saving




Figure 4.1 the flow chart for URC message in power saving mode



Above Figure 4.1 illustrates the action flow to get URC messages invoked while both DTE and modem in sleep mode. HE863 Family offers below serial ports, which have their own the limitation for flow control methods.

Table 4.1 the flow control capability for each serial interface

Flow Control Method	Hardware Flow	Software Flow
Main UART	Support	No Support
USB0	No Support	Support
USB3	No Support	Support

HE863 family keeps the URC messages listed in Table 4.1 and enabled by AT command in power saving mode.

Table 4.2 URC message List

URC Message	Enable/Disable AT Command
RING	Not Support , Always enabled
NO CARRIER	Not Support , Always enabled
CONNECT	Not Support , Always enabled
+CREG	+CREG
+CGREG	+CGREG
+CMTI,+CMT,+CBM,+CDS,+CDSI	+CNMI
+CCWA	+CCWA
#TEMPMEAS	#TEMPMON
#MWI	#MWI
#GSMAS	#GSMAD
+SRING	Not Support , Always enabled
+CRING	+CRC
+CLIP	+CLIP
+CUSD	+CUSD
+CCM	+CAOC
+CSSI,+CSSU	+CSSN
+CALA	+CALA

HE863 family keeps the URC messages are listed in Table 4.2 and enabled by AT command in power saving mode.

5.6. SMS Handling

The Telit HE863 family supports the Short Message Service, it is possible to store, delete, write, send and receive a SMS, which is a short text message up to 160 characters long.



5.6.1. SMS Device setup

Before accessing the Short Message Service, the device has to be properly set up.

5.6.1.1. Select SMS Format Type

The HE863 family supports SMS in two different formats:

- PDU
- Text

The difference is that in the PDU mode the device returns and receives SMS encoded in the format ready to be sent to the network; in TEXT mode the device converts automatically the read PDU into text and vice versa. By using TEXT mode, the PDU data encoding knowledge is not needed and operations are easier. For this reason, we are using the TEXT mode to explain how to operate with SMS. If you are familiar with PDU encoding then you can operate with PDU by selecting that format and using appropriate command syntax.

- Send command **AT+CMGF=<mode><cr>**

where:

<mode> is the SMS format type:

- 0 - PDU
- 1 - Text

- wait for response **OK**



TIP:

This setting is stored and remains until the device is turned off. Hence, there is no need to issue it more than one time. For TEXT mode use **<mode>=1**.

For example:

1- Let us assume you want to set TEXT format for the SMS:

command

AT+CMGF=1<cr>

response:

OK

5.6.1.2. Check SMS Service Centre Number

The SMS are sent by the HE863 family to a service centre (SMSC) where the message is dispatched towards its final destination or is kept until the delivery is possible. To



ensure a correct behavior of this service the number of the service centre must be the one your network operator supports.

To check which number is stored as the SMSC:

- send command **AT+CSCA?<cr>**
- wait for response in the format: **+CSCA: <number>,<type>**
OK

where:

<number> is the SMSC number

<type> is the SMSC number type:

145 - international numbering scheme (number begins with "+")

129 - national numbering scheme



TIP:

This settings remains stored in the SIM card until it is changed or deleted, so this operation may be done only once if the SIM Card is not changed. The setting is maintained even after power down.

For example:

1- Let us assume you want to check your SMSC number:

command

AT+CSCA? <cr>

response:

+CSCA: "+393359609600",145

OK

5.6.1.3. **Add SMS Service Centre Number (only if required)**

If your previously check for SMSC returned an empty field:

+CSCA: ,129

Or if the SMSC number stored does not correspond to the desired one, then the new number has to be stored. In this way, the previously stored number will be overwritten.



- send command **AT+CSCA=<number>,<type><cr>**

where:

<number> is the desired SMSC number

<type> is the SMSC number type:

145 - international numbering scheme (number begins with "+")

129 - national numbering scheme

- wait for **OK**

For example:

1- Let us assume your desired SMSC number is +39335123456 (stored in international format):

command

AT+CSCA="+39335123456",145<cr>

response:

OK

5.6.1.4. Select New Messages Indication Behavior

When the device receives a new message a unsolicited indication is generated, this indication may be sent to the DTE, buffered if the DTE is busy (for example during a data call) or discarded.

To set the desired behavior:

- send command **AT+CNMI=<mode>,<mt>,<bm>,<ds>,<bfr><cr>**

where:

Set command selects the behaviour of the device on how the receiving of new messages from the network is indicated to the DTE.

Parameter:

<mode> - unsolicited result codes buffering option

0 - Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications.

1 - Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved, otherwise forward them directly to the TE.

2 - Buffer unsolicited result codes in the TA in case the DTE is busy and flush them to the TE after reservation. Otherwise forward them directly to the TE.



3 - if **<mt>** is set to 1 an indication via 100 ms break is issued when a SMS is received while the module is in GPRS online mode. It enables the hardware ring line for 1 s. too.

<mt> - result code indication reporting for SMS-DELIVER

0 - No SMS-DELIVER indications are routed to the TE.

1 - If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using the following unsolicited result code:

+CMTI: <memr>,<index>

where:

<memr> - memory storage where the new message is stored

"SM"

"ME"

<index> - location on the memory where SM is stored.

2 - SMS-DELIVERs (except class 2 messages and messages in the message waiting indication group) are routed directly to the TE using the following unsolicited result code:

(PDU Mode)

+CMT: <alpha>,<length><CR><LF><pdu>

where:

<alpha> - alphanumeric representation of originator/destination number corresponding to the entry found in MT phonebook

<length> - PDU length

<pdu> - PDU message

(TEXT Mode)

+CMT:<oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data> (the information written in italics will be present depending on +CSDH last setting)

where:

<oa> - originating address, string type converted in the currently selected character set (see +CSCS)

<alpha> - alphanumeric representation of <oa>; used character set must be the one selected with either command +CSCS.

<scts> - arrival time of the message to the SC



<toa>, **<tosca>** - type of number **<oa>** or **<sca>**:

129 - number in national format

145 - number in international format (**contains the "+"**)

<fo> - first octet of 3gpp 03.40/23.040

<pid> - Protocol Identifier

<dcs> - Data Coding Scheme

<sca> - Service Centre address, string type, converted in the currently selected character set (see +CSCS)

<length> - text length

<data> - TP-User-Data

Class 2 messages and messages in the message waiting indication group (stored message) result in indication as defined in **<mt>=1**.

3 - Class 3 SMS-DELIVERs are routed directly to **TE** using unsolicited result codes defined in **<mt>=2**. Messages of other data coding schemes result in indication as defined in **<mt>=1**.

<bm> - broadcast reporting option

0 - Cell Broadcast Messages are not sent to the **DTE**

1 - if a Cell Broadcast Messages is stored, then the following unsolicited result code is sent:

+CBMI: <memr>,<index>

where:

<memr> - memory storage where the new message is stored

"BM"

<index> - location on the memory where BM is stored

2 - New Cell Broadcast Messages are sent to the **DTE** with the unsolicited result code:

(PDU Mode)

+CBM: <length><CR><LF><PDU>

where:

<length> - PDU length

<PDU> - message PDU



where:

<memr> - memory storage where the new message is stored

"SR"

<index> - location on the memory where SR is stored

<bfr> - buffered result codes handling method:

0 - **TA** buffer of unsolicited result codes defined within this command is flushed to the **TE** when **<mode>=1..3** is entered (**OK** response must be given before flushing the codes)

1 - **TA** buffer of unsolicited result codes defined within this command is cleared when **<mode>=1..3** is entered.

NOTE: Issuing **AT+CNMI<CR>** is the same as issuing the Read command.

NOTE: Issuing **AT+CNMI=<CR>** is the same as issuing the command **AT+CNMI=0<CR>**.

- wait for **OK**



TIP:

In this command description the values that are always 0 are parameter reserved for future use, in the current software revision the only value supported is 0.

For example:

1- Let us assume you want to eliminate all the unsolicited codes that may be sent when receiving SMS & Status Report:

command

AT+CNMI= 0,0,0,0,0<cr>

response:

OK

For example about a new message indication:

1- Let us assume you receive a new SMS delivery (**AT+CNMI=1,1,0,0,0**) and this new message is stored on the SIM "SM" storage at the location number 7; the unsolicited code you will receive (if code is enabled) is:

unsolicited code:



+CMTI: "SM",7

2- Let us assume you receive a new SMS Status Report delivery (AT+CNMI=1,0,0,2,0) and this new message is stored on the SIM "SR" storage at the location number 8; the unsolicited code you will receive is:

unsolicited code:

+CDSI: "SR",8

5.6.1.5. Set Text Mode Parameters (only in TEXT mode)

When the device is set to operate with Text SMS not with PDU, the SMS parameters that usually reside on the header of the PDU must be set apart with the command +CSMP.

The parameters to be set are:

- Message Format
- Validity Period
- Protocol Identifier
- Data Coding Scheme

The meaning and format of the parameters is:

Message format, like defined for the first octet of message according to GSM 3.40/23.040:

The format is an 8-bit parameter divided into 6 fields and then reported as an integer:

b7	b6	b5	b4	b3	b2	b1	b0
RP	UDHI	SRR	VPF		RD	MTI	

where

MTI message type parameter:

- 0 1 - SMS Submit
- 0 1 - SMS DELIVER

RD reject duplicates parameter

- 0 – do not reject duplicates SMS in SC
- 1 - reject duplicates on SC

VPF validity period format

- 0 0 - Validity period NOT present
- 1 0 - VP integer represented (relative)
- 1 1 - VP semi octet represented (absolute)



0 1 - reserved

SRR status report request

0 - status report not requested

1 - status report requested

UDHI user data Header Information

0 - No Header on PDU

1 - Header present on PDU

RP reply path

0 - RP not set

1 - RP set

Validity Period numerical if in relative format or string if in absolute format

This parameter represents the validity period for the SMS after which the message must be disregarded instead of being delivered.

If in relative format (see VPF parameter) it is an integer:

0 to 143 - corresponding to $(VP + 1) \times 5$ minutes

144 to 167 - corresponding to 12 hours + $((VP - 143) \times 30)$ minutes)

168 to 196 - corresponding to $(VP - 166) \times 1$ day

197 to 255 - corresponding to $(VP - 192) \times 1$ week

If in absolute format it is a string in the format:

"gg/MM/YY,hh:mm:ss±tz"

where

gg day of expiration (2 characters)

MM month of expiration (2 characters)

YY year of expiration (2 characters)

hh hour of expiration (2 characters)

mm minute of expiration (2 characters)

ss second of expiration (2 characters)

± sign of the time zone (+ or -)

tz time zone (2 characters)



67	Replace Short Message Type 3
68	Replace Short Message Type 4
69	Replace Short Message Type 5
70	Replace Short Message Type 6
71	Replace Short Message Type 7
72..94	Reserved
95	Return Call Message
96..126	Reserved
127	SIM Data download

Data coding Scheme as defined by GSM 3.38 - in numerical format The DCS is an 8-bit parameter reported as an integer, the default value is 0, otherwise for simplicity, we report only the most useful DCS, for further Schemes refer to GSM 3.38

B7	B6	b5	b4	b3	b2	b1	b0
1	1	1	1	0	Alphabet	Class	

where

Alphabet

0 - default Alphabet

1 - 8 bit

Class

0 0 - Class 0

0 1 - Class 1

1 0 - Class 2

1 1 - Class 3



TIP:

The default value for DCS = 0 represents the default SMS sent by a mobile. If you do not need any particular data coding scheme use DCS=0.

NOTE:

Not all the DCS combinations described in the 3gpp 3.38/23.038 are supported, both by the network and by the Telit HE863. Some features may be not implemented at network level or at device level, resulting in a +CMS ERROR: 303 (operation not supported) result code. If this happens then use a different DCS.

- send command **AT+CSMP=<fo>,<vp>,<pid>,<dc><cr>**

where:



- "ME"
- "SR"
- "BM"

<memw>: memory storage for Write and Send commands

<mems>: memory storage for new incoming message saving

- wait for response in the format:

+CPMS:<usedr>,<totalr>,<usedw>,<totalw>,<useds>,<totals>

OK

where

<usedr> - number of SMS stored into <memr>

<totalr> - max number of SMS that <memr> can contain

<usedw> - number of SMS stored into <memw>

<totalw> - max number of SMS that <memw> can contain

<useds> - number of SMS stored into <mems>

<totals> - max number of SMS that <mems> can contain

From this response you can check if the selected storage has room for new SMSs, the free positions in the storage X (where X can be r,w,s) are <totalX> -<usedX>.



NOTE:

"ME", "BM", "SR" storages are the volatile memory as RAM; So messages will be disappeared in storages after reboot.



5.6.2. IRA Character Set

The character set used in SMS text mode is the IRA. This set defines each char as a 7-bit value, hence from 0x00 to 0x7F. The table below reports all the chars supported and their hexadecimal code. To obtain the code for a char in the table remember that in the row it is reported the least significant nibble (4 bits) and in the column the most significant nibble. The empty cells correspond to reserved combinations.

		Most Significant Nibble							
		0x	1x	2x	3x	4x	5x	6x	7x
Least Significant Nibble	x0			SP ¹	0	@	P		p
	x1			!	1	A	Q	a	q
	x2			"	2	B	R	b	r
	x3			#	3	C	S	c	s
	x4			\$	4	D	T	d	t
	x5			%	5	E	U	e	u
	x6			&	6	F	V	f	v
	x7			'	7	G	W	g	w
	x8			{	8	H	X	h	x
	x9			}	9	I	Y	i	y
	xA	LF ²		*	:	J	Z	j	z
	xB			+	;	K		k	
	xC			,	<	L		l	
	xD	CR ³		-	=	M		m	
	xE			.	>	N		n	
	xF			/	?	O	£	o	

¹ - SP stands for space character

² - LF stands for Line Feed character

³ - CR stands for Carriage Return character

For example:

1- Let us assume you want to find the IRA code for the character '&':

From the table you find:

- most significant Nibble: 2
- least significant Nibble: 6

Hence the IRA code for the '&' character is the hexadecimal 0x26.

2- Let us assume you have the IRA code 0x6B and you want to find the corresponding character:



From the table you find at the position

- most significant Nibble: 6
- least significant Nibble: B

Hence, the character corresponding to the 0x6B IRA code is 'k'.



TIP:

With the command AT+CSCS is possible to select the character set; the available types are:

“IRA” - ITU-T.50

“GSM” - GSM 7 bit default alphabet (3GPP TS 23.038 [25]); this setting causes easily software flow control (XON/XOFF) problems.

“HEX” - Character strings consist only of hexadecimal numbers from 00 to FF; e.g. “032FE6” equals three 8-bit characters with decimal values 3, 47 and 230; no conversions to the original MT character set shall be done.

”UCS2” - 16-bit universal multiple-octet coded character set (ISO/IEC10646)

Please refer to the AT command specification for the full command description.

5.6.3. Writing a New SMS to Storage

A new SMS can be written in the selected storage <memw> (in the current SW version only "SM" is supported) and then can be sent to the desired destination.

To write the new SMS:

- send command **AT+CMGW="<da>"<cr>**

where:

<da>: destination address

- wait for prompt ">"
- send SMS text (MAX 160 characters)
- end command with CTRL-Z character (0x1A hexadecimal) or abort command with ESC character (0x1B hexadecimal)
- wait for response:

Response	Reason	Action
+CMGW: <index>	Message has been successfully written in position number <index>	proceed ahead
OK		
ERROR	some error occurred	Enable the extended error codes report (see par. 4.4.2.1)



+CMS ERROR: 330	SMSC address unknown	and retry. Insert SMSC address (see par. 5.6.1.3)
+CMS ERROR: 322	Memory Full	memory is full, hence delete some records and retry.



NOTE:

if command is aborted with ESC character, then only the OK result code is returned.

For example:

1- Let us assume you want to write a new SMS to the storage and the destination address is the number +39338123456789. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command

AT+CMGW="+39338123456789"

response:

>

now you can insert the message text in IRA format (note that the IRA format and ASCII format coincide for the alphabet characters but not for the other).

...here will be inserted the SMS message text...

conclude text with the character CTRL-Z

response:

+CMGW: 3

OK

In this case, the new SMS was successfully written to the location index 3 of the selected write memory.



5.6.4. Sending an SMS Previously Stored

An already written SMS can be sent from the selected storage **<memw>**.

To send the written SMS its location index is needed:

- send command **AT+CMSS=<index><cr>**

where:

<index>: SMS location index

- wait for response:

Response	Reason	Action
+CMSS: <mr> OK	Message has been successfully sent. <mr> represents the message reference number.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par. 4.4.2.1) and retry.
+CMS ERROR: 330	SMSC address unknown	Insert SMSC address (see par. 5.6.1.3)
+CMS ERROR: 41	"Temporary Failure", may be that the device is not registered on any network	Check for signal strength and network registration
+CMS ERROR: 331	No network service	Check for signal strength and network registration
+CMS ERROR: 1	Unassigned number	The destination address number does not exist. Check it and repeat command.
+CMS ERROR: 42	network congestion	Retry later
+CMS ERROR: 96	Mandatory information missing	Check for destination address in the SMS, overwrite it and retry.

For example:

1- Let us assume you want to send a SMS that was written to the storage index position number 3. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command

AT+CMSS=3



response:

+CMSS: 1

OK

In this case, the SMS was successfully sent to the destination and its network message reference number is 1.

5.6.5. Sending a New SMS Without Storing It

A new SMS can be sent directly to the network without storing it.

- send command **AT+CMGS=" <da> " <cr>**

where:

<da>: destination address

- wait for prompt ">"
- send SMS text (MAX 160 characters)
- end command with CTRL-Z character (0x1A hexadecimal) or abort command with ESC character (0x1B hexadecimal)
- wait for response:

Response	Reason	Action
+CMGS: <mr> OK	Message has been successfully sent. <mr> represents the message reference number.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par. 4.4.2.1) and retry.
+CMS ERROR: 330	SMSC address unknown	Insert SMSC address (see par. 5.6.1.3)
+CMS ERROR: 41	"Temporary Failure", may be that the device is not registered on any network	Check for signal strength and network registration
+CMS ERROR: 331	No network service	Check for signal strength and network registration
+CMS ERROR: 1	Unassigned number	The destination address number does not exist. Check it and repeat command.



+CMS ERROR: 42	network congestion	Retry later
+CMS ERROR: 96	Mandatory information missing	Check for destination address in the SMS, overwrite it and retry.
OK	command aborted by user	you issued a ESC char

For example:

1- Let us assume you want to directly send a new SMS to the destination address number +39338123456789. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command

AT+CMGS="+39338123456789",145

response:

>

now you can insert the message text in IRA format (note that the IRA format and ASCII format coincide for the alphabet characters but not for the other).

...here will be inserted the SMS message text to be sent...

conclude text with the character CTRL-Z

response:

+CMGS: 4

OK

In this case, the new SMS was successfully sent to the SC and its network reference number is 4.

Do not confuse message reference with message index position, the first indicates the network reference for identifying the sent message (the eventually requested status report will have the same reference) while the second indicates the position where the message has eventually been stored in the memory.

5.6.6. Deleting an SMS

An already written/received SMS can be deleted from the selected storage.

To delete the SMS its location index is needed:

- send command **AT+CMGD=<index>[,<delflag>]<cr>**

where:

<index>: SMS location index, if <delflag> = 0



Test command shows the valid memory locations and optionally the supported values of **<delflag>**.

<delflag>: an integer indicating multiple message deletion request as follows:

0 (or omitted) Delete the message specified in **<index>**

1 Delete all read messages from preferred message storage, leaving unread messages and stored mobile originated messages (whether sent or not) untouched

2 Delete all read messages from preferred message storage and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched

3 Delete all read messages from preferred message storage, sent and unsent mobile originated messages leaving unread messages untouched.

4 Delete all messages from preferred message storage including unread messages.

- wait for response:

Response	Reason	Action
OK	Message has been successfully deleted.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par. 4.4.2.1) and retry.
+CMS ERROR: 321	Invalid memory index e.g. the given record was already empty	Check the <index> number and retry.

For example:

1- Let us assume you want to delete a previously written SMS that was written to the storage index position number 3. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command

AT+CMGD=3

response:

OK

In this case, the SMS was successfully deleted.

2- Let us assume you want to delete a received SMS that was stored to the index position number 7:

command



AT+CMGD=7

response:

OK

5.6.7. Reading an SMS

A new SMS can be read with the command

- send command **AT+CMGR=<index><cr>**

where:

<index>: SMS location index

- wait for response in the format:

Output format for received messages (the information written in italics will be present depending on **+CSDH** last setting):

+CMGR: <stat>,<oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>

Output format for sent messages:

+CMGR: <stat>,<da>,<alpha>[,<toda>,<fo>,<pid>,<dcs>,,<sca>,<tosca>,<length>]<CR><LF><data>

Output format for message delivery confirm:

+CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st>

where:

<stat> - status of the message

"REC UNREAD" - new received message unread

"REC READ" - received message read

"STO UNSENT" - message stored not yet sent

"STO SENT" - message stored already sent

<fo> - first octet of the message PDU

<mr> - message reference number

<scts> - arrival time of the message to the SC

<dt> - sending time of the message

<st> - message status as coded in the PDU

<pid> - Protocol Identifier



<dc> - Data Coding Scheme

<oa> - Originator address, string type represented in the currently selected character set (see +CSCS)

<da> - Destination address, string type represented in the currently selected character set (see +CSCS)

<alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS. *NB: this optional field is currently not supported.*

<sca> - Service Centre number

<tooa>, <toda >, <tosca> - type of number <oa>, <da>, <sca>

129 - number in national format

145 - number in international format (contains the "+")

<length> - text length

<data> - TP-User_data

If <dc> indicates that GSM03.38 default alphabet is used , each character of GSM alphabet will be converted into current TE character set (see +CSCS)

If <dc> indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41)

Note: in both cases if status of the message is 'received unread', status in the storage changes to 'received read'. An error result code is sent on empty record <index>.

For example:

1- Let us assume you want to read the SMS that is stored at the position index 4. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command

AT+CMGR=4

response:

+CMGR: "STO UNSENT", "+393351234565"

Telit Test Message for Text Mode SMS.

OK

In this case the SMS was successfully read, the text contained was:

"Telit Test Message for Text Mode SMS."



The message was written to the storage by user (STO) but still not sent (UNSENT) to the destination address with the number +393351234565

2- Let us assume you want now to read the SMS that is stored at the position index 5:
command

AT+CMGR=5

response:

+CMGR: "REC UNREAD", "+393381234567890", "29/06/01,12:30:04+01"

Telit Test Message for Text Mode SMS RECEIVING.

OK

In this case the SMS was successfully read, the text contained was:

"Telit Test Message for Text Mode SMS RECEIVING."

The message was received (REC) from the number +393381234567890 at 12:30:04 the day 29/06/01 in the European time zone +1. After this read command the message at index 5 becomes REC READ.

5.6.8. Listing a Group of SMSs

The SMS can be grouped into 5 different groups depending on their status:

- REC UNREAD received messages still not read
- REC READ received messages already read
- STO UNSENT written messages not yet sent
- STO SENT written messages already sent
- ALL all types of messages

It is possible to have the list of all the messages in one group:

- send command **AT+CMGL=<stat><cr>**

where:

<stat> - status group of the message

"REC UNREAD" - new message

"REC READ" - read message

"STO UNSENT" - stored message not yet sent

"STO SENT" - stored message already sent

"ALL" - all messages

- wait for response in the format:



For every message in the group:

**+CMGL: <index>,<stat>,<oa/da> [,,,<tooa/toda>,<length>]
<CR><LF><text>**

where:

<index> - message index position on the storage

<stat> - status of the message

"REC UNREAD" - new message

"REC READ" - read message

"STO UNSENT" - stored message not yet sent

"STO SENT" - stored message already sent

<oa/da> - sender number/destination number

<tooa/toda> - type of number <oa/da>

145 - international number (contains "+" character)

129 - national number

<length> - length of the message text in characters

<text> - message text

Note: If status of the message is 'received unread', status in the storage changes to 'received read'.

For example:

1- Let us assume you want to list all the SMS received read that are stored. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command

AT+CMGL="REC READ"

response:

+CMGL: 5, "REC READ", "+393381234567890"

Telit Test Message for Text Mode SMS RECEIVING.

+CMGL: 8, "REC READ", "+393381234567890"

Telit Second Test Message for Text Mode SMS RECEIVING.

OK



In this case the SMS group was successfully read, the messages Received UNREAD were two in the position indexes 5 & 8. The optional parameters **<tooa/toda>** and **<length>** were not shown.

5.7. Using General Purpose Input/Output pins

The Telit HE863 family provides various General Purpose Input/Output pins, these pins can be configured via AT commands as Inputs, Outputs and two of them as "alternate function".

The "alternate function" are supported by pins GPIO5, which can be configured to become a RF Transmission monitor output pin that reflects the RF transmission activation, GPIO6, which can be configured to become an alarm output pin that reflects the alarm status, and GPIO7 which can be configured to become a buzzer output pin.

With these pins your application can control external hardware directly using the Telit HE863 family pins, with little or even no hardware added.

5.7.1. GPIO pin setup

Before using the GPIO pin, you must configure them to select their direction or alternate function

5.7.1.1. Setting GPIO pin as OUTPUT

When you set a GPIO as output, you must specify also the value that the pin output must take:

- send command **AT#GPIO=<pin>,<value>,1<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 - GPIO1	12 - GPIO12
2 - GPIO2	13 - GPIO13
3 - GPIO3	14 - GPIO14
4 - GPIO4	15 - GPIO15
5 - GPIO5	16 - GPIO16
6 - GPIO6	17 - GPIO17
7 - GPIO7	18 - GPIO18
8 - GPIO8	19 - GPIO19
9 - GPIO9	20 - GPIO20



- | | |
|-------------|-------------|
| 10 - GPIO10 | 21 - GPIO21 |
| 11 - GPIO11 | 22 - GPIO22 |

<value> is the GPIO pin value that the pin will assume:

- 0 - LOW
- 1 - HIGH

- wait for response **OK**



NOTE:

The **#GPIO** setting is not saved and will be lost on power off, so at start-up repeat pin initialization commands. At start-up the setting for GPIO6 and GPIO7 instead is maintained even after a shutdown to permit alarm feature to work always.

For example:

1- Let us assume you want to set GPIO3 pin as Output and you want it to be in LOW status:

command

AT#GPIO=3,0,1<cr>

response:

OK

In this case, the GPIO3 pin was successfully put in output direction and its status has been set to LOW.

5.7.1.2. Setting GPIO pin as INPUT

When you set a GPIO as input, you must specify also a dummy value for the pin state:

- send command **AT#GPIO=<pin>,<dummy_value>,0<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

- | | |
|-----------|-------------|
| 1 - GPIO1 | 12 - GPIO12 |
| 2 - GPIO2 | 13 - GPIO13 |
| 3 - GPIO3 | 14 - GPIO14 |
| 4 - GPIO4 | 15 - GPIO15 |
| 5 - GPIO5 | 16 - GPIO16 |
| 6 - GPIO6 | 17 - GPIO17 |



- | | |
|-------------|-------------|
| 7 - GPIO7 | 18 - GPIO18 |
| 8 - GPIO8 | 19 - GPIO19 |
| 9 - GPIO9 | 20 - GPIO20 |
| 10 - GPIO10 | 21 - GPIO21 |
| 11 - GPIO11 | 22 - GPIO22 |

<value> is a dummy value can be either:

- 0 - dummy value
- 1 - dummy value

- wait for response **OK**



NOTE:

The **#GPIO** setting for all GPIO except from GPIO6, is not saved and will be lost on power off, so at start-up repeat pin initialization commands.

At start-up all the GPIOs except from GPIO6 are configured by default as INPUT, but the setting for GPIO6 instead is maintained even after a shutdown to permit alarm feature to work always.

For example:

1- Let us assume you want to set GPIO4 pin as Input:

command

AT#GPIO=4,0,0<cr>

response:

OK

In this case, the GPIO4 pin was successfully put in input direction.



5.7.2. GPIO pin use

After having set-up the GPIO pin direction you can query the input status of an INPUT pin or set the output status of an OUTPUT pin.

5.7.2.1. Querying GPIO pin status

To query for the pin status:

- send command **AT#GPIO=<pin>,2<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 - GPIO1	12 - GPIO12
2 - GPIO2	13 - GPIO13
3 - GPIO3	14 - GPIO14
4 - GPIO4	15 - GPIO15
5 - GPIO5	16 - GPIO16
6 - GPIO6	17 - GPIO17
7 - GPIO7	18 - GPIO18
8 - GPIO8	19 - GPIO19
9 - GPIO9	20 - GPIO20
10 - GPIO10	21 - GPIO21
11 - GPIO11	22 - GPIO22

- wait for response in the format:

#GPIO: <dir>,<stat>

OK

where:

<dir> - GPIO<pin> direction setting

<stat> - status of the pin

0 - LOW

1 - HIGH



response:

#GPIO: 2,0

OK

In this case, the GPIO6 pin was set in "alternate function" direction and therefore works as alarm output. The reported status = LOW has no meaning.

5.7.2.2. Setting GPIO Pin Output Status

To set the pin status (when pin is set as OUTPUT):

- send command **AT#GPIO=<pin>,<value>,1<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 - GPIO1	12 - GPIO12
2 - GPIO2	13 - GPIO13
3 - GPIO3	14 - GPIO14
4 - GPIO4	15 - GPIO15
5 - GPIO5	16 - GPIO16
6 - GPIO6	17 - GPIO17
7 - GPIO7	18 - GPIO18
8 - GPIO8	19 - GPIO19
9 - GPIO9	20 - GPIO20
10 - GPIO10	21 - GPIO21
11 - GPIO11	22 - GPIO22

<value> is the pin value to be set and can be:

0 - LOW

1 - HIGH

- wait for response **OK**

For example:

1- Let us assume you want to set the GPIO3 pin HIGH:

command

AT#GPIO=3,1,1<cr>

response:



6 - the MODULE will make both the actions as for **<type>=2** and **<type>=4**.

7 - the MODULE will make both the actions as for **<type>=3** and **<type>=4**.

8 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE sets **High** the **RI** output pin. The **RI** output pin remains **High** until next **#WAKE** issue or until a 90s timer expires. If the device is in "alarm mode" and it does not receive the **#WAKE** command within 90s. After that it shuts down.

<text> - unsolicited alarm code text string. It has meaning only if **<type>** is equal to 2 or 5 or 6.

- Wait for response OK



NOTE:

If you use the GPIO6 pin as ALARM OUTPUT, then you MUST set its direction to "alternate function" (see par. 3.7.2.4) otherwise the pin does not respond to the alarm settings.

In case the alarm mode is equal to 1,3,7 then a dummy empty text is inserted "".

NOTE:

If you use the unsolicited codes **+ALARM: <text>**, then you must fix the port speed rate (see par. 2.7.1) and store it in the active profile (see command &W), in order to make the Telit HE863 family boot with the desired port speed, otherwise at the alarm wakeup, the module starts with the default port speed that may differ from yours.

TIP:

Remember that the string time has to be encapsulated in double brackets, furthermore the Alarm time is computed for different time zone, therefore the alarm time always refers to the same time zone as the clock setting regardless the time zone set in the +CALA command.

5.8.2.2. Stop the Alarm Activity

When the alarm time expires, the module starts the alarm activity according to the alarm behavior parameter **<type>** selected.

To stop the Alarm activity there are three ways, you can either decide to exit from alarm and shutdown the device or exit from alarm and entering the normal operational status; otherwise you can leave the alarm go on until the 90s timeout is reached.

5.8.2.2.1. Exit from the alarm status and shutdown

- send command **AT#SHDN<cr>**



- wait for response **OK**

At the OK result code, the device will end alarm activity and shutdown.

5.8.2.2.2. Exit from the alarm status and enter the normal operating mode

- send command **AT#WAKE=0<cr>**
- wait for response **OK**

At the OK result code, the device will end alarm activity and enter normal operating mode. If the device was already in normal operating mode (alarm has started when the module was already ON), then with the command only the alarm activity is terminated.

5.8.2.3. Querying the Alarm Status

When the device awakes by means of an alarm time expire, the module starts the alarm activity but not the network activity, permitting some operations to be done by the controlling application without registering the mobile in the network.

To check if the mobile is in the "alarm status" and therefore no network activity is done or if the device is in normal operating status:

- send command **AT#WAKE?<cr>**
- wait for response in the format:

+WAKE: <status>

OK

where:

<status> is the operating mode:

0 - normal operating mode

1 - alarm mode



NOTE:

If the device is in the alarm mode no network activity is done, therefore the only commands that are accepted are the #WAKE and #SHDN ones.

When in the alarm mode, no operation is allowed towards the network, therefore it is not possible to receive or send calls, SMS and whatever WCDMA/GSM/GPRS services.

5.8.2.3.1. Alarm operation example

For example:

1- Let us assume you have a battery powered device, a meteorological unit that measures every hour the conditions and therefore needs to send a new SMS every



hour to the central server, for example indicating the whether status just measured. Let say your application must consume the absolute minimum power to achieve the job, since it will be placed in a remote position where its battery must last as long as possible and therefore it must shutdown completely and wake up every hour for just the time needed to measure & send the whether, successively shutdown.

set up the time in the internal clock (only the first time)

command

AT+CCLK="02/11/07,12:24:30+01"<cr>

response

OK

set up the next alarm in order to raise the GPIO6 pin to power up the controlling application too.

command

AT+CALA="02/11/07,13:24:30+01",0,6,"TIME TO MEASURE & SMS...!"<cr>

response

OK

- shutdown the HE863 family and successively the controlling application.

command

AT#SHDN<cr>

response

OK

... after an hour..

The HE863 family will turn itself ON in "Alarm Mode" and contemporarily both rise the GPIO6 pin which turns on the power to the controlling application and issue every 3s an unsolicited code +ALARM: TIME TO MEASURE & SMS...!

turn on the keep alive line in the controlling application that keeps itself ON.

stop the alarm activity in the HE863 family (recognized by the +ALARM unsolicited code) and bring the HE863 family in operating mode

command


AT#WAKE=0<cr>

response

OK

take the whether measure






Wireless Cellular CSD interconnectivity

In PSD operations instead, the connection is made directly towards internet as if the PSD modem which support GPRS/EDGE/WCDMA/HSPA was a network IP socket interface. There is no data path reserved for the data exchange between the two peers, instead the resources are allocated dynamically on demand and the data exchanged is organized into packets typically TCP/IP, furthermore the maximum transfer speed can be much faster than GSM CSD.

An example of PSD connection is shown in the following picture, where the PSD connection is between the PSD modem and the internet as if all the devices inside the dashed line are not present:



Wireless Cellular PSD *interconnectivity*



Due to this kind of connection, when activating the PSD connection you must provide the network parameters to enter through the internet point of the GPRS/EDGE/WCDMA/HSPA network ISP (Internet Service Provider) and not the phone number to be dialed. Therefore, it is not possible to establish a direct point-to-point PSD connection between two modems as in CSD case. Instead an internet tunneling must be done to achieve a point to point connection between two peers.

This approach as the immediate advantage of projecting the controlling application of the PSD modem directly on the internet, ready to be accessed virtually from anywhere in the world at the same cost on the GPRS/EDGE/WCDMA/HSPA network. Actually the billing of the PSD connection is based on the amount of data exchanged (number of packets transferred) independently from the time the connection is active or where these packets must be delivered. Therefore, it is possible to leave the controlling application always connected and ready to receive/send data on demand, while paying only for the data really exchanged.

The drawback of the PSD connection is that the controlling application must have its own TCP/IP protocol stack embedded to decode the packets that arrive from GPRS/EDGE/WCDMA/HSPA network and encode the ones to be sent through the internet.

There are few considerations that must be done on the PSD connections:

- the GPRS connection speed with a GPRS class 33 multislots device is asymmetrical, 5 time slots in reception (80000 bps max in CS4), 3 time slots in sending (80000 bps max in CS4) and 6 time slots in active (tx time slot + rx time slot).
- the EDGE connection speed with a EDGE class 33 multislots device is asymmetrical, 5 time slots in reception (236800 bps max in MCS9), 3 time slots in sending (236800 bps max in MCS9) and 6 time slots in active (tx time slot + rx time slot).
- the UMTS connection speed is symmetrical, 384kbps in reception and sending.
- The HSPA connection speed with a category 6 device is asymmetrical, 7.2Mbps in reception and 5.76Mbps in sending.
- The controlling application of the module must have a TCP/IP - PPP software stack to interface with the PSD modems.
- The controlling application must rely on some ISP that may be the Network Operator of the SIM or USIM to gain access to the internet through the PSD connection.
- Because of the point before, the receiving application must have internet access either.
- Since the communication is based upon TCP/IP packets, then it is possible to talk contemporarily with more than one peer.



7. GPS operations (HE863-xxG only)

7.1. Introduction

The HE863-xxG module is equipped with embedded gps that is controllable by the modem using a set of AT commands or dedicated NMEA sentences.

7.2. HE863-xxG Serial Ports

4 serial ports are available on the module:

- UART SERIAL PORT
- USB CDC3

7.3. WGS 84

GPS receivers perform initial position and velocity calculations using an earth-centered earth-fixed (ECEF) coordinate system. Results may be converted to an earth model (geoid) defined by the selected datum. For HE863-xxG the default datum is WGS 84 (World Geodetic System 1984) which provides a worldwide common grid system that may be translated into local coordinate systems or map dates. (Local map dates are a best fit to the local shape of the earth and not valid worldwide).²

7.4. NMEA 0183

The NMEA 0183 is a specification created by the National Marine Electronics Association (NMEA) that defines the interface between other marine electronic equipment. The standard permits marine electronics to send information to computers and to other marine equipment. GPS receiver communication is defined within this specification. The actually supported version is 2.2

The provided NMEA sentences are:

GGA Time, position and fix type data.

GSV The number of GPS satellites in view satellite ID numbers, elevation, azimuth, and SNR values.

7.4.1. GGA - Position System Fixed Data

This sentence provides time, position, and fixes related data for a GPS Receiver. Table A contains the values for the following example:

`$GPGGA,161229.487,3723.2475,N,12158.3416,W,1,07,1.0,9.0,M, , , .0000*18`



Table A

Name	Example	Units	Description
Message ID	\$GPGGA		GGA protocol header
UTC Time	161229.487		hhmmss.sss
Latitude	3723.2475		ddmm.mmmm
N/S Indicator	N		N=north or S=south
Longitude	12158.3416		dddmm.mmmm
E/W Indicator	W		E=east or W=west
Position Fix Indicator	1		See Table B
Satellites Used	07		Range 0 to 12
HDOP	1.0		Horizontal Dilution of Precision
MSL Altitude	9.0	meters	
Units	M	meters	
Geoid Separation		meters	
Units	M	meters	
Age of Diff. Corr.		second	Null fields when DGPS is not used
Diff. Ref. Station ID	0000		
Checksum	*18		
<CR> <LF>			End of message termination

Table B

Value	Description
0	Fix not available or invalid
1	GPS SPS Mode, fix valid
2	Differential GPS, SPS Mode, fix valid
3-5	Not supported
6	Dead Reckoning Mode, fix valid

7.4.2.

GSV - GNSS Satellites in View

This sentence reports the number of satellites (SV) in view, satellite ID numbers, elevation, azimuth and SNR value. There could be four satellites information per transmission so, if the number of satellites in view is bigger, separated GSV sentences will be generated. The number of sentence in transmission and the total to be transmitted is shown in the first 2 fields of the sentence. Table G contains the values for the following example:

\$GPGSV,2,1,07,07,79,048,42,02,51,062,43,26,36,256,42,27,27,138,42*71



8. Service and Firmware Update

The **Telit Modules** firmware is updated through the Serial Interface normally used for the AT Commands.

It is suggested to provide an RS232 interface on the User Printed Circuit Board (where the **Telit Module** is soldered) to perform the physical connection between the **Telit module** and a Windows-based PC. That simple circuitry makes the firmware updating easy when a new firmware version is released.

During the User Application development or evaluation phase of the **Telit module**, the RS232 interface or the USB port implemented on the **Telit Evaluation Kit (EVK2)** [6] can be used to connect the **Telit module** to a Windows-based PC on which a dedicated tool for firmware updating is running.

Telit provides the User with two tools to update the firmware of the module. The following paragraphs describe them.



NOTE:

GT terminals are complete encased modems. They do not need the Telit Evaluation Kit (EVK2) to perform testing, evaluation and Firmware Update.

8.1. Step-by-Step Upgrade Procedure (TFI)

The firmware update can be done with a specific software tool provided by Telit that runs on Windows based PCs.

First the program will erase the content of flash memory, then the program will write on the flash memory. To update the firmware of the module, we suggest the following procedure:

- Run the file *TFI_XXXX.exe*. The following window must be displayed, Select the language preferred by pressing the correspondent button.



- The End User License Agreement will appear. Please, read it and accept the terms if you are going to proceed.



