



SL876Q5-A EVK User Guide

1VV0301345 Rev 0

2017-05-04

TELIT
TECHNICAL
DOCUMENTATION

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

NOTICE

While reasonable efforts have been made to ensure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. The information in this document has been carefully checked and is believed to be reliable, however no responsibility is assumed for inaccuracies or omissions. Telit reserves the right to make changes to any products described herein and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Telit does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

It is possible that this publication may contain references to, or information about Telit products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Telit intends to announce such Telit products, programming, or services in your country.

COPYRIGHTS

This manual and the Telit products described herein may be, include or describe copyrighted Telit material, such as computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Telit and its licensors contained herein or in the Telit products described in this manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Telit. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit, as arises by operation of law in the sale of a product.

COMPUTER SOFTWARE COPYRIGHTS

The Telit and Third Party supplied Software (SW) products described in this instruction manual may include copyrighted Telit and other Third Party supplied computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and other Third Party supplied SW certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Telit or other Third Party supplied SW computer programs contained in the Telit products described in this manual may not be copied (reverse engineered) or reproduced in any manner without the express written permission of Telit or the Third Party SW supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit or other Third Party supplied SW, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

USAGE AND DISCLOSURE RESTRICTIONS

I. License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

II. Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

III. High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

IV. Trademarks

TELIT and the Stylized T Logo are registered in the Trademark Office. All other product or service names are the property of their respective owners.

V. Third Party Rights

The software may include Third Party Right software. In this case you agree to comply with all terms and conditions imposed on you in respect of such separate software. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License shall apply to the Third Party Right software.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESS OR IMPLIED FROM ANY THIRD PARTIES REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODE"), AND THE USE OF ANY OR ALL THE OTHER CODE IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODE SHALL HAVE ANY LIABILITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODE OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

PRODUCT APPLICABILITY TABLE

PRODUCT
SL876Q5-A EVK

Table 0-1 Product Applicability Table

CONTENTS

NOTICE.....	2
COPYRIGHTS.....	2
COMPUTER SOFTWARE COPYRIGHTS	2
USAGE AND DISCLOSURE RESTRICTIONS	3
PRODUCT APPLICABILITY TABLE	4
CONTENTS	5
TABLES.....	7
FIGURES	8
1 INTRODUCTION	9
1.1 Purpose.....	9
1.2 Contact and Support Information.....	9
1.3 Text Conventions	10
1.4 Related Documents.....	10
1.4.1 Related Documents Requiring a Non-Disclosure Agreement	10
2 EVALUATION KIT REQUIREMENTS	10
3 EVALUATION KIT (EVK) DESCRIPTION	11
3.1 EVK Contents.....	11
3.2 SL876Q5-A Evaluation Board	12
3.3 SL876Q5-A Module.....	13
3.4 Evaluation Board Layout	14
3.5 Evaluation Board Component Identification.....	15
3.6 Evaluation Board Schematic Diagram	17
4 EVALUATION KIT SETUP	18
4.1 Installing the USB Drivers	18
4.2 Installing SiRFLive	19
5 EVALUATION BOARD OPERATION.....	20
6 USING SIRFLIVE	21
6.1 Starting SiRFLive	21
6.2 SiRFLive Windows	25
6.2.1 Signal View	25

6.2.2	Radar View	26
6.2.3	Debug View.....	27
6.2.4	Location View.....	28
6.3	Logging Data.....	29
6.4	Receiver Commands.....	31
6.4.1	Reset commands	32
6.4.2	Switching Protocols.....	33
6.4.3	Setting the Receiver Type	34
6.4.4	Enabling 5Hz Update	34
6.4.5	OSP MID 136 - Mode Control Command	36
7	UPDATING FIRMWARE WITH SIRFLIVE.....	37
7.1	Flashing Requirements	37
7.2	Flashing Instructions	37
8	SOFTWARE INTERFACE.....	39
8.1	NMEA Output Messages.....	39
8.2	NMEA Input Commands.....	41
8.3	One Socket Protocol (OSP) Output Messages	41
9	DOCUMENT HISTORY	42



TABLES

Table 0-1 Product Applicability Table 4
Table 3-1 EVK Contents..... 11
Table 3-2 SL876Q5-A Evaluation Board Components..... 16
Table 6-1 MID 136 - Mode Control command..... 36
Table 8-1 Default NMEA Output Messages 39
Table 8-2 Available Messages..... 40
Table 8-3 NMEA Talker IDs..... 40

FIGURES

Figure 3-1 EVK photo	11
Figure 3-2 SL876Q5-A Evaluation Board.....	12
Figure 3-3 SL876Q5-A Module.....	13
Figure 3-4 SL876Q5-A Evaluation Board Layout.....	14
Figure 3-5 SL876Q5-A Evaluation Board Schematic Diagram.....	17
Figure 4-1 USB Driver Installation	18
Figure 4-2 Identify new COM port.....	19
Figure 6-1 Connection settings window	21
Figure 6-2 Click Receiver, then Connect on the menu bar.....	22
Figure 6-3 Switch Comm Settings window.....	22
Figure 6-4 The OSP protocol window	23
Figure 6-5 Features, Power Mode window	23
Figure 6-6 Full Power Mode window.....	24
Figure 6-7 Verify NMEA window	24
Figure 6-8 Satellite signal levels	25
Figure 6-9 Satellites by azimuth and elevation	26
Figure 6-10 Receiver Messages (OSP)	27
Figure 6-11 Details of the position fix.....	28
Figure 6-12 Log File command.....	29
Figure 6-13 Enter the filename to specify the log file	30
Figure 6-14 Receiver commands.....	31
Figure 6-15 Reset Window	32
Figure 6-16 Switching to OSP protocol with its default 115200 baud rate.....	33
Figure 6-17 Click Receiver, Receiver Family, then the desired family.....	34
Figure 6-18 Enable 5Hz Nav command.....	34
Figure 7-1 Firmware file selection.....	37
Figure 7-2 Select Firmware file.....	38
Figure 7-3 Successful firmware installation.....	38

1 INTRODUCTION

1.1 Purpose

The scope of this manual is provide product information for the SL876Q5-A Evaluation Kit (EVK).

1.2 Contact and Support Information

For general contact, technical support services, technical questions, and to report documentation errors contact Telit Technical Support at:

- TS-EMEA@telit.com
- TS-AMERICAS@telit.com
- TS-APAC@telit.com

Alternatively, use:

<http://www.telit.com/support>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:




<http://www.telit.com>

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

1.3 Text Conventions

Dates are in ISO 8601 format, i.e. YYYY-MM-DD.

Symbol	Description
	Danger – This information MUST be followed or catastrophic equipment failure and/or bodily injury may occur.
	Caution or Warning – This is an important point about integrating the product into a system. If this information is disregarded, the product or system may malfunction or fail.
	Tip – This is advice or suggestion that may be useful when integrating the product.

1.4 Related Documents

- SL876Q5-A Product User Guide

1.4.1 Related Documents Requiring a Non-Disclosure Agreement

- None

2 Evaluation Kit Requirements

To use the SL876Q5-A Evaluation Kit (EVK), you will need:

- USB Drivers (on the included flash drive)
- SiRFLive 2.07P4 or later (on the included flash drive)
- A PC with a USB port that fulfills the minimum software requirements:
 - Windows XP or later
 - NET Framework 2.0 (automatically installed by the SiRFLive package if necessary - internet connection is required).

3 Evaluation Kit (EVK) Description

3.1 EVK Contents




Figure 3-1 EVK photo

EVK Contents
Plastic case
USB cable
USB drive with software and documentation
Evaluation Board

Table 3-1 EVK Contents

3.2 SL876Q5-A Evaluation Board



With default jumpers


Figure 3-2 SL876Q5-A Evaluation Board

3.3 SL876Q5-A Module



Figure 3-3 SL876Q5-A Module

3.4 Evaluation Board Layout



See Table 3-5 PL-108 Pin Description for jumper color code.

Figure 3-4 SL876Q5-A Evaluation Board Layout

3.5 Evaluation Board Component and Pin Identification

ID	Description
IC 1	SL876Q5-A Module (including chip antenna)
SO 100	SMA connector - External Antenna
SW 100	On-Off Toggle Switch Applies 1V8 to the Module On-Off pin
DL 100	LED – 1PPS output
DL 101	LED - TX data output
DL 102	LED – System ON output
PL 100	Mini USB connector – Power, ground, Tx, and Rx
PL 102	1 x 5 Header Pins
PL 104	1 x 4 Header Pins
PL 108	2 x 10 Header Pins
PL 101	1 x 10 Header Pins
See tables below for Header Pin descriptions	

Table 3-2 Evaluation Board Components

Pin	PL-102 Description
1	Ground
2	PL104-4 & 10 K Ω to 1V8 pullup
3	PL104-3 & 10 K Ω to 1V8 pullup
4	PL104-2
5	PL104-1

Table 3-3 PL-102 Pin Description

Pin	PL-104 Description
1	PL 102-5
2	PL 102-4
3	PL 102-3 & 10 K Ω to 1V8 pullup
4	PL 102-2 & 10 K Ω to 1V8 pullup

Table 3-4 PL-104 Pin Description

Pin	PL-108 Description	Pin	Description	For normal operation
1	V _{GPS}	2	module V _{CC} (module supply current)	Yes
3	module BOOT	4	10 K Ω pullup to 1V8	No
	Jumper these pins only if a “hardware” boot is required (e.g. if using SiRFflash). For SiRFfive re-flashing, do not jumper these pins.			
5	Enable 1V8	6	V _{USB}	Yes
7	Enable 3V _{ALT}	8	V _{USB}	Yes
9	Enable V _{GPS}	10	V _{USB}	Yes
11	V _{ANT} (Antenna Voltage Supply)	12	3V _{ALT} controlled by LNA Enable	Option
13	module GPIO6	14	10 K Ω pullup to 1V8	UART - Yes
15	module GPIO7	16	10 K Ω pulldown to Ground	UART - No
17	USB RXD	18	module TX	Yes
19	module RX	20	USB TXD	Yes

Table 3-5 PL-108 Pin Description

Pin	PL-101 Description
1	1V8
2	module 1PPS pulse output (level translated)
3	module SDA (GPIOB)
4	module SCL (GPIOC)
5	module nExternal Ant Enable (input) Connect to ground (e.g. pin 9) to enable an external antenna.
6	N C
7	module GPIOA
8	module nRESET
9	Ground
10	N C

Table 3-6 PL-101 Pin Description

4 Evaluation Kit Setup

4.1 Installing the USB Drivers

Before connecting the SL876Q5-A Evaluation Kit, install the necessary USB drivers.

- Double-click the USB driver executable CDM v2.12.00 WHQL Certified.exe, and follow the directions to install the USB drivers.



Figure 4-1 USB Driver Installation

- Click “Continue Anyway” to install the USB COM port driver
- When the EVK board is connected to a personal computer USB port, the driver will create a COM port.
- Use the Windows “Device Manager” to check the identification of the new COM port. This port identification is necessary for EVK tools to connect to the evaluation kit.




Figure 4-2 Identify new COM port

- In this example, the COM port is assigned as COM5

4.2 Installing SiRFLive

Minimum PC requirements:

- Pentium CPU 2 GHz
- 1 GB of RAM
- 100 MB hard drive

Recommended:

- 2 GB of RAM
- 1280 x 1024 screen resolution

Double-click the SiRFLiveInstaller_MKTG_Lite.msi file to install the SiRFLive program, then follow the installer directions until finished.

It is recommended that SiRFLive be installed to the default location – C:\CSR\SiRFLive.

5 Evaluation Board Operation

1. Verify that the correct jumpers are installed. See Sections **3.4 Evaluation Board Layout** and **3.5 Evaluation Board Component Identification**.
2. Power will be applied to the SL876Q5-A module when the USB interface is connected to a USB port on a personal computer. When the EVB On-Off switch is turned ON, the module ON_OFF pin will be powered up and the module will begin operation.
3. Place the board face up in a location with a clear view of open sky.
4. Use SiRFLive or TelitView to send commands to and display output from the module.

6 Using SiRFLive

6.1 Starting SiRFLive

1. Connect the EVK to a USB port on the PC.
2. Turn on (up) the EVK Power switch.

3. Launch the SiRFLive application.



4. Connection Settings window: Use the **Receiver** drop-down box to select the receiver. This is where you select the COM port that was previously created by the USB driver in **Section 4.1 Installing the USB Drivers**.




Figure 6-1 Connection settings window

5. If the default **Baud Rate** is 115200 and **Protocol** is OSP on your EVK, leave those boxes with their values as presented.
If the default **Baud Rate** is 9600 and **Protocol** is NMEA on your EVK, change those boxes to match.
If you have changed the receiver's defaults, select them using the **Baud Rate** and **Protocol** drop-down boxes.
6. Click **OK**. The remainder of these screen captures will show NMEA protocol. OSP will present somewhat different data.

7. If necessary, click **Receiver**, then **Connect** on the menu bar.




Figure 6-2 Click Receiver, then Connect on the menu bar

8. The SL876Q5-A defaults to a power-saving mode called SmartGNSS2, so you may see the GLONASS satellites disappear from the Radar View. This is normal. If you wish to command the full-time use of GLONASS as well as GPS, use the following procedure:

- a. Click **Receiver**, **Command**, then **Switch Comm Settings**.




Figure 6-3 Switch Comm Settings window

- b. Verify that **Switch Protocol (to OSP)** and **Baud Rate of 115200** are selected as shown above.

- c. Click **Set**. The receiver and display will both switch to OSP protocol at 115,200 bps.




Figure 6-4 The OSP protocol window

- d. Click **Features**, **Power Mode**, then **Advanced**.




Figure 6-5 Features, Power Mode window

e. Verify that **Full Power** is selected, and click **OK**.




Figure 6-6 Full Power Mode window

f. To return to the NMEA display, click **Receiver, Command, Switch Comm Settings**




Figure 6-7 Verify NMEA window

g. Verify **NMEA at 9600 bps** (or your desired rate), and click **Set**.

9. There are many additional functions available in SiRFLive. Please refer to the built-in User Manual for further details. Click **Help** in the Menu Bar, then **User Manual**.

6.2 SiRFLive Windows

After a successful connection with the receiver is established, the default SiRFLive windows should be arranged and become filled with data.



If not all the default windows are arranged or opened, under the Main Menu Bar, Click **Window, Restore Layout, and Default.**

6.2.1 Signal View



(Tool Bar icon)




Figure 6-8 Satellite signal levels

6.2.2 Radar View




(Tool Bar icon)



Symbol	Description
Circle	GPS
Square	GLONASS
Sky blue	SBAS
Red	$C/N_0 = 0$
Blue	$C/N_0 \neq 0$ and <u>not</u> used in the navigation solution
Green	$C/N_0 \neq 0$ and used in the navigation solution
Orange	ABP is being used to acquire satellites
Purple	CGEE is being used
Pink	SGEE is being used


Figure 6-9 Satellites by azimuth and elevation

6.2.3 Debug View



(Tool Bar icon)

Displays the messages incoming from the receiver



```
COM14: Debug View SW Version: Not detected
14896010 CM:RtcEdgeAlign T:127 dRate:9 count:15141 31426 Acq:3310918892 Wclk:1 dRtc:0.999786377 prevAcq:3294553650
bepDrift:0.999954973 rtcDrift:0.999954869
NLC: 2 4 9 27 12 17 28 25 0 0 0 0
NLD: ff ff ed ff ff ff ed 6d 0 0 0 0
NLE: 0 0 0 0 0 0 0 10 0 0 0 0
NLF: 1 1 1 1 1 1 1 0 0 0 0 0
NLG:251291.009299760 0.009299918 -2466256.6 -4706248.9 3516971.6
NLH:251291.009299760 251290.999999837 33.678648 -117.656278 236.4
NLI:251291.009299760 56 3309424385 0 7 5 5
14896050 BEP: TOw:251291.009299760 1602 swd:1.000061 A:3309424385 CB:0.009300 CD:96326 Y CDUnc:63
14896050 PrePos: IntUpd KFNv sv: 0 Tag:14896000 Flags:60 Clk:0.000001 S20ms:0 S1ms:0.000001 CDrtt(hz):64.1 HP:159.5
HV:3.18
```

Figure 6-10 Receiver Messages (OSP)

6.2.4 Location View



(Tool Bar icon)



Map position button requires Internet access.

Map Position

Configuration

Clear Data

Set Reference Location

The screenshot shows a window titled "COM2 : Location View" with a toolbar containing icons for map, configuration, clear data, and set reference location. The main area displays "Position Information" with the following data:

Receiver Time(UTC): 18:33:21	TOW: 326016.04	Ext. Week: 1635
Latitude: 33.670878	Longitude: -117.653770	Altitude: 220.29 m
HDOP: 0.80	Speed: 0.02 m/s	Heading: 306.87°
Mode: > 4-SVs KF + Dgps		
Number of SVs used in Fix: 10	(11 14 16 20 23 24 25 30 31 32)	

Below the table, the coordinates "Lat:33.670852, Lng:-117.653742" are shown. A circular diagram with a red center point and a radius of 5.00m is displayed. The "Auto Center" checkbox is checked at the bottom.

Figure 6-11 Details of the position fix

6.3 Logging Data



(Main Tool Bar icon)

SiRFLive can record the current message stream (OSP or NMEA) into a log file.

From the Menu Bar, click **File, Log File, & Start** or click the **Log File** icon on the Tool Bar.




Figure 6-12 Log File command

Enter the desired log file path and filename in the **Log File Path** box, as shown below, then click **Start** to begin logging.




Figure 6-13 Enter the filename to specify the log file

6.4 Receiver Commands

Many of the receiver commands can be accessed through the Menu Bar under **Receiver, Command**. There are also equivalent shortcuts on the Tool Bar for frequently used commands




Figure 6-14 Receiver commands



Some receiver commands are available in One Socket Protocol (OSP) only.

6.4.1 Reset commands




(Tool Bar icon)

Select from the Menu Bar **Receiver**, **Command**, **Reset** or click the **Reset** icon on the Tool Bar.

Resets are used to measure the TTFF of the receiver. The TTFF/Nav Accuracy window conveniently displays the TTFF in seconds and Navigation accuracy based on the Reference Location.

Reference Location allows the user to change the position used as the reference. This helps determine position accuracy in conjunction with Time-To-First-Fix values.



COM15: Reset

Reference Location

Sim_BDS_FixedPwr_BDS3

Latitude 31

Longitude 121

Altitude 5

Use Fixed Position as Ref

Set as Default

Check Position Accuracy

Warm Init Params

Update with current fixed data

Use Current PC Time

Position

X (m) -2686727

Y (m) -4304282

Z (m) 3851642

Clock Drift (Hz) 75000

Ext Week # 1311

TOW 86400

Channels 12

Use New Factory Reset

Reset Mode

Hot Start

Warm Start (No Init)

Warm Start (Init)

Cold Start

Factory Reset

Control Mode

Enable Development Data

Config AutoRepl Send Cancel

Figure 6-15 Reset Window

6.4.2 Switching Protocols

On the Menu Bar, select **Receiver, Command, Switch COMM Settings**.

Click **Set** to apply settings.

OSP has many commands that are not available in NMEA. Therefore, switching to OSP is recommended for testing purposes.




Figure 6-16 Switching to OSP protocol with its default 115200 baud rate

6.4.3 Setting the Receiver Type

SiRFLive will normally auto-detect the connected chipset, but if not, click **Receiver**, **Receiver Family**, then the desired family.




Figure 6-17 Click Receiver, Receiver Family, then the desired family

6.4.4 Enabling 5Hz Update

First, set the baud rate high enough so that characters are not dropped. The default rates (9600 for NMEA and 115.200 for OSP) may be too low depending on the configured message set.

Through the SiRFLive Menu Bar, click **Receiver**, **Navigation**, **Set 5Hz Nav** and select **Enable 5Hz Nav**.




Figure 6-18 Enable 5Hz Nav command

The **Enable 5Hz Nav** command in SiRFLive sends the following OSP:

A0 A2 00 0E 88 00 00 04 04 00 00 00 00 00 00 00 0F 02 00 A1 B0 B3

The **Disable 5Hz Nav** command in SiRFLive sends the following OSP:

A0 A2 00 0E 88 00 00 04 00 00 00 00 00 00 00 0F 02 00 9D B0 B3

6.4.5 OSP MID 136 - Mode Control Command

Name	Bytes	Binary (Hex)		Unit	Description
		Scale	Example		
Message ID	1 U		88		Decimal 136
Reserved	2 U		0000		Reserved
Degraded Mode	1 U		01		Controls use of 2-SV and 1-SV solutions
PositionCalc Mode	1 U		01		xxxx xxx0 = ABP, OFF xxxx xxx1 = ABP, ON xxxx xx0x = Reverse EE OFF xxxx xx1x = Reverse EE ON xxxx x0xx = 5Hz nav update OFF xxxx x1xx = 5Hz nav update ON xxxx 0xxx = SBAS Ranging use OFF xxxx 1xxx = SBAS Ranging use ON
Reserved	1 U		00		Reserved
Altitude	2 S		0000	meters	User specified altitude, range - 1,000 to 10,000
Alt Hold Mode	1 U		00		Controls use of 3-SV solution
Alt Hold Source	1 U		00		0 = Use last computed altitude 1 = User user-input altitude
Reserved	1 U		00		Reserved
DegradedTime Out	1 U		05	sec	0 = disable degraded mode, 1 to 120 seconds degraded mode time limit
DR Time Out	1 U		02	sec	0 = disable dead reckoning, 1 to 120 seconds dead reckoning mode time limit
Measurement and Track Smoothing	1 U		00000011		xxxxxxx0 = disable track smoothing xxxxxxx1 = enable track smoothing xxxxxx0x = use raw measurements xxxxxx1x = use smooth measurements

Table 6-1 MID 136 - Mode Control command

7 Updating Firmware with SiRFLive

7.1 Flashing Requirements

- Personal Computer with a USB/COM port running SiRFLive Firmware file

7.2 Flashing Instructions



Note: Do NOT use the BOOT pin on the module (leave it floating).

1. Click on **Receiver, Update Firmware** from the Menu Bar.




Figure 7-1 Firmware file selection

2. Enter the filename or browse to the firmware file.




Figure 7-2 Select Firmware file

3. Click **Update**.




Figure 7-3 Successful firmware installation

4. The new firmware will be installed, and the receiver will begin operation.

8 Software Interface

The host serial I/O port (UART, I²C, or SPI) supports full duplex communication between the receiver and the user.

The default UART configuration is: NMEA, 9600 bps, 8 data bits, no parity, and 1 stop bit.

Two protocols are available for data output and command input:

- NMEA-0183 V4.10
- SiRF One Socket Protocol (OSP)



More information regarding the software interface can be found in the Telit CSR Software User Guide. Access to this document requires a Non-Disclosure Agreement (NDA) with Telit.

8.1 NMEA Output Messages

Defaults:

- NMEA-0183
- 1 Hz fix rate. Maximum is 10 Hz.
- Message Set

Standard Messages

Message ID	Description	Frequency
RMC	GNSS Recommended minimum navigation data	1
GGA	GNSS position fix data	1
GSA	GNSS Dilution of Precision (DOP) and active satellites	1
GSV	GNSS satellites in view.	1 / 5
Note: Multiple GSA and GSV messages may be output per cycle.		

Table 8-1 Default NMEA Output Messages

The following messages can be enabled by command:

Message ID	Description
GLL	Geographic Position – Latitude & Longitude
GNS	GNSS Fix Data
VTG	Course Over Ground & Ground Speed

Table 8-2 Available Messages

Talker ID	Constellation
GA	Galileo
GB	BeiDou
GL	GLONASS
GP	GPS
GN	Solutions using multiple constellations

Table 8-3 NMEA Talker IDs

Proprietary Messages

The receiver can issue several proprietary NMEA output messages (\$PSRF) which report additional receiver data and status information.

8.2 NMEA Input Commands

The receiver uses NMEA proprietary messages for commands and command responses. This interface provides configuration and control over selected firmware features and operational properties of the module.

The format of a command is:

```
$<command-ID>[,<parameters>]*<cr><lf>
```

Commands are NMEA proprietary format and begin with "\$PSRF".

Parameters, if present, are comma-delimited as specified in the NMEA

8.3 One Socket Protocol (OSP) Output Messages

SiRF One Socket Protocol (OSP) is supported. This is an extension of the existing SiRF Binary protocol. The following messages are output once per second:

- MID 2
- MID 3
- MID 4
- MID 7
- MID 9
- MID 41
- MID 64 SUB ID 2 (One message for each satellite being tracked).
- MID 138

9 DOCUMENT HISTORY

Revision	Date	Changes
0	2017-03-21	First Issue



SUPPORT INQUIRIES

Link to www.telit.com and contact our technical support team for any questions related to technical issues.

www.telit.com



Telit Communications S.p.A.
Via Stazione di Prosecco, 5/B
I-34010 Sgonico (Trieste), Italy

Telit Wireless Solutions Inc.
3131 RDU Center Drive, Suite 135
Morrisville, NC 27560, USA

Telit Wireless Solutions Ltd.
10 Habarzel St.
Tel Aviv 69710, Israel

Telit IoT Platforms LLC
5300 Broken Sound Blvd, Suite 150
Boca Raton, FL 33487, USA

Telit Wireless Solutions Co., Ltd.
8th Fl., Shinyoung Securities Bld.
6, Gukjegeumyung-ro8-gil, Yeongdeungpo-gu
Seoul, 150-884, Korea

Telit Wireless Solutions
Tecnologia e Servicos Ltda
Avenida Paulista, 1776, Room 10.C
01310-921 São Paulo, Brazil

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2016, Telit