



GNSS Software Extensions

User Guide

PRELIMINARY

1W0301544 Rev. 5 – 2021-07-26

APPLICABILITY TABLE

PRODUCTS
SL869-V2
SL869L-V2
SL871
SL871L
SE868-a
SE868K3-A
SE868K3-AL
SE878K3-A
SC872-A
SC874-A
SE868-v3
SE873
SE873Q5
SE876Q5-A
SL869-V3
SL869-ADR
SE868SY-D

SOFTWARES
V13-2.3.2-STD-5.1.14
V26-1.0.0-STD-5.7.11P4 and subsequent versions
V33-1.0.6-STD-4.5.10
V33-1.0.4-CLDR-4.7.10
V50-1.0.0-B01 and subsequent versions

CONTENTS


APPLICABILITY TABLE	2
CONTENTS	3
1. INTRODUCTION	7
1.1. Scope	7
1.2. Audience	7
1.3. Contact Information, Support	7
1.4. Symbol Conventions	8
1.5. Related Documents	8
2. COMMUNICATION INTERFACE	9
2.1. Serial Communication	9
2.2. Telit Proprietary NMEA Messages Format	9
2.2.1. Telit Proprietary NMEA Messages Applicability Table	11
3. TELIT NMEA MESSAGES	12
3.1. PTWSVER - Telit Software Version Message	12
3.1.1. Input Message	12
3.1.2. Output Message	12
3.2. PTWSLNA – LNA Message	13
3.2.1. Input Message	13
3.2.1.1. Set LNA Gain	14
3.2.1.2. Query LNA Gain	14
3.2.2. Output Message	14
3.2.2.1. Set LNA Gain Responses	14
3.2.2.2. Query LNA Gain Responses	15
3.3. PTWSMODE – MODE Messages	15
3.3.1. CONST Message Type	15
3.3.1.1. Input Message	15
3.3.1.2. Output Message	17
3.4. PTWSRLM – RLM Messages	20
3.4.1. Input Message	20



3.4.1.1.	Configure RLM Message	20
3.4.1.2.	Query RLM Message Configuration	21
3.4.2.	Output Message	22
3.4.2.1.	Configure RLM Message Response	22
3.4.2.2.	Query RLM Message Configuration Response	22
3.5.	PTWSEPE – EPE Messages	22
3.5.1.	Input Message	22
3.5.2.	Output Message	23
3.5.2.1.	Input Message Response	23
3.5.2.2.	EPE Reporting Message	24
3.6.	PTWSANT – Antenna Status Messages	24
3.6.1.	Input Message	25
3.6.2.	Output Message	26
3.6.2.1.	Antenna Status Reporting Message	26
3.6.2.2.	Antenna Status Reporting Mode Configuration Response	27
3.6.3.	Antenna Status Error and Acknowledge Responses	27
3.7.	PTWSFENCE – Geofencing Messages	28
3.7.1.	CONFIG Message Type	28
3.7.1.1.	Input Messages	28
3.7.1.2.	Output Messages	30
3.7.2.	STATUS Message Type	31
3.7.2.1.	Input Messages	31
3.7.2.2.	Output Messages	33
3.8.	PTWSRESET - Reset Message	34
3.8.1.	Input Message	34
3.8.2.	Output Message	35
4.	APPENDIX A – TELIT LEGACY NMEA MESSAGES	36
4.1.	Telit Legacy NMEA Messages Format	36
4.1.1.	Telit Legacy NMEA Messages Applicability Table	37
4.2.	PTWS,VERSION – Telit Software Version Message	38
4.2.1.	Input Message	38



4.2.2.	Output Message	38
4.3.	PTWS,ANT – Antenna Status Message	38
4.3.1.	Input Message	39
4.3.2.	Output Message	39
4.4.	PTWS,JAM – Jamming Detection Status Message	39
4.4.1.	Input Message	40
4.4.2.	Output Message	40
4.5.	PTWS,LNA – LNA Gain Message	41
4.5.1.	Input Messages	41
4.5.1.1.	Set LNA Gain	41
4.5.1.2.	Query LNA Gain	41
4.5.2.	Output Message	42
4.6.	PTWS,ODO – ODO Messages	42
4.6.1.	Input Messages	42
4.6.1.1.	Start ODO Count	42
4.6.1.2.	Stop ODO Count	43
4.6.1.3.	Query ODO Count	43
4.6.1.4.	Turn ODO Output Messages On	43
4.6.1.5.	Turn ODO Output Messages Off	43
4.6.2.	Output Message	44
5.	PRODUCT AND SAFETY INFORMATION	45
5.1.	Copyrights and Other Notices	45
5.1.1.	Copyrights	45
5.1.2.	Computer Software Copyrights	45
5.2.	Usage and Disclosure Restrictions	46
5.2.1.	License Agreements	46
5.2.2.	Copyrighted Materials	46
5.2.3.	High Risk Materials	46
5.2.4.	Trademarks	47
5.2.5.	Third Party Rights	47
5.2.6.	Waiver of Liability	47



5.3.	Safety Recommendations	48
6.	GLOSSARY	49
7.	DOCUMENT HISTORY	50

PRELIMINARY

1. INTRODUCTION

1.1. Scope

This document describes the Telit software extensions, which are custom commands from the proprietary Telit NMEA interface.

The interface described in this specification applies to the default or stock firmware for GNSS modules in the V13, V26, V33, and V50 firmware families that use flash program memory.

1.2. Audience

This document is intended for public distribution to potential customers who are evaluating a GNSS module from the above firmware family and which is listed in the Applicability Table. It can also be used by customers who are developing application software for a Host Processor contained within their product that incorporates one of the listed modules.

1.3. Contact Information, Support

For general contact, technical support services, technical questions and report of documentation errors contact Telit Technical Support at:

- TS-EMEA@telit.com
- TS-AMERICAS@telit.com
- TS-APAC@telit.com
- TS-SRD@telit.com
- TS-ONEEDGE@telit.com

Alternatively, use:

<https://www.telit.com/contact-us>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<https://www.telit.com>

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates the user feedback on our information.

1.4. Symbol Conventions



Danger: This information **MUST** be followed or catastrophic equipment failure or personal injury may occur.



Warning: Alerts the user on important steps about the module integration.



Note/Tip: Provides advice and suggestions that may be useful when integrating the module.



Electro-static Discharge: Notifies the user to take proper grounding precautions before handling the product.

Table 1: Symbol Conventions

All dates are in ISO 8601 format, that is YYYY-MM-DD.

1.5. Related Documents

- [1] NMEA 0183, Version 3.00, National Marine Electronics Association
- [2] Interface Specification IS-GPS-200G, 2012-09-05
- [3] Galileo-OS-SIS-ICD
- [4] Galileo-SAR-SDD

2. COMMUNICATION INTERFACE

The serial communication interface between the GNSS receiver module and the host processor is based on the NMEA-0183 protocol standard specified by the National Marine Electronics Association (NMEA). It is an ASCII standard widely used throughout the GPS industry for serial communication with GNSS receivers [\[1\]](#).



Note: For a full comprehensive description of NMEA 0183 standard, please refer to [\[1\]](#).

2.1. Serial Communication

Serial communication with the GNSS receiver is primarily conducted over the serial port. There is no hardware flow control. The default port settings are:

- 9600 Baud
- Eight data bits
- No parity bits
- One stop bit

Note: Some Firmware versions may have different default values than those given above.

2.2. Telit Proprietary NMEA Messages Format

In addition to the standard NMEA output messages as well as vendor's proprietary NMEA messages, Telit GNSS software supports a set of proprietary NMEA messages, that comply with NMEA 0183, to further enhance the control of GNSS receivers and expose more functionalities.

Telit proprietary NMEA messages start with the "\$" character, which is then followed by the proprietary address field string that uses the Manufacturer's Mnemonic Code registered by Telit with the NMEA, which is "TWS". Thus, the Telit proprietary address field is of the form:

\$PTWSxxx[x...]

Where, xxx.. represents an alphanumeric message identifier having a minimum of three characters and being all upper case.

Checksum fields are included in all Telit proprietary NMEA output messages, and letters representing hexadecimal digits are upper-case. Checksum fields are optional for Telit proprietary NMEA input commands.

The messages end with Carriage Return (CR) and Line Feed (LF) characters.

Following is the list of Telit NMEA messages supported with the applicable software.

Proprietary Address Field	Description
\$PTWSVER	Telit software version message
\$PTWSLNA	LNA Gain message
\$PTWSMODE	Operational setting message
\$PTWSRLM	Return Link Message
\$PTWSEPE	Estimated Position Error
\$PTWSANT	Antenna status message
\$PTWSFENCE	Geofence Management message
\$PTWSRESET	Reset message

Table 2: Telit Proprietary NMEA Messages

2.2.1. Telit Proprietary NMEA Messages Applicability Table

		\$PTWSVER	\$PTWSLNA	\$PTWSMODE	\$PTWSRLM	\$PTWSEPE	\$PTWSANT	\$PTWSFENCE	\$PTWSRESET
V13	SL869-V2	✓	✓	✓	✓	✓	x	✓	x
	SL869L-V2	✓	✓	✓	✓	✓	x	✓	x
	SL871	✓	✓	✓	✓	✓	✓	✓	x
	SL871L	✓	✓	✓	✓	✓	✓	✓	x
	SE868-A	✓	✓	✓	✓	✓	x	✓	x
	SE868K3-A	✓	✓	✓	✓	✓	x	✓	x
	SE868K3-AL	✓	✓	✓	✓	✓	x	✓	x
	SE878K3-A	✓	✓	✓	✓	✓	✓	✓	x
	SC872-A	✓	✓	✓	✓	✓	x	✓	x
	SC874-A	✓	✓	✓	✓	✓	x	✓	x
V26	SE868-V3	✓	✓	✓	✓	✓	x	✓	x
	SE873	✓	✓	✓	✓	✓	x	✓	x
	SE873Q5	✓	✓	✓	✓	✓	x	✓	x
	SL876Q5-A	✓	✓	✓	✓	✓	✓	✓	x
V33	SL869-V3	✓	x	✓	x	✓	✓	✓	x
	SL869-ADR	✓	x	✓	x	✓	✓	✓	x
V50	SE868SY-D	✓	x	✓	x	x	x	✓	

x	Not Supported
✓	Supported

Table 3: Telit Proprietary NMEA Messages Applicability Table

3. TELIT NMEA MESSAGES

3.1. PTWSVER - Telit Software Version Message

The Telit Software Version can be polled using the input message described in this section.

This command obsoletes \$PTWS,VERSION. Therefore, this latter is still supported but its usage is now deprecated.

3.1.1. Input Message

Synopsis:

```
$PTWSVER,action[,param][*CS]<CR><LF>
```

Example:

```
$PTWSVER,GET,TELIT*57<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSVER	Telit Software Version Message
Action	GET	Action to be executed: GET action only is supported
Param	TELIT	Optional parameter indicating the specific type of version to be retrieved TELIT = The Telit version is retrieved SDK = The vendor's version string from the underlying SDK is retrieved If no parameter is provided, the Telit version is retrieved.

Table 4: PTWSVER – Telit Software Version Input Message Structure

3.1.2. Output Message

Synopsis:

```
$PTWSVER,param,text*CS<CR><LF>
```

Error:

```
$PTWSVER,ERROR[,Action][,Parameter]*CS<CR><LF>
```

```
$PTWSCHECKSUM*0D
```

```
$PTWSINVALID*51
```

Example:

```
$PTWSVER,TELIT,V13-2.3.0-STD-5.1.5-N96-000200*78
```

Field	Example	Description
Proprietary Address Field	PTWSVER	Telit SW Version Message
Param	TELIT	Parameter indicating the type of version string being reported TELIT = Telit version string SDK = Vendor's version string from the underlying SDK
Text	VAL	Firmware Version Information
VerString	V13-2.3.0-STD-5.1.5-N96-000200	Telit FW version string

Table 5: PTWSVER – Telit Software Version Output Message Structure

3.2. PTWSLNA – LNA Message

LNA related settings can be controlled using the messages described in this section.

This command obsoletes \$PTWS,LNA. Therefore, this latter is still supported but its usage is now deprecated.

3.2.1. Input Message

Synopsis:

```
$PTWSLNA,attrib,action[,<value>][*CS]<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSLNA	Telit LNA Gain Message
Attrib	GAIN	Parameter indicating the feature attribute to which the message applies: GAIN attribute only is supported
Action	SET	Action to be executed GET = Poll the current LNA Gain value - The next field of this message must be omitted SET = Configure the LNA Gain to a specific setting to be specified in the next field
Value	HIGH	Optional parameter indicating the specific LNA GAIN setting when the Action is SET HIGH = High gain LOW = Low gain

Table 6: PTWSLNA – Telit LNA Input Message Structure

3.2.1.1. Set LNA Gain

This command is used to configure the LNA Gain setting.

Synopsis:

```
$PTWSLNA,GAIN,SET,<value>[*CS]<CR><LF>
```

Example:

```
$PTWSLNA,GAIN,SET,LOW*78<CR><LF>
```



Note: V26 Firmware Family

The module performs a HOT Start after the command execution.

3.2.1.2. Query LNA Gain

This command is used to query the current LNA Gain setting.

Synopsis:

```
$PTWSLNA,GAIN,GET[*CS]<CR><LF>
```

Example:

```
$PTWSLNA,GAIN,GET*14<CR><LF>
```

3.2.2. Output Message

3.2.2.1. Set LNA Gain Responses

Success:

```
$PTWSLNA,OK*6B
```

Error:

```
$PTWSLNA,ERROR,GAIN,SET*74
```

```
$PTWSLNA,ERROR,GAIN*1A
```

```
$PTWSLNA,ERROR,SET*4A
```

```
$PTWSLNA,ERROR*37
```

```
$PTWSNOSUPPORT*4E
```

```
$PTWSCHECKSUM*0D
```

```
$PTWSINVALID*51
```

3.2.2.2. Query LNA Gain Responses

Success:

```
$PTWSLNA,GAIN,value*CS<CR><LF>
```

Example:

```
$PTWSLNA,GAIN,LOW*16<CR><LF>
```

Error:

```
$PTWSLNA,ERROR,GAIN*1A
```

```
$PTWSLNA,ERROR*37
```

```
$PTWSNOSUPPORT*4E
```

```
$PTWSCHECKSUM*0D
```

```
$PTWSINVALID*51
```

3.3. PTWSMODE – MODE Messages

Telit MODE messages can be used to control various aspects of the operating mode of the GNSS module.

3.3.1. CONST Message Type

PTWSMODE,CONST messages can be used to control (enable, disable) the use of navigational satellite constellations and poll the current configuration. When a constellation is enabled, the module will acquire and track satellites from that constellation and use its measurements to update the navigational solution.

3.3.1.1. Input Message

Synopsis:

```
$PTWSMODE,CONST,action[,GPS][,GLO][,BDS][,BDSB1C][,GAL][,QZS][,NAV][,GPSL5][,G  
ALE5][,BDSB2][,QZSL5]*CS<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSMODE	Telit MODE Messages
Attrib	CONST	Parameter indicating the feature attribute to which the message applies: CONST attribute only is supported

Field	Example	Description
Action	SET	Action to be executed GET = Poll the current enabled constellations - The next fields of this message must be omitted SET = Configure the navigational constellations to be used – This configuration must be specified using one or more comma-separated fields of type Parameter specified below
ParameterN	GPS	Optional parameter indicating the specific constellations that must be enabled GPS = Enable GPS constellation GLO = Enable GLONASS constellation GAL = Enable GALILEO constellation BDS = Enable BEIDOU constellation (B1I signal) BDSB1C = Enable BEIDOU constellation (B1C signal) QZS = Enable QZSS constellation NAV = Enable IRNSS/NAVIC (L5 only) constellation GPSL5 = Enable GPS L5 constellation GALE5 = Enable GALILEO E5 constellation BDSB2 = Enable Beidou B2 constellation QZSL5 = Enable QZSS L5 constellation At least one constellation must be present in the command, however QZS-only operation is not supported. Also, GLONASS (GLO) and Beidou (BDS) constellations cannot be enabled at the same time.

Table 7: PTWSMODE,CONST – Telit MODE,CONST Input Message Structure



Note: NAV, BDSB1C, GPSL5, GALE5, BDSB2, QZSL5 constellations are supported by V50 firmware family only.

3.3.1.1.1. Set Active Constellations

This command is used to enable the active constellations.

Synopsis:

```
$PTWSMODE,CONST,SET[,GPS][,GLO][,BDS][,BDSB1C][,GAL][,QZS][,NAV][,GPSL5][,GALE5] [,BDSB2][,QZSL5] [*CS]<CR><LF>
```

Example:

```
$PTWSMODE,CONST,SET,GPS,GLO*04<CR><LF>
```

3.3.1.1.2. Query Active Constellations

This command is used to query the constellations currently enabled.

Synopsis:


```
$PTWSMODE,CONST,GET[*10]<CR><LF>
```

Example:

```
$PTWSMODE,CONST,GET*10<CR><LF>
```

3.3.1.2. Output Message

3.3.1.2.1. Set Active Constellations Response

Success:

```
$PTWSMODE,OK*2B
```

Error:

```
$PTWSMODE,ERROR,CONST,SET*70
```

```
$PTWSMODE,ERROR,CONST*1E
```

```
$PTWSMODE,ERROR*77
```

```
$PTWSNOSUPPORT*4E
```

```
$PTWSCHECKSUM*0D
```

3.3.1.2.2. Query Active Constellations Response

Success:

```
$PTWSMODE,CONST[,GPS][,GLO][,BDS][,BDSB1C][,GAL][,QZS][,NAV][,GPSL5][,GALE5][,BDSB2][,QZSL5][*CS]<CR><LF>
```

Example:

```
$PTWSMODE,CONST,GPS,GLO*6A<CR><LF>
```

Error:

```
$PTWSMODE,ERROR,CONST*1E
```

```
$PTWSMODE,ERROR*77
```

```
$PTWSCHECKSUM*0D
```

Note: V26 Firmware Family

The supported constellation combinations are as follows:

GPS	GLO	BDS	GAL	QZS
ON	OFF	OFF	OFF	OFF
ON	ON	OFF	OFF	OFF
ON	OFF	ON	OFF	OFF
ON	OFF	OFF	ON	OFF
ON	ON	OFF	ON	OFF
ON	OFF	ON	ON	OFF
ON	OFF	OFF	OFF	ON
ON	ON	OFF	OFF	ON
ON	OFF	ON	OFF	ON
ON	OFF	OFF	ON	ON
ON	ON	OFF	ON	ON
ON	OFF	ON	ON	ON
OFF	OFF	OFF	ON	OFF

Note: V13 Firmware Family

The supported constellation combinations are as follows:

GPS	GLO	BDS	GAL	QZS
ON	OFF	OFF	OFF	N/A
ON	ON	OFF	OFF	N/A
ON	OFF	ON	OFF	N/A
ON	OFF	OFF	ON	N/A
ON	ON	OFF	ON	N/A

QZSS configuration cannot be changed at runtime through \$PTWSMODE,CONST.

Note: V33 Firmware family

The supported constellation combinations are as follows:

GPS	GLO	BDS	GAL	QZS
ON	OFF	OFF	OFF	OFF
OFF	ON	OFF	OFF	OFF
ON	ON	OFF	OFF	OFF
OFF	OFF	ON	OFF	OFF
ON	OFF	ON	OFF	OFF
OFF	ON	ON	OFF	OFF
OFF	OFF	OFF	ON	OFF
ON	OFF	OFF	ON	OFF
OFF	ON	OFF	ON	OFF
ON	ON	OFF	ON	OFF
OFF	OFF	ON	ON	OFF
ON	OFF	ON	ON	OFF
OFF	OFF	OFF	OFF	ON
ON	OFF	OFF	OFF	ON
OFF	ON	OFF	OFF	ON
ON	ON	OFF	OFF	ON
OFF	OFF	ON	OFF	ON
ON	OFF	ON	OFF	ON
OFF	OFF	OFF	ON	ON
ON	OFF	OFF	ON	ON
OFF	ON	OFF	ON	ON
ON	ON	OFF	ON	ON
OFF	OFF	ON	ON	ON
ON	OFF	ON	ON	ON

V50 Firmware family

The supported constellation combinations withstand the following limitations:

- Single constellation mode is available only for GPS
- NAVIC and GLONASS constellations cannot be enabled simultaneously
- Maximum four concurrent constellations can be enabled at the same time:
 - Different bands for the same constellation (for example, GPS + GPS L5) are considered as a single constellation
 - GPS and QZSS are considered as one constellation
 - GPS and QZSS constellations must use the same band (for example, both L1, both L5 or both L1+L5)
 - QZSS only operation is not supported.



Note: In case of wrong constellation combination, the module's response is:

```
$PTWSNOSUPPORT*4E
```

and the current configuration is maintained.

3.4. PTWSRLM – RLM Messages

PTWSRLM messages are used to control the reporting of the RLM (Return Link Service Message) output message defined in the NMEA-0183 standard.

3.4.1. Input Message

3.4.1.1. Configure RLM Message

The reporting of the RLM NMEA output message can be configured using the message described in this section.

Synopsis:

```
$PTWSRLM,action[,<value>][*CS]<CR><LF>
```

Examples:

```
$PTWSRLM,ENABLE*7E<CR><LF>
```

```
$PTWSRLM,REGISTER,0A0A0A0A0A0A0A0*1B<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSRLM	Telit RLM Message
Action	ENABLE	Action to be executed Allowed values to enable/disable the reporting of the RLM message ENABLE = Enable RLM NMEA output message DISABLE = Disable RLM NMEA output message Allowed values to register/unregister a specific Beacon ID for which the reporting of the RLM message is to be enabled REGISTER = Register a Beacon ID UNREGISTER = Unregister a Beacon ID
Value		Optional parameter, in form of 15 hex digits, indicating the specific Beacon ID for which the reporting of the RLM message is to be enabled – mandatory when the Action field is REGISTER

Table 8: PTWSRLM – Telit RLM Message Structure

Note: The reporting of the RLM NMEA output message is disabled by default at each module restart. \$PTWSRLM,ENABLE command has then to be sent to enable the RLM reporting again.

V26 Firmware Family

The Beacon ID, for which the reporting of the RLM message is to be enabled, must be specified through the \$PTWSRLM,REGISTER,<beaconID> command. This latter command is therefore available on V26 firmware family only.

The SAR search/decode process ends if one of the following conditions is met:

- On demand via \$PTWSRLM,UNREGISTER,<beaconID>
- Valid RLM message received
- 30-min timeout exceeded



Warning: \$PTWSRLM message structure may be subjected to change to accommodate future enhancements needed to manage SAR/RLM messaging.

3.4.1.2. Query RLM Message Configuration

The current configuration for the reporting of the RLM NMEA output message can be queried using the command described in this section.

Synopsis:

```
$PTWSRLM,attrib,action[*CS]<CR><LF>
```

Example:

```
$PTWSRLM,STATUS,GET*11<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSRLM	Telit RLM Message
Attrib	STATUS	Parameter indicating the feature attribute to which the message applies: STATUS attribute only is supported
Action	GET	Action to be executed GET = Poll the current configuration for the RLM output message.

Table 9: PTWSRLM – Telit RLM Query Message Structure

3.4.2. Output Message

3.4.2.1. Configure RLM Message Response

Success:

```
$PTWSRLM,OK*7B
```

Error:

```
$PTWSRLM,ERROR,REGISTER*02
```

```
$PTWSRLM,ERROR*27
```

```
$PTWSCHECKSUM*0D
```

3.4.2.2. Query RLM Message Configuration Response

Success:

```
$PTWSRLM,STATUS,1*76<CR><LF> - If RLM reporting is enabled
```

```
$PTWSRLM,STATUS,0*77<CR><LF> - If RLM reporting is disabled
```

Error:

```
$PTWSRLM ERROR,STATUS*13
```

```
$PTWSRLM,ERROR*27
```

```
$PTWSCHECKSUM*0D
```

3.5. PTWSEPE – EPE Messages

PTWSEPE messages are used to control the reporting of the EPE (Estimate Positioning Error) output message.

3.5.1. Input Message

The reporting of the PTWSEPE output message can be enabled or disabled using the message described in this section.

Synopsis:

```
$PTWSEPE,action,<value>[*CS]<CR><LF>
```

Example:

```
$PTWSEPE,SET,ON*13<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSEPE	Telit EPE Message
Action	SET	Action to be executed SET = Configure the EPE message reporting according to the value to be specified in the next field
Value	ON	Parameter to enable/disable the reporting of the EPE message ON = Enable PTWSEPE output message OFF = Disable PTWSEPE output message

Table 10: PTWSEPE – Telit EPE Input Message Structure



Note: The reporting of the EPE output message is disabled by default at each module restart. \$PTWSEPE,SET,ON command has then to be sent to enable the EPE reporting again.

Warning: V13 Firmware Family

The allowed values for the <action> field are:

- ENABLE = Enable PTWSEPE output message
- DISABLE = Disable PTWSEPE output message



The <value> field is not used.

Example:

```
$PTWSEPE,ENABLE*7D<CR><LF>
```

```
$PTWSEPE,DISABLE*28<CR><LF>
```

3.5.2. Output Message

3.5.2.1. Input Message Response

Success:

```
$PTWSEPE,OK*78
```

Error:

```
$PTWSEPE,ERROR,SET*4A
```

```
$PTWSEPE,ERROR*24
```

```
$PTWSCHECKSUM*0D
```

```
$PTWSINVALID*51
```

3.5.2.2. EPE Reporting Message

The EPE (Estimate Positioning Error) is reported using the PTWSEPE output message described in this section.

Synopsis:

```
$PTWSEPE,<timestamp>,<EHPE>,<EVPE>*CS <CR><LF>
```

Example:

```
$PTWSEPE,132517.000,5.35,16.74*56<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSEPE	Telit EPE Message
Timestamp	132517.000	UTC time of the position error data hhmmss.sss (hours,minutes,seconds)
EHPE	5.35	Expected Horizontal Position Error One-sigma estimate of the horizontal error expressed in meters as a floating-point number with two digits of precision
EVPE	16.74	Expected Vertical Position Error One-sigma estimate of the vertical error, expressed in meters as a floating-point number with two digits of precision

Table 11: PTWSEPE – Telit EPE Reporting Output Message Structure

Note: V33 Firmware Family

The EPE reporting message reports the <EHPE> value only.

3.6. PTWSANT – Antenna Status Messages

PTWSANT messages are used to monitor the Antenna Status by performing antenna detection (in case of antenna modules only) and antenna sensing.

This command obsoletes \$PTWS,ANT. Therefore, this latter is still supported but its usage is now deprecated.



Note: Antenna detection and antenna sensing features may require a specific external circuitry to be performed.

Please contact Telit Technical Support for further information.

3.6.1. Input Message

PTWSANT input messages are used to query the antenna status and configure specific reporting modes.

Synopsis:

```
$PTWSANT,attrib,action[,mode][*CS]<CR><LF>
```

Examples:

```
$PTWSANT,STATUS,GET*19<CR><LF>
```

```
$PTWSANT,OUTPUT,SET,EVENT*66<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSANT	Telit Antenna Status Message
Attrib	STATUS	Parameter indicating the feature attribute to which the message applies: STATUS = Query the Antenna Status - Action field can be GET only OUTPUT = Configure a specific reporting mode for the Antenna Status - when the Action field is SET Poll the current reporting mode configuration - when the Action field is GET
Action	GET	GET = Query the Antenna Status - When the Attrib field is STATUS Poll the current reporting mode configuration - When the Attrib field is OUTPUT SET = Configure a specific reporting mode for the Antenna Status - When the Attrib field is OUTPUT.
Mode		Optional parameter indicating the specific reporting mode to be set - When the Attrib field is OUTPUT and the Action field is SET NONE = Polling Mode PERIODIC = Periodic Mode EVENT = Event Mode

Table 12: PTWSANT – Telit Antenna Status Input Message Structure

Note: Antenna Status Reporting Modes



- NONE: Polling mode - The output is provided only after a \$PTWSANT,STATUS,GET command
- PERIODIC: The output is provided along with the other NMEA sentences, once a second
- EVENT: The output is provided only if an antenna status change has been detected

3.6.2. Output Message

3.6.2.1. Antenna Status Reporting Message

The Antenna Status is reported through the message described in this section.

In case of antenna modules, antenna detection is performed first, to understand which, between the embedded internal antenna and an external active one, is used. In latter case, antenna sensing is performed to check the working status of the external antenna itself.

Synopsis:

```
$PTWSANT,STATUS,AntStatus*CS<CR><LF>
```

Examples:

```
$PTWSANT,STATUS,NORMAL*5C<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSANT	Telit Antenna Status Message
Attrib	STATUS	Parameter indicating the feature attribute to which the message applies: STATUS = Antenna Status Reporting
AntStatus	NORMAL	Antenna Status SHORT = Antenna Sense – Shorted NORMAL = Antenna Sense – Normal OPEN = Antenna Sense – Open/Detached INTERNAL = Antenna Detection – Internal Antenna UNKNOWN = Unknown status

Table 13: PTWSANT – Telit Antenna Status Reporting Message Structure

3.6.2.2. Antenna Status Reporting Mode Configuration Response

The current reporting mode configuration for Antenna Status is reported in the message described in this section.

Synopsis:

\$PTWSANT,OUTPUT,mode*CS

Examples:

\$PTWSANT,OUTPUT,EVENT*08

Field	Example	Description
Proprietary Address Field	PTWSANT	Telit Antenna Status Message
Attrib	OUTPUT	Parameter indicating the feature attribute to which the message applies: OUTPUT = Antenna Status Reporting Mode Configuration
Mode	EVENT	NONE = Polling Mode PERIODIC = Periodic Mode EVENT = Event Mode

Table 14: PTWSANT – Telit Antenna Status Reporting Mode Configuration Message Structure

Note:

V26 Firmware Family

Polling mode only is supported.

PTWSANT supports the antenna detection only – The supported statuses are INTERNAL and NORMAL. In this latter case, the NORMAL status is used just to indicate that an external antenna is being used, i.e. no antenna sensing is performed.

V33 Firmware Family

PTWSANT supports the antenna sensing only – The only supported statuses are SHORT, NORMAL and OPEN.

3.6.3. Antenna Status Error and Acknowledge Responses

The messages described in this section are reported to respond to an unsuccessful command or to respond to a configuration modification command.

Success

The following response applies only to \$PTSANT,OUTPUT,SET commands:

\$PTWSANT,OK*2B

Error

The following response applies only to \$PTWSANT,STATUS commands:

\$PTWSANT,ERROR,STATUS*17

The following responses apply only to \$PTWSANT,OUTPUT commands:

\$PTWSANT,ERROR,OUTPUT,SET*72

\$PTWSANT,ERROR,OUTPUT*1C

The following are responses for generic errors:

\$PTWSANT,ERROR*2F

\$PTWSNOSUPPORT*4E

\$PTWSCHECKSUM*0D

3.7. PTWSFENCE – Geofencing Messages

PTWSFENCE messages are used to control various aspects of Telit Geofencing feature.



Note: V26 Firmware Family

PTWSFENCE messages are available on V26-1.0.1-STD-5.7.12P1.1 and subsequent versions.

3.7.1. CONFIG Message Type

\$PTWSFENCE,CONFIG messages can be used to configure the fence regions to be used by the Geofencing feature.

3.7.1.1. Input Messages

3.7.1.1.1. Set Fence Parameters

Synopsis:

```
$PTWSFENCE,CONFIG,SET,<id>,<tolerance>,<shape>,<lat>,<long>,<rad>[*CS]<CR><LF>  
>
```

Example:

```
$PTWSFENCE,CONFIG,SET,1,1,CIRC,31.248672,121.589105,50*00<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSFENCE	Telit Geofencing Messages
Attrib	CONFIG	Parameter indicating the feature attribute to which the message applies
Action	SET	Action to be executed SET = Configure settings for a specific fence ID
ID	1	ID of the fence region to be configured 1 to 6
Tolerance	1	Confidence level to be taken into account for geofence status calculation 0 = No confidence required 1 = 68% 2 = 95%, 3 = 99.7%
Shape	CIRC	Shape of the fence – CIRC, circular fences supported only
Lat	31.248672	Latitude in form of ±31.248672 (plus sign can be omitted)
Long	121.589105	Longitude in form of ±121.589105 (plus sign can be omitted)
Rad	50	Radius in meters Min value = 10 m Max value = 100000 m

Table 15: PTWSFENCE,CONFIG,SET – Set Fence Parameters

3.7.1.1.2. Query Fence Parameters

Synopsis:

```
$PTWSFENCE,CONFIG,GET[,<id>][*CS]<CR><LF>
```

Example:

```
$PTWSFENCE,CONFIG,GET,1*0A<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSFENCE	Telit Geofencing Messages
Attrib	CONFIG	Parameter indicating the feature attribute to which the message applies

Field	Example	Description
Action	GET	Action to be executed GET = Query the current settings for a specific fence ID
ID	1	Optional Parameter indicating the ID of the fence whose configuration needs to be polled 1 to 6 If no fence ID is specified, multiple responses are relayed, one for each configured fence

Table 16: PTWSFENCE,CONFIG,GET – Query Fence Parameters



Note: When a query is performed for an unconfigured fence ID, a \$PTWSFENCE,ERROR response is returned.

3.7.1.2. Output Messages

3.7.1.2.1. Set Fence Parameters Response

Success:

\$PTWSFENCE,OK*63

Error:

\$PTWSFENCE,ERROR,CONFIG,SET*77

\$PTWSFENCE,ERROR,CONFIG*19

\$PTWSFENCE,ERROR*3F

\$PTWSNOSUPPORT*4E

\$PTWSCHECKSUM*0D

\$PTWSINVALID*51

3.7.1.2.2. Query Fence Parameters Response

Success:

- a. Case I – Fence ID is specified in the query message

\$PTWSFENCE,CONFIG,<id>,<tolerance>,CIRC,<lat>,<long>,<rad>[*CS] <CR><LF>

Example:

\$PTWSFENCE,CONFIG,1,1, CIRC,31.248672,121.589105,50*6E<CR><LF>

- b. Case II – No Fence ID is specified in the query message

```
$PTWSFENCE,CONFIG,<n>,<id>,<tolerance>,CIRC,<lat>,<long>,<rad>[*CS]<CR><LF>
```

Where, **n** is the number of configured fences

Example:

```
$PTWSFENCE,CONFIG,3,1,1,CIRC,31.248672,121.589105,50*51<CR><LF>
```

```
$PTWSFENCE,CONFIG,3,2,0,CIRC,31.248672,-10.589105,16*4F<CR><LF>
```

```
$PTWSFENCE,CONFIG,3,3,2,CIRC,31.248672,112.589105,66*55<CR><LF>
```

Error:

```
$PTWSFENCE,ERROR,CONFIG,GET*63
```

```
$PTWSFENCE,ERROR,CONFIG*19
```

```
$PTWSFENCE,ERROR*3F
```

```
$PTWSNOSUPPORT*4E
```

```
$PTWSCHECKSUM*0D
```

```
$PTWSINVALID*51
```

3.7.2. STATUS Message Type

\$PTWSFENCE,STATUS messages can be used to enable/disable the fence regions to be used by the Geofencing feature and poll the status for each configured area.

3.7.2.1. Input Messages

3.7.2.1.1. Enable/Disable Fence

Synopsis:

```
$PTWSFENCE,STATUS,SET,<id>,<ON|OFF|1|0>[*CS]<CR><LF>
```

Example:

```
$PTWSFENCE,STATUS,SET,1,1*1D<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSFENCE	Telit Geofencing Messages
Attrib	STATUS	Parameter indicating the feature attribute to which the message applies
Action	SET	Action to be executed SET = Configure settings for a specific fence ID
ID	1	ID of the fence region to be enabled/disabled 1 to 6
Activation	1	Activation state for the specified ID 0/OFF = Disabled 1/ON = Enabled

Table 17: PTWSFENCE,STATUS,SET – Enable/Disable Fence

3.7.2.1.2. Poll Fence Status

Synopsis:

```
$PTWSFENCE,STATUS,GET[,<id>][*CS]<CR><LF>
```

Example:

```
$PTWSFENCE,STATUS,GET,1*14<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSFENCE	Telit Geofencing Messages
Attrib	STATUS	Parameter indicating the feature attribute to which the message applies
Action	GET	Action to be executed GET = Poll the current status for a specific fence ID
ID	1	Optional Parameter indicating the ID of the fence whose status needs to be polled 1 to 6 If no fence ID is specified, a single, variable length message is relayed where only the status of enabled geofences is reported

Table 18: PTWSFENCE,STATUS,GET – Poll Fence Status



Note: When a query is performed for an unconfigured fence ID, a \$PTWSFENCE,ERROR response is returned.

3.7.2.2. Output Messages

3.7.2.2.1. Enable/Disable Fence Response

Success:

\$PTWSFENCE,OK*63

Error:

\$PTWSFENCE,ERROR,STATUS,SET*69

\$PTWSFENCE,ERROR,STATUS*07

\$PTWSFENCE,ERROR*3F

\$PTWSCHECKSUM*0D

\$PTWSINVALID*51

3.7.2.2.2. Poll Fence Status Response

Success:

- a. Case I – Fence ID is specified in the query message

\$PTWSFENCE,STATUS,<timestamp>,<date>,<id>,<1|0>,<status>[*CS] <CR><LF>

Example:

\$PTWSFENCE,STATUS,110415.000,300718,1,1,IN*4B<CR><LF>

Field	Example	Description
Proprietary Address Field	PTWSFENCE	Telit Geofencing Messages
Attrib	STATUS	Parameter indicating the feature attribute to which the message applies
Timestamp	110415.000	UTC Time of the position that was used to determine the status – hhmmss.sss format
Date	300718	Date – DDMMYY format
ID	1	ID of the fence region being polled 1 to 6
Activation	1	Activation state for the specified ID 0 = Disabled 1 = Enabled

Field	Example	Description
Status	IN	Current Position Status IN = The position and its uncertainty circle are completely inside the geofence OUT = The position and its uncertainty circle are completely outside the geofence ON = The position and its uncertainty circle intersect the geofence boundary UNK = The fence is turned off, or the position is invalid (module is not navigating)

Table 19: PTWSFENCE,STATUS – Poll Fence Status Response

- b. Case II – No Fence ID is specified in the query message

```
$PTWSFENCE,STATUS,<hhmmss.sss>,<date>,<n>,<summary>,<id1>,<status1>,<id2>,<status2>,...<idN>,<statusN>[*CS]
```

Where:

n is the number of enabled fences

summary is the OR'ed value of the status of all active/enabled geofences

Example:

```
$PTWSFENCE,STATUS,110415.000,300718,2,IN,1,IN,4,OUT*19
```

Error:

```
$PTWSFENCE,ERROR,STATUS,GET*7D
```

```
$PTWSFENCE,ERROR,STATUS*07
```

```
$PTWSFENCE,ERROR*3F
```

```
$PTWSCHECKSUM*0D
```

```
$PTWSINVALID*51
```

3.8. PTWSRESET - Reset Message

PTWSRESET message enables the reset of the GNSS receiver.

3.8.1. Input Message

Synopsis:

```
$PTWSRESET,<type>[*CS]<CR><LF>
```

Example:

```
$PTWSRESET,HOT*2A<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWSRESET	Telit Reset Message
Type	HOT	HOT = Hot reset WARM = Warm reset COLD = Cold reset FACTORY = Factory reset

Table 20: PTWSRESET – Reset Message Structure

3.8.2. Output Message

Success:

\$PTWSRESET,OK*7D

Error:

\$PTWSRESET,ERROR*21

PRELIMINARY

4. APPENDIX A – TELIT LEGACY NMEA MESSAGES

4.1. Telit Legacy NMEA Messages Format

This appendix documents Telit legacy NMEA commands that were supported by Telit V13 firmware family (up to version V13-2.2.3-STD-3.8.16), that comply with NMEA 0183, to further enhance the control of GNSS receivers and expose more functionalities.

Telit legacy proprietary NMEA messages start with the “\$” character, which is then followed by the proprietary address field string that uses the Manufacturer’s Mnemonic Code registered by Telit with the NMEA, which is “TWS”. Thus; the Telit proprietary address field is of the form:

\$PTWS,xxx[x...]

Where *xxx..* represents an alphanumeric message identifier having a minimum of three characters and being all uppercase.

Checksum fields are included in all Telit proprietary NMEA output messages, and letters representing hexadecimal digits are uppercase. Checksum fields are optional for Telit proprietary NMEA input commands.

The messages end with Carriage Return (CR) and Line Feed (LF) characters.

Telit Legacy NMEA Messages are now superseded by the new Telit NMEA message set and are no longer maintained.

Proprietary Address Field	Message Identifier	Description
\$PTWS	VERSION	Telit software version message
	ANT	Antenna status message
	JAM	Jamming detection status
	LNA	LNA Gain message
	ODO	Odometer message

Table 21: Telit Legacy NMEA Messages

4.1.1. Telit Legacy NMEA Messages Applicability Table

		LEGACY				
		\$PTWS,VERSION	\$PTWS,ANT	\$PTWS,JAM	\$PTWS,LNA	\$PTWS,ODO
V13	SL869-V2	✓	✓	✓	✓	✓
	SL869L-V2	✓	✓	✓	✓	✓
	SL871	✓	✓	✓	✓	✓
	SL871L	✓	✓	✓	✓	✓
	SE868-A	✓	✓	✓	✓	✓
	SE868K3-A	✓	✓	✓	✓	✓
	SE868K3-AL	✓	✓	✓	✓	✓
	SE878K3-A	✓	✓	✓	✓	✓
	SC872-A	✓	✓	✓	✓	✓
	SC874-A	✓	✓	✓	✓	✓
V26	SE868-V3	*	*	*	*	*
	SE873	*	*	*	*	*
	SE873Q5	*	*	*	*	*
	SL876Q5-A	*	*	*	*	*
V33	SL869-V3	*	*	*	*	*
	SL869-ADR	*	*	*	*	*

×	Not Supported
✓	Supported

Table 22: Telit Legacy NMEA Messages Applicability Table

4.2. PTWS,VERSION – Telit Software Version Message

The Telit Software Version can be obtained using the input message described in this section.

This message is now obsolete by the new PTWSVER message.

4.2.1. Input Message

Query Telit software version: This message polls the version string of Telit software.

Synopsis:

```
$PTWS,VERSION,GET
```

Example:

```
$PTWS,VERSION,GET*0C<CR><LF>
```

4.2.2. Output Message

Telit Software Version string output: This message outputs the version string of Telit software.

Synopsis:

```
$PTWS,VERSION,VAL,VerString
```

Example:

```
$PTWS,VERSION,VAL,v13-2.2.0-STD-3.8.13-N96-B2*3F<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWS	Telit NMEA Talker ID
Message ID	VERSION	Software Version Message
Tag1	VAL	VAL = Version string value reported in the next field
VerString	v13-2.2.0-STD-3.8.13-N96-B2	Telit FW version string

Table 23: PTWS,VERSION – Telit Software Version Output Message Structure

4.3. PTWS,ANT – Antenna Status Message

Antenna Status can be obtained using the input message described in this section.

This message is now obsolete by the new PTWSANT message.

4.3.1. Input Message

Query Antenna Status: This message queries the status of the antenna circuit on a module.

Synopsis:

\$PTWS,ANT,STATUS

Example:

\$PTWS,ANT,STATUS*4F<CR><LF>

4.3.2. Output Message

Antenna Status output message: This message outputs the current antenna status.

Synopsis:

\$PTWS,ANT,STATUS,VAL,AntStatus,AntStatusCode

Example:

\$PTWS,ANT,STATUS,VAL,OK,1*0D<CR><LF>

Field	Example	Description
Proprietary Address Field	PTWS	Telit NMEA Talker ID
Message ID	ANT	Antenna Status Message
Tag1	STATUS	STATUS = Antenna Status reported in this message
Tag2	VAL	VAL = Antenna Status value reported in the next field
AntennaStatus	OK	SHORT = Antenna is Shorted OK = Antenna Status is Normal OPEN = Antenna is Detached UNKNOWN = Unknown status
AntennaStatusCode	1	0 = Antenna Sense → SHORT 1 = Antenna Sense → OK 2 = Antenna Sense → OPEN 3 – 255 = Any value returned by the Antenna sense function other than 0, 1, and 2

Table 24: PTWS,ANT – Antenna Status Output Message Structure

4.4. PTWS,JAM – Jamming Detection Status Message

Jamming detection status can be obtained using the input message described in this section.

4.4.1. Input Message

Query Jamming detection status: This message queries the status of the Jamming detection.

Synopsis:

```
$PTWS,JAM,STATUS
```

Example:

```
$PTWS,JAM,STATUS*52<CR><LF>
```

4.4.2. Output Message

Jamming Detection Message: This message outputs the Jamming detection results.

Synopsis:

```
$PTWS,JAM,SIGNAL,VAL,INDEX,JamIndex,FREQ,JamFreq
```

Examples:

1. Jamming Detected

```
$PTWS,JAM,SIGNAL,VAL,INDEX,8,FREQ,1574.996338*6E<CR><LF>
```

2. No Jamming Detected

```
$PTWS,JAM,SIGNAL,NONE*7E<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWS	Telit NMEA Talker ID
Message ID	JAM	Jamming Detection Status Message
Tag1	SIGNAL	SIGNAL = Jamming signal information reported in the next field
Tag2	VAL	NONE = No jamming frequency is detected If this field = NONE, the rest field of this message will be voided. VAL = One or more jamming signal frequency detected
Tag3	INDEX	INDEX = Index of the jamming frequencies reported in the next field
JamFreq	1574.996338	The corresponding jamming frequency that was detected (at the JamIndex slot). Unit: MHz Precision: six decimal positions that gives a resolution of 1 Hz

Table 25: PTWS,JAM – Jamming Detection Status Output Message Structure

4.5. PTWS,LNA – LNA Gain Message

LNA Gain settings can be controlled using the messages described in this section.

This message is now obsolete by the new PTWSLNA message.

4.5.1. Input Messages

Synopsis:

```
$PTWS,LNA,Tag1,Tag2[,LNAUserValue]
```

Field	Example	Description
Proprietary Address Field	PTWS	Telit NMEA Talker ID
Message ID	LNA	LNA Gain Message
Tag1	GAIN	GAIN = LNA Gain specific message
Tag 2	SET	GET = Poll the current LNA Gain value - The next field of this message must be omitted SET = Configure the LNA Gain to a specific setting to be specified in the next field
LNAUserValue	1	Only applicable if Tag2 = "SET" 1 = LNA Gain High 0 = LNA Gain Low

Table 26: PTWS,LNA – LNA Gain Input Message Structure

4.5.1.1. Set LNA Gain

This command is used to configure the LNA Gain setting.

Synopsis:

```
$PTWS,LNA,GAIN,SET,LNAUserValue
```

Example:

```
$PTWS,LNA,GAIN,SET,1*31<CR><LF>
```

4.5.1.2. Query LNA Gain

This command is used to query the current LNA Gain setting.

Synopsis:

```
$PTWS,LNA,GAIN,GET
```

Example:

```
$PTWS,LNA,GAIN,GET*38<CR><LF>
```

4.5.2. Output Message

The LNA Gain output message is used to report the current the LNA gain setting.

Synopsis:

```
$PTWS,LNA,GAIN,VAL,DEF,LNADefault,USR,LNAUser
```

Example:

```
$PTWS,LNA,GAIN,VAL,DEF,1,USR,0*27<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWS	Telit NMEA Talker ID
Message ID	LNA	LNA Gain Message
Tag1	GAIN	GAIN = LNA Gain specific message
Tag 2	VAL	VAL = This message reports LNA Gain setting information
Tag 3	DEF	DEF = Default LNA Gain setting reported in the next field
LNADefault	1	1 = Default LNA gain value HIGH 0 = Default LNA gain value LOW
Tag 4	USR	USR = LNA Gain setting configured by the User and reported in the next field
LNAUser	0	1 = Default LNA gain value HIGH 0 = Default LNA gain value LOW 1 = Not specified (the default gain value is used)

Table 27: PTWS,LNA – LNA Gain Output Message Structure

4.6. PTWS,ODO – ODO Messages

Odometer specific messages can be controlled through the input messages described in this section.

4.6.1. Input Messages

4.6.1.1. Start ODO Count

This command is used to reset the ODO count value to zero and restart the odometer count.

Synopsis:

```
$PTWS,ODO,START
```

Example:

```
$PTWS,ODO,START*04<CR><LF>
```

4.6.1.2. Stop ODO Count

This command is used to stop the ODO count.

Synopsis:

```
$PTWS,ODO,STOP
```

Example:

```
$PTWS,ODO,STOP*5C<CR><LF>
```

4.6.1.3. Query ODO Count

This command queries the current ODO value.

Use this command to poll ODO value if the ODO output has been turned off.

Synopsis:

```
$PTWS,ODO,GET
```

Example:

```
$PTWS,ODO,GET*12<CR><LF>
```

4.6.1.4. Turn ODO Output Messages On

This command turns the ODO output message on. The receiver will output the current ODO count through the \$PTWS,ODO,VALUE output message.

Synopsis:

```
$PTWS,ODO,OUTPUT,ON
```

Example:

```
$PTWS,ODO,OUTPUT,ON*76<CR><LF>
```

4.6.1.5. Turn ODO Output Messages Off

This command turns the ODO output message off. The receiver will stop reporting the current ODO count.

Synopsis:

```
$PTWS,ODO,OUTPUT,OFF
```

Example:

```
$PTWS,ODO,OUTPUT,OFF*38<CR><LF>
```

4.6.2. Output Message

ODO Output message: This message outputs the current ODO count at the output rate of position fix.

Synopsis:

```
$PTWS,ODO,VALUE,dddd.dd
```

Examples:

```
$PTWS,ODO,VALUE,9281.30*0C<CR><LF>
```

Field	Example	Description
Proprietary Address Field	PTWS	Telit NMEA Talker ID
Message ID	ODO	ODO Message
Tag1	VALUE	VALUE = Current ODO value reported in the next field
ODO Count Value	9281.30	dddd.dd (meters) Current ODO count value

Table 28: PTWS,ODO – ODO Output Message Structure

Note: The ODO output is turned OFF by default at each reset. The ODO output can be enabled again using the “\$PTWS,ODO,OUTPUT,ON” command.

Since after each restart the ODO value is undefined, the “\$PTWS,ODO,START” command must be sent to reset the ODO count value.

5. PRODUCT AND SAFETY INFORMATION

5.1. Copyrights and Other Notices

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

Although reasonable efforts have been made to ensure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from the use of the information contained herein. The information contained in this document has been carefully checked and is believed to be reliable. Telit reserves the right to make changes to any of the products described herein, to revise it and to make changes from time to time without any obligation to notify anyone of such revisions or changes. Telit does not assume any liability arising from the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

This document may contain references or information about Telit's products (machines and programs), or services that are not announced in your country. Such references or information do not necessarily mean that Telit intends to announce such Telit products, programming, or services in your country.

5.1.1. Copyrights

This instruction manual and the Telit products described herein may include or describe Telit copyrighted material, such as computer programs stored in semiconductor memories or other media. The laws in Italy and in other countries reserve to Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute, and make derivative works of the copyrighted material. Accordingly, any of Telit's or its licensors' copyrighted material contained herein or described in this instruction manual, shall not be copied, reproduced, distributed, merged, or modified in any way without the express written permission of the owner. Furthermore, the purchase of Telit products shall not be deemed to grant in any way, neither directly nor by implication, or estoppel, any license.

5.1.2. Computer Software Copyrights

Telit and the Third Party supplied Software (SW) products, described in this instruction manual may include Telit's and other Third Party's copyrighted computer programs stored in semiconductor memories or other media. The laws in Italy and in other countries reserve to Telit and other Third Party, SW exclusive rights for copyrighted

computer programs, including – but not limited to - the exclusive right to copy or reproduce in any form the copyrighted products. Accordingly, any copyrighted computer programs contained in Telit’s products described in this instruction manual shall not be copied (reverse engineered) or reproduced in any manner without the express written permission of the copyright owner, being Telit or the Third Party software supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or in any other way, any license under the copyrights, patents or patent applications of Telit or other Third Party supplied SW, except for the normal non-exclusive, royalty free license to use arising by operation of law in the sale of a product.

5.2. Usage and Disclosure Restrictions

5.2.1. License Agreements

The software described in this document is owned by Telit and its licensors. It is furnished by express license agreement only and shall be used exclusively in accordance with the terms of such agreement.

5.2.2. Copyrighted Materials

The Software and the documentation are copyrighted materials. Making unauthorized copies is prohibited by the law. The software or the documentation shall not be reproduced, transmitted, transcribed, even partially, nor stored in a retrieval system, nor translated into any language or computer language, in any form or by any means, without prior written permission of Telit.

5.2.3. High Risk Materials

Components, units, or third-party goods used in the making of the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: operations of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (“High Risk Activities”). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness eligibility for such High-Risk Activities.

5.2.4. Trademarks

TELIT and the Stylized T-Logo are registered in the Trademark Office. All other product or service names are property of their respective owners.

5.2.5. Third Party Rights

The software may include Third Party's software Rights. In this case the user agrees to comply with all terms and conditions imposed in respect of such separate software rights. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License, shall apply to the Third-Party Rights software as well.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESSED OR IMPLIED FROM ANY THIRD PARTY REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODES"), AND THE USE OF ANY OR ALL OTHER CODES IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODES MUST BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST OF PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODES OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

5.2.6. Waiver of Liability

IN NO EVENT WILL TELIT AND ITS AFFILIATES BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY INDIRECT DAMAGE OF ANY KIND WHATSOEVER, INCLUDING BUT NOT LIMITED TO REIMBURSEMENT OF COSTS, COMPENSATION OF ANY DAMAGE, LOSS OF PRODUCTION, LOSS OF PROFIT, LOSS OF USE, LOSS OF BUSINESS, LOSS OF DATA OR REVENUE, WHETHER OR NOT THE POSSIBILITY OF SUCH DAMAGES COULD HAVE BEEN REASONABLY FORESEEN, CONNECTED IN ANY WAY TO THE USE OF THE PRODUCT/S OR TO THE INFORMATION CONTAINED IN THE PRESENT DOCUMENTATION, EVEN IF TELIT AND/OR ITS AFFILIATES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

5.3. Safety Recommendations

Make sure the use of this product is allowed in your country and in the environment required. The use of this product may be dangerous and has to be avoided in areas where:

- it can interfere with other electronic devices, particularly in environments such as hospitals, airports, aircrafts, etc.
- there is a risk of explosion such as gasoline stations, oil refineries, etc. It is the responsibility of the user to enforce the country regulation and the specific environment regulation.

Do not disassemble the product; any mark of tampering will compromise the warranty validity. We recommend following the instructions of the hardware user guides for correct wiring of the product. The product has to be supplied with a stabilized voltage source and the wiring has to be conformed to the security and fire prevention regulations. The product has to be handled with care, avoiding any contact with the pins because electrostatic discharges may damage the product itself. Same cautions have to be taken for the SIM, checking carefully the instruction for its use. Do not insert or remove the SIM when the product is in power saving mode.

The system integrator is responsible for the functioning of the final product. Therefore, the external components of the module, as well as any project or installation issue, have to be handled with care. Any interference may cause the risk of disturbing the GSM network or external devices or having an impact on the security system. Should there be any doubt, please refer to the technical documentation and the regulations in force. Every module has to be equipped with a proper antenna with specific characteristics. The antenna has to be installed carefully in order to avoid any interference with other electronic devices and has to guarantee a minimum distance from the body (20 cm). In case this requirement cannot be satisfied, the system integrator has to assess the final product against the SAR regulation.

The equipment is intended to be installed in a restricted area location.

The equipment must be supplied by an external specific limited power source in compliance with the standard EN 62368-1:2014.

The European Community provides some Directives for the electronic equipment introduced on the market. All of the relevant information is available on the European Community website:

https://ec.europa.eu/growth/sectors/electrical-engineering_en

6. GLOSSARY


ASCII	American Standard Code for Information Interchange
BE	Broadcast Ephemeris
DGPS	Differential Global Positioning System
DOP	Dilution of Precision
NMEA	National Marine Electronics Association
PRN	Pseudo-Random Noise
SRAM	Static Random-Access Memory
UTC	Co-ordinated Universal Time

PRELIMINARY

7. DOCUMENT HISTORY

Revision	Date	Changes
5	2021-07-26	Removed PTWSCPU Messages Updated document to new Telit standard template
4	2021-05-11	Updated PTWSMODE Messages
3	2020-06-26	Added Telit Legacy NMEA appendix Added support to V50 Firmware Family and new supported PTWS Messages
2	2019-11-13	Added PTWSFENCE support for V13 Firmware Family Updated Telit Technical Support access link
1	2019-08-08	Added support to V33 Firmware Family Added PTWSFENCE Commands and Messages Added PTWSRLM support on V26 FW family
0	2018-04-12	First issue

From Mod.0809 rev.3

A network diagram consisting of various colored nodes (blue, orange, yellow, green, black, grey) connected by thin grey lines, forming a complex web. The nodes are scattered across the page, with a higher concentration in the top-left and bottom-right corners.

Connect to our site and contact our
technical support team for any question

www.telit.com

The Telit logo features a stylized orange and yellow mark above the word "Telit" in a bold, dark blue sans-serif font.

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2021, Telit