

HE Windows CE 6.0 User Guide

1VV0300927 rev. 1 – 2011-11-03



Disclaimer

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

Notice

While reasonable efforts have been made to assure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. The information in this document has been carefully checked and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies or omissions. Telit reserves the right to make changes to any products described herein and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Telit does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

It is possible that this publication may contain references to, or information about Telit products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Telit intends to announce such Telit products, programming, or services in your country.

Copyrights

This instruction manual and the Telit products described in this instruction manual may be, include or describe copyrighted Telit material, such as computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Telit and its licensors contained herein or in the Telit products described in this instruction manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Telit. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit, as arises by operation of law in the sale of a product.

Computer Software Copyrights

The Telit and 3rd Party supplied Software (SW) products described in this instruction manual may include copyrighted Telit and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and other 3rd Party supplied SW certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Telit or other 3rd Party supplied SW computer programs contained in the Telit products described in this instruction manual may not be copied (reverse engineered) or reproduced in any manner



without the express written permission of Telit or the 3rd Party SW supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit or other 3rd Party supplied SW, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Usage and Disclosure Restrictions

License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

Trademarks

TELIT and the Stylized T Logo are registered in Trademark Office. All other product or service names are the property of their respective owners.

Copyright © Telit Communications S.p.A. 2011.



Applicable Products

Product
HE863-EUx
HE910

Version
U05.00.00



Contents

1.	<i>Introduction</i>	6
1.1.	Scope	6
1.2.	Audience	6
1.3.	Contact Information, Support	6
1.4.	Product Overview	6
1.5.	Document Organization	7
1.6.	Text Conventions	7
1.7.	Document history	7
2.	<i>System setup</i>	8
2.1.	General Overview	9
2.2.	Pre-requirements	11
2.3.	Adding HE support in the OS image using the binary	13
3.	<i>Using HE modules</i>	15
3.1.	The serial API	15
3.1.1.	CreateFile	15
3.1.2.	WriteFile	16
3.1.3.	ReadFile	18
3.1.4.	CloseHandle	19
3.2.	PPP Connection	20



1. Introduction

1.1. Scope

This user guide serves the following purpose:

Provides details about the HE Telit Modules.

Describes how to compile, include in a kernel image and use the HE Windows CE 6.0 driver for a headless system.

1.2. Audience

This User Guide is intended for software developers who develop applications using HE modem.

1.3. Contact Information, Support

For general contact, technical support, to report documentation errors and to order manuals, contact Telit's Technical Support Center (TTSC) at:

TS-EMEA@telit.com

TS-NORTHAMERICA@telit.com

TS-LATINAMERICA@telit.com

TS-APAC@telit.com

Alternatively, use:

<http://www.telit.com/en/products/technical-support-center/contact.php>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

To register for product news and announcements or for product questions contact Telit Technical Support Center (TTSC).

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

1.4. Product Overview

HE modules contain a fully featured HSDPA modem and UMTS/GSM/GPRS module, compatible with the other Telit GSM/GPRS modules.



1.5. Document Organization

This manual contains the following chapters:

- “Chapter 1, Introduction” provides a scope for this manual, target audience, technical contact information, and text conventions.
- “Chapter 2, System setup” describes how to add the HE USB driver in a Windows CE 6.0 image.
- “Chapter 3, Device Driver” describes how to use the HE driver for interacting with the HE modem.

1.6. Text Conventions

This section lists the paragraph and font styles used for the various types of information presented in this user guide.



Danger – This information **MUST** be followed or catastrophic equipment failure or bodily injury may occur.



Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.

Format	Content
Arial monospaced	Windows CE shell commands at command prompt, filesystem paths, source code examples and menu items

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.

1.7. Document history

Revision	Date	Changes
ISSUE #0	2011-05-03	First Release
ISSUE #1	2011-11-03	Second Release, update for HE910 module



2. System setup


In this chapter it is described the general architecture of a Windows CE system with attached an HE module, the requirements needed for using the HE and how to integrate the HE device driver in a Windows CE image. The following table shows the reference platforms which this guide has been tested for:

Device	Operating System
AT92SAM9263-EK	Windows CE 6.0 R3



2.1. General Overview

In the following image it is shown a diagram of USB software/hardware interaction in a Windows CE system with a HE module attached:



From the bottom of the stack:

- Telit modem connected through an USB port.
- USB: serial bus for interfacing devices to a host computer.
- USB Host Controller: a combination of hardware and software that is responsible for the following actions:
 - Detecting the insertion and removal of USB devices
 - Managing flow control between the host and USB devices
 - Managing data flow between the host and USB devices
 - Collecting status
 - Providing power to attached USB devices



- USB HE Device Driver: piece of software that allows the HE to be seen by the user application as connected through serial ports rather than USB port.
- Virtual serial ports (COM6, COM7, COM8 and COM9): serial ports created by the HE device driver for accessing the modem; they can be used as real physical serial ports.

HE:

- COM6: Telit HSDPA modem port, used for normal modem/application interaction (e.g. AT commands sending, data connection...).
 - COM7: Telit on COM7.
 - COM8: Telit on COM8.
 - COM9: Telit Auxiliary, used for debugging purposes.
- User Application: piece of software written by the customer that uses HE features through virtual serial ports.




2.2. Pre-requirements

For correctly building a Windows CE 6.0 image with the HE USB driver on a headless system the following pre-requirements need to be satisfied:

- Microsoft Visual Studio 2005, with Platform Builder for CE 6.0.
- An OS design with the USB host controller supported.
- Knowledge of Windows CE OS image and subproject creation.

Please note that there are different ways for enabling the USB host controller and they depend on the considered hardware. In our test platform the USB host controller can be enabled during the initial image creation wizard (in the Core OS Services step), as the following image suggests:



or it can be added using the catalog as the following image suggests:






2.3. Adding HE support in the OS image using the binary

For adding HE support in the OS image, having the binary *CDCACM.dll*, follow these steps:

- In the Solution Explore, under the folder Parameter Files open the folders called as your BSP name and open the file project.bib. Under the Modules section add the following line:

CDCACM.dll \$(_PROJECTROOT)\ [path_where_the_dll_is] \CDCACM.dll NK SHK


paying attention to change the path to the correct one (the place where the dll can be found).



- Open the file project.reg and, at its end, paste the content of the file CDCACMDriver_HEXXX.reg where XXX is the module that you are going to use.



HE Windows CE 6.0 Software User Guide 1VV0300927 rev.1 – 2011-11-03



- Recreate the OS image.

Now you should have the HE driver integrated into your OS image. Start your system with the just created OS image and, after the boot, plug the device into your target: if the connection succeeds you should see the four virtual serial ports described in paragraph 2.1 ready to be used.



3. Using HE modules

In this chapter it is explained how to programmatically use HE modules (via the serial port API) and how to setup a PPP connection.

3.1. The serial API

Application can interact with the HE through the virtual serial ports created by the driver (for example COM6). Windows CE 6.0 has a complete API for dealing with serial ports; following you can find all the most important calls with code examples. Further information can be found in Microsoft Developer Network.

3.1.1. CreateFile

This function creates, opens, or truncates a file, COM port, device, service, or console. It returns a handle to access the object.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```
HANDLE CreateFile(  
    LPCTSTR lpFileName,  
    DWORD dwDesiredAccess,  
    DWORD dwShareMode,  
    LPSECURITY_ATTRIBUTES lpSecurityAttributes,  
    DWORD dwCreationDisposition,  
    DWORD dwFlagsAndAttributes,  
    HANDLE hTemplateFile  
);
```

Parameters:

lpFileName



[in] Pointer to a null-terminated string that specifies the name of the object, such as file, COM port, disk device, or console, to create or open.

dwDesiredAccess

[in] Type of access to the object. An application can obtain read-only access, write-only access, read/write access, or device-query access.

dwShareMode

[in] Share mode for the object. If this parameter is set to zero, the object cannot be shared. Subsequent open operations on the object fail until the handle is closed. This parameter can be set to one or more values.

lpSecurityAttributes

[in] Not used.

dwCreationDisposition

[in] Action to take on files that exist, and which action to take when files do not exist.

dwFlagsAndAttributes

[in] File attributes and flags for the file.

hTemplateFile

[in] Ignored; as a result, this function does not copy the extended attributes to the new file.

Return Value:

An open handle to the specified file indicates success. If the specified file exists before the function call and dwCreationDisposition is set to CREATE_ALWAYS or OPEN_ALWAYS, a call to GetLastError returns ERROR_ALREADY_EXISTS, even though the function has succeeded. If the file does not exist before the call, GetLastError returns zero. INVALID_HANDLE_VALUE indicates failure. To get extended error information, call GetLastError.

Example:

```
HANDLE hModem;
hModem = CreateFile( TEXT("COM6:"),
    GENERIC_READ | GENERIC_WRITE,
    0,
    NULL,
    OPEN_EXISTING,
    0,
    NULL);
if (hModem == INVALID_HANDLE_VALUE)
    // error opening port; abort
```

Further information on the parameters' values can be found at <http://msdn.microsoft.com/en-us/library/aa914735.aspx>.

3.1.2. WriteFile

This function writes data to a file. WriteFile starts writing data to the file at the position indicated by the file pointer.



Header:

winbase.h

Library:

coredll.lib

Syntax:

```
BOOL WriteFile(  
    HANDLE hFile,  
    LPCVOID lpBuffer,  
    DWORD nNumberOfBytesToWrite,  
    LPDWORD lpNumberOfBytesWritten,  
    LPOVERLAPPED lpOverlapped  
);
```

Parameters:

hFile

[in] Handle to the file to be written to (returned by CreateFile). The file handle must have been created with GENERIC_WRITE access to the file.

lpBuffer

[in] Pointer to the buffer containing the data to write to the file.

nNumberOfBytesToWrite

[in] Number of bytes to write to the file.

lpNumberOfBytesWritten

[out] Pointer to the number of bytes written by this function call. **WriteFile** sets this value to zero before taking action or checking errors.

lpOverlapped

[in] Unsupported; set to NULL.

Return Value:

Nonzero indicates success. Zero indicates failure.

Example:



```
#define BYTES_TO_BE_WRITTEN 4
char atTest[]="AT\r\n";
DWORD written;
HANDLE hModem;
hModem = CreateFile( TEXT("COM6:"),
    GENERIC_READ | GENERIC_WRITE,
    0,
    NULL,
    OPEN_EXISTING,
    0,
    NULL);
if (hModem == INVALID_HANDLE_VALUE)
    // error opening port; abort
if (!WriteFile(hModem, atTest, BYTES_TO_BE_WRITTEN, &written, NULL))
    // error writing bytes; abort
```

Further information on the parameters' values can be found at <http://msdn.microsoft.com/en-us/library/ms892380.aspx>.

3.1.3. ReadFile

This function reads data from a file, starting at the position indicated by the file pointer.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```
BOOL ReadFile(
    HANDLE hFile,
    LPVOID lpBuffer,
    DWORD nNumberOfBytesToRead,
    LPDWORD lpNumberOfBytesRead,
    LPOVERLAPPED lpOverlapped
);
```

Parameters:

hFile

[in] Handle to the file to be read. The file handle must have been created with GENERIC_READ access to the file. This parameter cannot be a socket handle.



lpBuffer

[out] Pointer to the buffer that receives the data read from the file.

nNumberOfBytesToRead

[in] Number of bytes to be read from the file.

lpNumberOfBytesRead

[out] Pointer to the number of bytes read. **ReadFile** sets this value to zero before doing taking action or checking errors.

lpOverlapped

[in] Unsupported; set to NULL.

Return Value:

Nonzero indicates success. Zero indicates failure.

Example:

```
#define BYTES_TO_BE_WRITTEN 4
#define BYTES_TO_BE_READ 9
char atTest[]="AT\r\n";
char atAnswer[10];
DWORD written;
DWORD read;
HANDLE hModem;
hModem = CreateFile( TEXT("COM6:"),
    GENERIC_READ | GENERIC_WRITE,
    0,
    NULL,
    OPEN_EXISTING,
    0,
    NULL);
if (hModem == INVALID_HANDLE_VALUE)
    // error opening port; abort
if (!WriteFile(hModem, atTest, BYTES_TO_BE_WRITTEN, &written, NULL))
    // error writing bytes; abort
Sleep(500);
if (!ReadFile(hModem, atAnswer, BYTES_TO_BE_READ, &read, NULL))
    // error reading bytes; abort
```

Further information on the parameters' values can be found at <http://msdn.microsoft.com/en-us/library/ms891445.aspx>.

3.1.4. CloseHandle



This function closes an open object handle.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```
BOOL CloseHandle(  
    HANDLE hObject  
);
```

Parameters:

hObject
[in] Handle to an open object.

Return value:

Nonzero indicates success. Zero indicates failure.

Example:

```
HANDLE hModem;  
hModem = CreateFile( TEXT("COM6:"),  
    GENERIC_READ | GENERIC_WRITE,  
    0,  
    NULL,  
    OPEN_EXISTING,  
    0,  
    NULL);  
if (hModem == INVALID_HANDLE_VALUE)  
    // error opening port; abort  
CloseHandle(hModem);
```

Further information can be found at <http://msdn.microsoft.com/en-us/library/ms923946.aspx>.

3.2. PPP Connection

There are several ways to setup a PPP connection for a Windows CE system; in this guide it is described one of the possible methods suitable for headless devices. For further instructions on



how to create a subproject refer to MSDN (<http://msdn.microsoft.com/en-us/library/aa913961.aspx>).

- Open Visual Studio 2005 and load your Os Image Design solution.
- In the solution explorer create a Windows CE Console Application subproject with the source files provided by Microsoft in the directory, starting from your Windows CE root (typically WINCE600), \PUBLIC\COMMON\OAK\DRIVERS\NETSAMP\RASENTRY, compile it and add to the OS image. This program adds an entry to the default RAS phonebook from information stored in a configuration file.
- Create the RAS phonebook configuration file (for example called telitHE863.ras). In the directory, starting from your Windows CE root (typically WINCE600), \PUBLIC\COMMON\OAK\DRIVERS\NETSAMP\RASENTRY, there is the file *rasentry.txt* that explains the rules for creating this kind of file. Following there is an example:

```
Name=Telit RAS
UseCountryAndAreaCodes=N
Phone=[Your provider phone number]
SpecificIpAddr=N
SpecificNameServers=N
DeviceType=modem
DeviceName=Telit HSDPA Modem on COM6:
SwCompression=N
IpHeaderCompression=N
DialModifier=[Custom AT commands if needed]
SpecificNameServers=Y
DnsAddr=[Your provider primary DNS address]
AltDnsAddr=[Your provider alternative DNS address]
```

- Create a Windows CE Console Application subproject with the source files provided by Microsoft in the directory, starting from your Windows CE root (typically WINCE600), \PUBLIC\COMMON\OAK\DRIVERS\NETSAMP\RASDIAL compile it and add to the OS image. This program setups the PPP connection according to the selected RAS phonebook entry.
- Start your target and, after the boot, plug the HE. Upload the created RAS phonebook configuration file to the target (for example using the File Viewer tool that you can find in the menu *Target → Remote Tools → File Viewer*).
- Launch in the target the application *RASENTRY* with the path of the RAS phonebook configuration file as the first argument; you can run an application in your system by choosing the menu voice *Target → Run Programs* and selecting the desired application.
- Launch in the target the application *RASDIAL* with the name of the created RAS phonebook entry (Telit RAS in the above example) as the first argument.

If all is successful the PPP connection should be setup: you can launch the *ipconfig* application for checking the target ip address.

