



Telit EVB2.0

User Guide


1WV0301732 Rev. 1 – 2021-10-18

APPLICABILITY TABLE


PRODUCTS
All modules available on a legacy TLB
All modules available on a smart TLB
<ul style="list-style-type: none">• First release of EVB 2.0 (based on CS2125).• EVB2.0 2nd release (based on CS2148) will include some changes compared to the first release.

CONTENTS

APPLICABILITY TABLE	2
CONTENTS	3
1. INTRODUCTION	6
1.1. Scope	6
1.2. Audience	6
1.3. Contact Information, Support	6
1.4. Symbol Conventions	7
2. GENERAL PRODUCT DESCRIPTION	8
2.1. Overview	8
2.2. Block Diagram	8
2.1. EVB2.0 Target	9
2.2. TLB Types	9
2.3. Main Features	10
2.4. Main Electrical Specifications	11
2.5. Mechanical Specifications	12
2.5.1. Dimensions	12
2.5.2. Temperature Range	12
3. 120-PIN MALE B2B CONNECTORS	13
3.1. B2B Connectors Layout (Top View)	13
3.2. B2B Connectors Pinout	14
4. POWER SUPPLY	17
4.1. Example Use Cases	18
4.2. V_{batt} Voltage Level	19
4.3. Power Supply Configuration	19
4.3.1. No-Leak Jumper	19
4.3.2. Source Selector	20
4.3.3. Voltage Selector	21
4.3.4. Kill Push Button	21
4.4. Power Supply Requirements	21



4.5.	4-Wires Connection for DIRECT SUPPLY	22
4.5.1.	Direct Supply	22
4.6.	Power Consumption Measurement	23
4.6.1.	Measure the Current by a Current Meter	24
4.6.2.	Measure the Current by a Power Supply	25
4.6.3.	Measure the Current through the Shunt Resistor	26
4.7.	VAUX/PWRMON Power Output	26
5.	DIGITAL SECTION	28
5.1.	Power On	28
5.2.	Communication Ports	29
5.2.1.	USB DEVICE (MAIN) and USB AUX (FTDI)	29
5.2.2.	UARTs Pins Naming Convention	30
5.2.3.	Serial Ports	30
5.3.	SIM Card Holders	31
5.4.	SDIO Interface	31
5.5.	LEDs	32
5.5.1.	Peak Current	32
5.5.2.	STAT_LED	32
5.5.3.	AUDIO ON	32
5.5.4.	FTDI ON	33
5.5.5.	PWRMON	33
5.5.6.	GPS PPS	33
5.5.7.	SW_RDY SYSTEM_RDY	33
5.5.8.	SPARE LED	33
5.6.	Push Buttons	33
5.6.1.	RESET	33
5.6.2.	SHDN	33
5.6.3.	ON/OFF	34
5.6.4.	USB_BOOT	34
5.6.5.	WCI_RX	34
5.6.6.	KILL	34
6.	AUDIO SECTION	35



6.1.	Electrical Characteristics	36
7.	MECHANICAL SPECIFICATIONS	38
7.1.	Drawing	38
8.	PRODUCT AND SAFETY INFORMATION	39
8.1.	Copyrights and Other Notices	39
8.1.1.	Copyrights	39
8.1.2.	Computer Software Copyrights	39
8.2.	Usage and Disclosure Restrictions	40
8.2.1.	License Agreements	40
8.2.2.	Copyrighted Materials	40
8.2.3.	High Risk Materials	40
8.2.4.	Trademarks	41
8.2.5.	Third Party Rights	41
8.2.6.	Waiver of Liability	41
8.3.	Safety Recommendations	42
9.	GLOSSARY	43
10.	DOCUMENT HISTORY	44

1. INTRODUCTION

1.1. Scope

This document introduces the Telit EVB2.0 and presents possible hardware solutions for the development of a product based on the Telit modules. The features and solutions described in this document are applicable to the variants listed in the applicability table.

This document may not include all hardware solutions or products that can be designed. Where the suggested hardware configurations are not to be considered mandatory, the information provided should be used as a guide and starting point for the proper development of the product with the Telit module.

1.2. Audience

This document is intended for system integrators that are using the Telit module in their products.

1.3. Contact Information, Support

For general contact, technical support services, technical questions and report of documentation errors contact Telit Technical Support at:

- TS-EMEA@telit.com
- TS-AMERICAS@telit.com
- TS-APAC@telit.com
- TS-SRD@telit.com
- TS-ONEEDGE@telit.com

Alternatively, use:

<https://www.telit.com/contact-us>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<https://www.telit.com>

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates the user feedback on our information.

1.4. Symbol Conventions



Danger: This information **MUST** be followed, or catastrophic equipment failure or personal injury may occur.



Warning: Alerts the user on important steps about the module integration.



Note/Tip: Provides advice and suggestions that may be useful when integrating the module.



Electro-static Discharge: Notifies the user to take proper grounding precautions before handling the product.

Table 1: Symbol Conventions

All dates are in ISO 8601 format, that is YYYY-MM-DD.

2. GENERAL PRODUCT DESCRIPTION

2.1. Overview

Telit EVB 2.0 system consists of a main board, as well as connectors, cables, accessories, and software. It is designed to host Telit modules allowing users to easily test the main module functions and features.

2.2. Block Diagram

The block diagram below depicts the main EVB building blocks in their approximate positions on the board.




Figure 1: EVB Block Diagram

The EVB hosts a daughter board known as the TLB which serves as a mechanical adapter from various Telit modules form factors to the three board-to-board connectors.

This approach strikes a balance between the need for a small-closed-shielded hardware layout (best practice in electronics) and making it available in an open and user-friendly package. Thus, the EVB and TLBs are intentionally not optimized as a “finished” product.

Of course, some circuit parts can be used as examples or inspirations, but in some cases, end product design solutions should be tailored to specific applications.

The modem communicates with the host PC via two USB-C cables: one for the module USB communication port and the other for serial lines, through a USB to serial converter.

The onboard power supply on the EVB is versatile and configurable: ancillary circuits and Telit module can be powered independently by USB MAIN PWR through a regulator, via a 12V Wall Adapter through a regulator and, for specific in-depth tests, providing DC power directly from an external power supply (caution: the voltage must be regulated and needs to be within the modem voltage range).

The EVB includes two SIM card holders, thus supporting dual-SIM modems. For modules supporting only one SIM interface, SIM1 holder is the default SIM socket.

Push buttons and LEDs are used as interface towards the human operator.

A large number of standard 2.54 mm pin headers, clearly identified by silk screen on the PCB, help the user in testing connections between ports or from an interface port to test equipment.

The audio section is minimal and allows testing with a standard hands-free headset, as well as connection to test equipment or to external amplifiers and transducers provided by the customer.

Telit modules require either 3.8, 3.3 or 1.8 V: this board is meant to be universal, thus it supports all three voltage levels; however, the user must carefully set up the board according to the instructions.



Warning: In case of incorrect power supply voltage configuration, the module can be irreversibly damaged.

2.1. EVB2.0 Target

EVB2.0 design aims at full compatibility with all existing Telit products and to be future proof.

2.2. TLB Types

TLBs are classified into two types: "old" (referred to as "LEGACY TLBs") and "new" (referred to as "SMART TLBs"). They differ in whether they were designed before or after EVB2.0 introduction.

TLB TAG	Description
LGCY38 TLB	The TLBs developed before this EVB, for modules with $V_{batt}=3.8V$. The voltage selector must be set at 3.8V.
LGCY33 TLB	The TLBs developed before this EVB, for modules with $V_{batt}=3.3v$. The voltage selector must be set to 3.3V.
SMRT38 TLB	TLBs that (in spite of the voltage selector position) automatically set the MAIN regulator's voltage to the required 3.8V.
SMRT33 TLB	TLB's that (in spite of the voltage selector position) automatically set the MAIN regulator's voltage to the required 3.3V.
SMRT18 TLB	TLB's that (in spite of the voltage selector position) automatically set the MAIN regulator's voltage to the required 1.8V.

Table 2: Product Variants and their Frequency Bands

EVB2 is backwards compatible with legacy TLBs that were developed and released prior to its introduction.

EVB2 offers some special features on the smart TLB:

- Power When Needed (PWN): The Main regulator is enabled when the TLB is properly inserted
- Automatic Voltage Selection (AVS) for main supply: the range is approximately 1÷4.5V.
- Automatic Voltage Selection (AVS) for VDDIO, typically 1.8 or 2.8V.
- Automatic Voltage Selection (AVS) for VSERV (starting from EVB2 version identified as "CS2148"), the range is roughly 0.5÷3.3V.

Please refer to "AVS Section" for detailed information about voltages on the SMART TLB's.

2.3. Main Features

Function	Features
Connection with PC or external host	<ul style="list-style-type: none"> • The USB of the device is connected to the PC via an USB-C port (MAIN USB) • The UART ports of the device are conveyed as VCP on an USB-C port (AUX USB) <ul style="list-style-type: none"> ○ The main UART is converted by an FTDI chip ○ An AUX UART is converted by an FTDI chip ○ An UART3 is converted by an FTDI chip
Versatile power supply	<ul style="list-style-type: none"> • DIRECT SUPPLY is for advanced users (typically, hardware designers) who need to provide supply voltage directly to the module • VIA REGULATOR <ul style="list-style-type: none"> ○ 12V wall adapter or USB MAIN source selection ○ Every device gets the proper voltage (1.8V, 3.3V, 3.8V) ○ The voltage is automatic or even PROGRAMMABLE ○ Power Supply can be opened for testing ○ Power Supply is activated automatically or on demand

Function	Features
	<ul style="list-style-type: none"> When VIA DCDC mode is used, an external PC can control the regulator: it can be switched ON or OFF and the voltage can be set as desired
2 SIM holder	<ul style="list-style-type: none"> There are 2 SIM holders, for module supporting 2 SIM interfaces SIM1 is the default SIM holder for the module that manage a single SIM.
SDIO interface	<ul style="list-style-type: none"> The SDIO interface goes to dedicated connector powered by a 3.3v regulator
Digital audio	<ul style="list-style-type: none"> A codec provided with all ancillary parts is producing the digital audio
Analog audio	<ul style="list-style-type: none"> Buffer amplifier, click & pop-less design without tantalum capacitors and microphone bias circuitry to manage analog audio, both connected to the jack and test points
Push buttons and switches	<ul style="list-style-type: none"> All the basic HW activations (On/Off, Reset, ...) can be operated manually via push buttons
LED's	<ul style="list-style-type: none"> LEDs provide indication of board and module status etc
Current consumption measurements	<ul style="list-style-type: none"> Multiple ways available to measure module current consumption. Easy disconnect of ancillary circuits (needed during normal operation) to avoid leaking currents that impact current measurements
GPIO facilitation	<ul style="list-style-type: none"> Module signals are tied to pin headers, to ease test and debugging. Some signals are bridged with jumpers to make them available to high-level interfaces/connectors All headers can be connected by means of wired jumpers
Voltage & current monitorable by PC	<ul style="list-style-type: none"> A current and voltage monitor connected via I2C can be read by an external PC, allowing to monitor the status of the device under test
Control extension port	<ul style="list-style-type: none"> The I2C controlling bus and some supply rails are available on a connector to manage a daughter board for future use
JTAG header	<ul style="list-style-type: none"> 2 x 10 shrouded JTAG header

Table 3: Functional Features

2.4. Main Electrical Specifications

Connector	Specification
Direct Supply	Refer to the module specifications
5.5/2.5mm power jack	5V or 12V (36 V tolerant)
SIM holders	Refer to the specifications of the module mounted
USB AUX	USB2 interface
USB MAIN	USB3, $V_{USB} = 5v$
Audio Jack Microphone	J-fet Electret Microphone: -38-45dBv/Pa
Audio Jack earpieces	≥ 16 Ohm, 320hm best

Table 4: Electrical Specification at Connections

2.5. Mechanical Specifications

2.5.1. Dimensions

The overall dimensions of EVB2 (CS2125 PCB version) are:

- Size: 156x110 [mm]
- PCB Thickness: 1.6 [mm]

2.5.2. Temperature Range

Mode	Temperature	Note
Operating Temperature Range	-20°C ÷ +55°C	SIM CARDS might not withstand extreme temperatures
	-40°C ÷ +100°C	The board (except SIM cards) is fully functional (*) across the whole temperature range.
Storage and non-operating Temperature Range	-40°C ÷ +85°C	

Table 5: Temperature Range



Note: (*) Functional: if applicable, the board is capable to supply and enable serial/USB communications to the TLB and its module.

3.2. B2B Connectors Pinout

B2B L (LEFT)					
1 GPS_LNA_BIAS	2 GND	3 GPS_LNA_EN	4 MICBIAS_MODULE	5 GND	6 NC / JACK_DET
7 GND	8 GND	9 GND	10 GND	11 GND	12 NC
13 MIC2_MT+	14 MIC2_MT-	15 GND	16 EAR2_MT-	17 EAR2_MT+	18 NC
19 GND	20 GND	21 GND	22 GND	23 GND	24 GND
25 MIC1_MT+	26 MIC1_MT-	27 GND	28 EAR1_MT-	29 EAR1_MT+	30 GND
31 SPKR_N	32 SPKR_P	33 NC	34 NC	35 RESERVED (DON'T USE)	36 MIC_VDD
37 GND	38 GND	39 D_MIC_CLK	40 D_MIC_DATA_1	41 GND	42 GND
43 NC	44 GND	45 GND	46 GND	47 GND	48 GND
49 NC	50 GND	51 GND	52 ADC_IN3	53 ADC_IN2	54 ADC_IN1
55 NC	56 NC	57 NC	58 NC	59 DAC_OUT	60 NC
61 DVI_RX	62 DVI_TX	63 DVI_CLK	64 DVI_WAO	65 REF_CLK_FF	66 GND
67 GND	68 GND	69 GND	70 GND	71 GND	72 ESIM_RST
73 GND	74 GND	75 GND	76 GND	77 SIMVCC1	78 SIMVCC1
79 HSIC_STB	80 HSIC_DATA	81 SIMCLK1	82 SIMIN1	83 SIMIO1	84 SIMRST1
85 HW_KEY	86 VRTC	87 ETH_RST_N	88 ETH_INT_N	89 SIMVCC2	90 SIMVCC2
91 USB_VBUS	92 USB_ID	93 SIMIN2	94 SIMIO2	95 SIMRST2	96 SIMCLK2
97 GND	98 GND	99 MAC_REF_CLK	100 MAC_TXEN_ER	101 MAC_MDIO	102 MAC_RXDV_ER
103 USB_D+	104 GND	105 MAC_TXD_0	106 MAC_MDC	107 MAC_RXD_0	108 MAC_CRSDV
109 USB_D-	110 GND	111 MAC_TXD_1	112 MAC_TXD_2	113 MAC_RXD_1	114 MAC_RXD_2
115 GND	116 GND	117 MAC_TX_CLK	118 MAC_TXD_3	119 MAC_RX_CLK	120 MAC_RXD_3

Table 6: B2B L Pin-out Information

B2B C (CENTRAL)					
1 GND	2 GND	3 I2C_SCL_AUX	4 I2C_SDA_AUX	5 GND	6 SGMII_RX_M
7 USB_SS_RX_P	8 GND	9 I2C_SDA_B2B	10 TGPI0_06	11 SGMII_TX_M	12 SGMII_RX_P
13 USB_SS_RX_M	14 GND	15 TGPI0_05	16 I2C_SCL_B2B	17 SGMII_TX_P	18 GND
19 GND	20 GND	21 VAUX/PWRMON2	22 VAUX/PWRMON2	23 GND	24 PCIE_RX_P
25 USB_SS_TX_P	26 GND	27 NC	28 FORDCED_USB_B OOT	29 PCIE_TX_P	30 PCIE_RX_M
31 NetS0101_45	32 GND	33 TGPI0_12	34 SPI_MOSI	35 PCIE_TX_M	36 GND
37 GND	38 NC	39 TGPI0_11	40 TGPI0_04	41 GND	42 PCIE_REFCLK_ P
43 #SPI_CS	44 TGPI0_02	45 TGPI0_03	46 SPI_MISO	47 NC	48 PCIE_REFCLK_ M
49 VAUX/PWRMON1	50 VAUX/PWRMON1	51 LED_DRV_EN	52 SPI_CLK	53 NC	54 NC
55 TGPI0_08	56 TGPI0_07	57 TGPI0_01	58 TGPI0_09	59 NC	60 NC
61 TGPI0_21	62 TGPI0_10	63 TGPI0_22	64 TGPI0_20	65 NC	66 NC
67 VMMC	68 VMMC	69 MMC_CD	70 MMC_DAT3	71 NC	72 NC
73 MMC_DAT0	74 MMC_DAT2	75 MMC_CLK	76 MMC_DAT1	77 PCIE_EP_RESET_N	78 NC
79 TLB_CONN	80 GND	81 C107/DSR	82 MMC_CMD	83 PCIE_CLKREQ_N	84 NC
85 WIFI_SD0_TGPI0 15	86 WIFI_SD1_TGPI0 16	87 WIFI_SDCMD_TGPI 014	88 WIFI_SDRST_TGPI 013	89 TXD_AUX	90 RTS_AUX
91 WIFI_SD5_TGPI0 24	92 WIFI_SD2_TGPI0 17	93 WIFI_SD3_TGPI01 8	94 WIFI_SD4_TGPI02 3	95 RXD_AUX	96 CTS_AUX
97 WIFI_SD6_TGPI0 25	98 WIFI_SD7_TGPI0 26	99 WIFI_SDCLK_TGPI 019	100 WCI_TX	101 WCI_RX	102 NC
103 C125/RING	104 RFCLK2_QCA	105 WLAN_SLEEP_CL K	106 C105/RTS	107 PCIE_EP_WAKE_N	108 NC
109 C104/RXD	110 C109/DCD	111 C103/TXD	112 C106/CTS	113 C108/DTR	114 NC
115 NC	116 NC	117 NC	118 NC	119 NC	120 NC

Table 7: B2B C Pin-out Information

B2B R (RIGHT)					
1	2	3	4	5	6
VBATT	VBATT	VBATT	VBATT_PA	VBATT_PA	VBATT_PA
7	8	9	10	11	12
VBATT	VBATT	VBATT	VBATT_PA	VBATT_PA	VBATT_PA
13	14	15	16	17	18
VBATT	VBATT	VBATT	VBATT_PA	VBATT_PA	VBATT_PA
19	20	21	22	23	24
VBATT_AUX	VBATT_AUX	VBATT_AUX	VBATT_PA	VBATT_PA	VBATT_PA
25	26	27	28	29	30
GND	GND	GND	GND	GND	DCDC_ADJ
31	32	33	34	35	36
GND	LDO_ADJ	GND	DCDC_OUTPUT	3V8_EVB	DCDC_ADJ_2
37	38	39	40	41	42
NC	NC	GND	GND	GND	GND
43	44	45	46	47	48
NC	NC	NC	DCDC_OUTPUT_2	DCDC_OUTPUT_2	DCDC_OUTPUT_2
49	50	51	52	53	54
NC	NC	NC	NC	NC	NC
55	56	57	58	59	60
NC	NC	UART3_TXD	UART3_RXD	UART3_RTS	UART3_CTS
61	62	63	64	65	66
NC	NC	NC	NC	NC	TP101
67	68	69	70	71	72
NC	NC	NC	NC	NC	NC
73	74	75	76	77	78
NC	NC	NC	NC	NC	JTAG_DETECT
79	80	81	82	83	84
OLD_TLB_GND	GND	GND	TLB_DETECT	GND	GND
85	86	87	88	89	90
GND	GND	GND	GND	GND	GND
91	92	93	94	95	96
#RESET	#ON_OFF	STAT_LED	LED_DRV	SW_RDY/SYSTEM_ON	#SHDN
97	98	99	100	101	102
GND	GND	GND	GND	JTAG_TRIGOUT	JTAG_TRIGIN
103	104	105	106	107	108
GPS_PPS	GPS_RFPAON	GPS_CLK	GND	JTAG_SUPPLY	JTAG_PS_HOLD
109	110	111	112	113	114
GND	GND	GND	GND	JTAG_TDI	GND
115	116	117	118	119	120
JTAG_TMS	JTAG_TDO	#JTAG_TRST	JTAG_TCK	JTAG_RTCK	#JTAG_RESOUT

Table 8: B2B R Pin-out Information

4. POWER SUPPLY

During final product development phases, it might be necessary to supply the module with low-level voltages (either 1.8V, 3.3V, or 3.8V) from an external DC source located close to the board and through a wire of adequate section. This case is defined as “DIRECT SUPPLY”.

Other users will just need to start working with the target module quickly and with reduced external devices. In this user case, a wall adapter connected to the board through the on-board regulator will be the optimal solution. This case is defined “VIA DCDC”.

Both approaches are supported with Telit EVB2, hybrid solution is also possible.

Quite often, a user must source the target in DIRECT SUPPLY mode (i.e. to be closer to a “real application” situation, or to observe the module current consumption) while also powering up the remaining EVB circuitry with a separate power supply (that is, via DCDC).

For each of the four rails, the following options are available:

1. V_{batt} , feeding the baseband part of the target module
2. V_{batt_PA} , feeding the RF part of the target module
3. V_{batt_AUX} , feeding the auxiliary circuits NOT belonging to the module
4. $3V8_EVB$, feeding auxiliary EVB circuits, fixed at 3.8V

These voltages are displayed on the selector from left to right, as shown below.




Figure 3: 4 Ways Power Selector

Please note that VIA DCDC can in turn be sourced by the wall adapter or, using the 3x1 male header selector, by the 5v of the MAIN USB.

4.1. Example Use Cases

Use Case 1:

The TLB is powered externally by DIRECT SUPPLY, while the EVB is powered by VIA DCDC. The EVB must always receive 3.8 V, so it is most frequently connected to the internal fixed regulator.




Figure 4: Use Case 1: 4 Ways Selector



Warning: This rail can only be connected to DIRECT SUPPLY when the external power supply is set to 3.8V.

Use Case 2:

The two most central headers on the left are the device's supply terminals, so if a separate DC source is required, connect to these two headers.




Figure 5: Use Case 2: 4 Ways Selector



Note: Please see section 4.6 Power Consumption Measurement for more information and use cases.

4.2. V_{batt} Voltage Level

Telit modules typically require either 3.8V, data cards require 3.3V, and 1.8V is the standard voltage for positioning modules. Please follow the guidelines below to provide the correct voltage to each Telit module:

- When in DIRECT SUPPLY mode,
 - The user is responsible to set the correct voltage on the external power supply.
- When in VIA DCDC mode,
 - For LEGACY TLB's
 - The voltage for LEGACY TLBs is selected using the EVB's 3.3v/3.8V voltage selector (please remember no LEGACY TLB supports positioning modules, thus there is no need for 1.8V selection)
 - For SMART TLB's
 - The voltage is automatically set (that is AVS, Automatic Voltage Selection is implemented). A resistor mounted on the TLB properly biases the voltage regulator network and triggers V_{batt} voltage to be set according to the module mounted on the TLB.

4.3. Power Supply Configuration

4.3.1. No-Leak Jumper

NO-LEAK is a jumper that disconnects reverse polarity protection diodes and stabilization capacitors. These components introduce current leakage thus this jumper must be removed during current consumption tests.

The adjacent “coffee bean” short must be cut as well, otherwise the above operation will not have any effect.




Figure 6: No-leak Jumper

4.3.2. Source Selector

When the VIA DCDC mode for some supply rail is used, it is possible to select the power source: it can be supplied either from the dedicated 5.5x2.5 mm jack or from the 5V USB-MAIN (USB-DEVICE).

With the jumper on the left position, USB is selected as source.

With the jumper on the right position, the jack is selected as source.



Figure 7: Source Selector

4.3.3. Voltage Selector

On the legacy TLB board (developed before EVB2 introduction), no AVS (Automatic Voltage Selector) is available, thus the DCDC regulator must be set to the voltage needed by the device using the voltage selector switch.

With the jumper set on the left position, the voltage is set to 3.3V.

With the jumper set on the right position, the voltage is set to 3.8V.



Figure 8: Voltage Selector

4.3.4. Kill Push Button

The KILL button, located in the top right-hand corner of the EVB, is designed to choke the device by disabling the DCDC regulator.

It is not recommended to use this button to power down the Telit module because the device must be turned off properly. This feature is only available to allow the user to simulate a sudden power supply interruption.



Figure 9: Kill Push Button

4.4. Power Supply Requirements

In DIRECT SUPPLY mode, the wirings impedance should be kept under control and must be less than 150mΩ, with an inductance not greater than 1μH. In general, a 0.5m long 18AWG wire is suitable.

In VIA DCDC mode, the wall adapter connected to the jack can supply a voltage in the 5V-12V range. The regulator can accept up to 36V (42V absolute maximum) but, in this case, the output voltage (V_{batt}) will not be properly regulated. Please note that a minimum current of 1.25A is required.

The cylindric jack is a 5,5x2,5 mm type with the inner terminal positive.

The WALL ADAPTER must fulfill the following requirements:

WALL ADAPTER	Value
Nominal Supply Voltage	8 V ÷ 12 V
Operating Voltage Range	4.8 V - 13 V (TBC)
Extended Voltage Range	4.8 V - 24 V (TBC)
Courent sourced	>=1.25A

Table 9: WALL ADAPTER Requirements



Warning: When the power supply wire voltage drops at 4.8-5V (especially with thin wires), the 3.8V module may experience undervoltage.

4.5. 4-Wires Connection for DIRECT SUPPLY

Any voltage drop due to connections or high impedance wires is a potential issue for the target and, in some cases, can lead to unexpected device switch-off (when V_{batt} falls below the minimum threshold). Thus, to prevent issues, it is recommended to use short and thick wires to supply power to the EVB.

If possible, use the 4-wire connection (2 source cables and 2 sense cables), connecting all wires at the end point on the four dedicated pads on the EVB. Termination capacitors - requested by the external Power Supply to be stable - are already mounted on the EVB2.

A long cable without detection could be affected not only by voltage drops, but could also lead to power wupply instability (that is voltage overshoot, thus permanent device failure).

4.5.1. Direct Supply

Soldering is the best connection method to prevent voltage drops. To ensure good mechanical retention as well, it is recommended to pass the wires through the cable lock slot.




Figure 10: Direct Supply

4.6. Power Consumption Measurement

The EVB not only allows different power supply configurations (as explained in the previous chapter), but at the same time supports different methods to measure current consumption of the Telit module connected to the EVB:

1. Current measurements through a current meter (EVB powered VIA DCDC)
2. Current measurements current through an external power supply (EVB powered via DIRECT SUPPLY - TP301)
3. Current measurements through a shunt resistor.




Figure 11: PL302 and TP301

With the first two methods, it is possible to measure the current separately for **VBATT**, **VBATT_PA**, **VBATT_AUX** and **3V8_EVB** rails.



Note: Each current component can be measured separately only if allowed by the TLB geometry. Please check the TLB schematic to verify if these paths are available separately.

4.6.1. Measure the Current by a Current Meter

The board is fully powered VIA DCDC. The current consumption of the device can be measured by placing an Ammeter in series to the desired rail.

The image below shows the VBATT measurement configuration.

Please ensure that the ammeter wires are properly sized. Avoid using thin or long wires because their high impedance could lead to voltage drop and the device could malfunction (disconnection, switch off).




Figure 12: Ammeter Insertion

Measurement setup example:




Figure 13: Measurement Setup with Ammeter

4.6.2. Measure the Current by a Power Supply

In this case, only the device is powered by an external source via DIRECT SUPPLY, while the TLB's auxiliary parts and the EVB board are powered via DCDC.

Obviously, a key requirement is that the external power supply must be able to perform current measurements.

The image below shows how to measure the consumption of the device.




Figure 14: Measure the Current by a Power Supply

Example of measurement setup:




Figure 15: Measurement Setup with Ammeter

NOTE: To avoid leakage currents due to the protection diode:

1. Remove the NO-LEAK JUMPER(PL301)
2. Cut the coffee-bean shaped bridge




Figure 16: Avoiding Leakage Current

4.6.3. Measure the Current through the Shunt Resistor

The device is exclusively powered VIA DCDC.

The device current consumption is indirectly measured by measuring the voltage across the 50 mΩ shunt resistor.




Figure 17: Measure the Current through the Shunt Resistor

4.7. VAUX/PWRMON Power Output

Most Telit modules include a regulated power supply output to supply small devices from the module itself, such as level translators, audio codecs, sensors, and so on.

Due to the different architectures, devices provide different voltages (usually 1.8V, rarely 2.8V) and current values, some as high as 50mA, some as low as 1mA. The general

approach in EVB2 design is to avoid drawing current from this port and use 3V8_EVB as source.

At the same time, if desired, VAUX/PWRMON1/2 pins are available for supplying the translators through a 0-Ohm jumper. They are available as well on their pin header to allow the user to connect external application hardware and test the system.



Note: When connecting a load on this net, the related current will bias positively the current drawn by the device. Please take this into account when evaluating device power consumption.

5. DIGITAL SECTION

Most of the device pins available on the to EVB are digital.

Its supply domain is VDDIO_1V8/2V8 and is set to 1.8V or 2.8V depending on the device (legacy TLB's are satisfied with 1.8V, smart TLB's set the voltage by its own).

These signals mostly terminate on a male connector, allowing the user to connect to other boards using wire jumpers.

Some of these lines are not terminated on a header and are connected directly to a peripheral (that is the serial or the DVI lines). In such cases, there are a couple of headers with jumpers: this allows the signals to function normally, but also to be interrupted to facilitate testing, debugging and measuring.

Where possible, the name of the signal is silk-screened on the board to allow quick identification.

Digital pins are grouped in the frontal area of the board and are available on 2x4 pins, 2.54 mm connectors.




Figure 18: Digital Section: Pinout

5.1. Power On

In most cases a button connecting a pin to ground is the proper way to turn on Telit devices.

In the other cases, there will be an adapter circuitry on the TLB that translates the open collector interface with the appropriate one, depending on the specific device.



Note: In this document, all inverted lines (that is, active low signals), are labeled with a name ending with '#', '*' or with a bar above the name.



Warning:

To check if the device has powered on, the hardware line PWRMON should be monitored.

No pull-up resistor should ever be used on the ON_OFF* line since it is internally pulled up. Using a pull-up resistor may cause problems with improper latching and power on/off of the module. The ON_OFF* line must be connected only in open collector or open drain configuration.

5.2. Communication Ports

5.2.1. USB DEVICE (MAIN) and USB AUX (FTDI)

The EVB mounts two USB-C connectors, labeled “MAIN” and “FTDI” on the initial EVB 2.0 board revision silk screen (based on CS2125 PCB revision), “DEVICE” and “AUX” on the second EVB 2.0 board revision.

Normally, communication between the TLB-mounted device and the host PC takes place either through USB DEVICE port or UART lines (translated by the FTDI chip).

The USB DEVICE (MAIN) is the top one and is connected to the Telit module USB port. Through this port it is possible to power the EVB, provided that the source selector is set on the left position.

The USB AUX (FTDI) is connected to a FTDI 4-channel port translator splitting the USB bus into one I2C interface and three UART lines.




Figure 19: USB DEVICE (MAIN) and USB AUX (FTDI)

The 3 UART lines are connected to the device serial lines and are mapped as Virtual Com Ports on the host PC.

Note: When the USB DEVICE is used as a power source, make sure the USB cable is as short and thick as possible, in order to avoid voltage drops on the cable that can cause issues.

Please note that a regulator must have some voltage margin to produce a reliable output voltage and the voltage drops reduce this margin.

5.2.2. UARTs Pins Naming Convention

On the EVB2 schematic, there is an apparent misalignment between the pins direction and their naming.

Note: Pins direction is inverted because on the main UART the host is considered the DTE (as per V.24 standards). On the other hand, for the other 2 UART lines, the Telit device is rated as DTE so the host becomes a DCE.

5.2.3. Serial Ports

The three serial ports are listed below:

- MODEM SERIAL (Main) is the port dedicated to the AT-commands
- AUX SERIAL is a second port for modules supporting two serial ports

- UART3 SERIAL is a spare serial port, often used by the GNSS receiver integrated in cellular devices

Each serial line must be configured as 115200 8-N-1, unless otherwise specified.

Serial port lines can be monitored (eg with a scope or logic state analyzer) or disconnected, thanks to dedicated jumpers placed on the front of the board. Each line jumper is silk-screened to allow easy identification. These lines operate at same voltage of the module under test, as they are actually the device communication ports.

This allows to interface the Telit device with the customer hardware prototype.



Note: For minimal implementation, only TXD and RXD lines can be connected, with the other lines left floating as long as software flow control is implemented.

To avoid back powering effect, it is recommended to prevent HIGH logic level signals from being applied to the digital pins when the device is powered off or during an ON/OFF transition.

5.3. SIM Card Holders

Since some cellular modules support two SIM interfaces, the EVB mounts two SIM card holders.

The default SIM holder is the one labeled “SIM1” on the left.




Figure 20: Sim Holders

5.4. SDIO Interface

At the top center of the EVB, a SDIO card connector is mounted.

SDIO cards are supplied with 3.3V: this rail (derived from the 3V8_EVB line) is always on when the board powered on.



Figure 21: SDIO Interface

5.5. LEDs

5.5.1. Peak Current

When exceeding about 100mA current draw, the LED switches on.

5.5.2. STAT_LED

Indication of Network Service Availability

The STAT_LED pin status displays network service availability and call status. The function is available as an alternative function of GPIO_01 (to be enabled by means of the AT#GPIO=1,0,2 AT command). Please refer to each module documentation for information on network service LED status.

STAT_LED status is defined accordingly to the table below:

Device Status	Led Status
Device off	Permanently off
Not Registered	Permanently on
Registered in idle	Blinking (1s on + 2 s off)
Registered in idle + power saving	Depends on the event that triggers the wakeup (In sync with network paging)
Connecting	Blinking 1s on + 2s off

Table 10: LED Status

5.5.3. AUDIO ON

This LED switches on when the “carrier” signal is present on the audio jack. It detects when the balanced output lines reach $\frac{1}{2}$ VDD stage and is ready to produce sound.

The indication is supported for both digital and analog audio chains.

5.5.4. FTDI ON

This LED switches on when the host PC operating system enumerates the USB instance of the FTDI level converter.

5.5.5. PWRMON

This LED switches on when the host PC operating system enumerates the module USB instance.

5.5.6. GPS PPS

This LED switches on when the device enables 1PPS output and the level is high: it's the 1PPS display, typical for positioning devices.

5.5.7. SW_RDY SYSTEM_RDY

This LED switches on when the module is ready to operate. Please note that only some Telit devices support this function.

5.5.8. SPARE LED

This LED is a visual test probe that switches on when the test point connected by the user reaches the high logic level.

5.6. Push Buttons



Warning RETRACTION: RESET and SHDN buttons have inverted silk-screen labelling.

5.6.1. RESET

Some devices require a low level on this line as a RESET command.

5.6.2. SHDN

Some devices require a low level on this line as a SHUTDOWN request.

5.6.3. ON/OFF

This is the ON/OFF push button: keeping it pressed for a few seconds switches the device ON or OFF.

The adjacent “AUTO_ON” switch, is a “comfort gadget” for users who want to emulate ON/OFF button always pressed. When activated, it “holds down” the ON/OFF push button permanently.

5.6.4. USB_BOOT

FORCED_USB_BOOT pin must be activated only during the firmware upgrade operation. Normally it must be left idle.

5.6.5. WCI_RX

This push button is available for compliance with some existent Telit devices requiring this line.

5.6.6. KILL

This push button abruptly stops the main DCDC regulator, causing a power disruption if a device is powered through DCDC. It is the forced power-cycle function.



Warning: Use of KILL is not recommended.

Make sure to follow the switch-off procedures for the specific device in the application. It is provided on the EVB for testing purpose only.

6. AUDIO SECTION

The EVB2 AUDIO interface includes an headphone amplifier, typically not present on Telit evaluation boards: this solution was chosen since loudspeakers are referenced to ground, thus avoiding tantalum DC block capacitors causing audio clicks and pops.

The user interface is a CTIA standard handfree TRRS 3.5mm jack or a 4 test points array in 2.54mm pitch.




Figure 22: Digital Audio Jumpers Configuration

Since a CODEC (provided with local clock and I2C pull-up) handles the conversion, the other end, towards the device under test, can be easily operated as an analogue or digital interface.

This I2C interface (necessary to configure and activate the codec) is different from that of the FTDI chip: it belongs to the I2C port of the module under test.

Some Telit modules have dedicated I2C pins, known as "native I2C," while others share lines between GPIO and I2C.

The I2C selector allows to choose between native I2C and GPIO1/2: if different GPIO lines must be used, it is suggested to connect them using the supplied wired jumpers.

To provide the user with maximum flexibility, all audio and codec signals are routed through a pair of jumpered headers. In example, a handsfree can be connected directly and jumpers can be removed to connect external circuitry.

To initialize the audio codec using GPIO1 as SDA and GPIO2 as SCL, the following commands from the AT interface must be sent:

- AT#I2CWR=1,2,30,4,19
- 00109000100A330000330C0C09092424400060 <CTRL-Z>
- AT#I2CWR=1,2,30,17,1
- 8A <CTRL-Z>

To use the audio in ANALOG MODE, the jumpers must be set as shown in the image below:



Figure 23: Jumpers Configuration for Audio in Analog Mode

Telit modules digital audio interface (DVI) is based on the I2S serial bus interface standard. The audio port can be connected to the end device using the digital interface, or via one of the several compliant codecs (in case an analog audio is needed).

6.1. Electrical Characteristics

The product is providing the DVI on the following pins:

Signal	I/O for the device	Function	Type
DVI_WAO	Output for Device (MASTER) Input for Device (SLAVE)	Digital Audio Interface (Word Alignment / LRCLK)	CMOS 1.8V/2.8V
DVI_RX	Input for Device Output for Codec	Digital Audio Interface (RX)	CMOS 1.8V/2.8V
DVI_TX	Output for Device Input for Codec	Digital Audio Interface (TX)	CMOS 1.8V/2.8V
DVI_CLK	Output for Device (MASTER) Input for Device (SLAVE)	Digital Audio Interface (BCLK)	CMOS 1.8V/2.8V

Table 11: Pins DVI

7. MECHANICAL SPECIFICATIONS (FIRST EVB2.0 RELEASE)

7.1. Drawing




Figure 24: Board Mechanical Drawing (dimensions are in millimeters)

8. PRODUCT AND SAFETY INFORMATION

8.1. Copyrights and Other Notices

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

Although reasonable efforts have been made to ensure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from the use of the information contained herein. The information contained in this document has been carefully checked and is believed to be reliable. Telit reserves the right to make changes to any of the products described herein, to revise it and to make changes from time to time without any obligation to notify anyone of such revisions or changes. Telit does not assume any liability arising from the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

This document may contain references or information about Telit's products (machines and programs), or services that are not announced in your country. Such references or information do not necessarily mean that Telit intends to announce such Telit products, programming, or services in your country.

8.1.1. Copyrights

This instruction manual and the Telit products described herein may include or describe Telit copyrighted material, such as computer programs stored in semiconductor memories or other media. The laws in Italy and in other countries reserve to Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute, and make derivative works of the copyrighted material. Accordingly, any of Telit's or its licensors' copyrighted material contained herein or described in this instruction manual, shall not be copied, reproduced, distributed, merged, or modified in any way without the express written permission of the owner. Furthermore, the purchase of Telit products shall not be deemed to grant in any way, neither directly nor by implication, or estoppel, any license.

8.1.2. Computer Software Copyrights

Telit and the Third Party supplied Software (SW) products, described in this instruction manual may include Telit's and other Third Party's copyrighted computer programs stored in semiconductor memories or other media. The laws in Italy and in other countries reserve to Telit and other Third Party, SW exclusive rights for copyrighted

computer programs, including – but not limited to - the exclusive right to copy or reproduce in any form the copyrighted products. Accordingly, any copyrighted computer programs contained in Telit’s products described in this instruction manual shall not be copied (reverse engineered) or reproduced in any manner without the express written permission of the copyright owner, being Telit or the Third Party software supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or in any other way, any license under the copyrights, patents or patent applications of Telit or other Third Party supplied SW, except for the normal non-exclusive, royalty free license to use arising by operation of law in the sale of a product.

8.2. Usage and Disclosure Restrictions

8.2.1. License Agreements

The software described in this document is owned by Telit and its licensors. It is furnished by express license agreement only and shall be used exclusively in accordance with the terms of such agreement.

8.2.2. Copyrighted Materials

The Software and the documentation are copyrighted materials. Making unauthorized copies is prohibited by the law. The software or the documentation shall not be reproduced, transmitted, transcribed, even partially, nor stored in a retrieval system, nor translated into any language or computer language, in any form or by any means, without prior written permission of Telit.

8.2.3. High Risk Materials

Components, units, or third-party goods used in the making of the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: operations of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (“High Risk Activities”). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness eligibility for such High-Risk Activities.

8.2.4. Trademarks

TELIT and the Stylized T-Logo are registered in the Trademark Office. All other product or service names are property of their respective owners.

8.2.5. Third Party Rights

The software may include Third Party's software Rights. In this case the user agrees to comply with all terms and conditions imposed in respect of such separate software rights. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License, shall apply to the Third-Party Rights software as well.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESSED OR IMPLIED FROM ANY THIRD PARTY REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODES"), AND THE USE OF ANY OR ALL OTHER CODES IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODES MUST BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST OF PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODES OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

8.2.6. Waiver of Liability

IN NO EVENT WILL TELIT AND ITS AFFILIATES BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY INDIRECT DAMAGE OF ANY KIND WHATSOEVER, INCLUDING BUT NOT LIMITED TO REIMBURSEMENT OF COSTS, COMPENSATION OF ANY DAMAGE, LOSS OF PRODUCTION, LOSS OF PROFIT, LOSS OF USE, LOSS OF BUSINESS, LOSS OF DATA OR REVENUE, WHETHER OR NOT THE POSSIBILITY OF SUCH DAMAGES COULD HAVE BEEN REASONABLY FORESEEN, CONNECTED IN ANY WAY TO THE USE OF THE PRODUCT/S OR TO THE INFORMATION CONTAINED IN THE PRESENT DOCUMENTATION, EVEN IF TELIT AND/OR ITS AFFILIATES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

8.3. Safety Recommendations

Make sure the use of this product is allowed in your country and in the environment required. The use of this product may be dangerous and must be avoided in areas where:

- it can interfere with other electronic devices, particularly in environments such as hospitals, airports, aircrafts, etc.
- there is a risk of explosion such as gasoline stations, oil refineries, etc. It is the responsibility of the user to enforce the country regulation and the specific environment regulation.

Do not disassemble the product; any mark of tampering will compromise the warranty validity. We recommend following the instructions of the hardware user guides for correct wiring of the product. The product must be supplied with a stabilized voltage source and the wiring must be conformed to the security and fire prevention regulations. The product must be handled with care, avoiding any contact with the pins because electrostatic discharges may damage the product itself. Same cautions must be taken for the SIM, checking carefully the instruction for its use. Do not insert or remove the SIM when the product is in power saving mode.

The system integrator is responsible for the functioning of the final product. Therefore, the external components of the module, as well as any project or installation issue, must be handled with care. Any interference may cause the risk of disturbing the GSM network or external devices or having an impact on the security system. Should there be any doubt, please refer to the technical documentation and the regulations in force. Every module must be equipped with a proper antenna with specific characteristics. The antenna must be installed carefully in order to avoid any interference with other electronic devices and has to guarantee a minimum distance from the body (20 cm). In case this requirement cannot be satisfied, the system integrator must assess the final product against the SAR regulation.

The equipment is intended to be installed in a restricted area location.

The equipment must be supplied by an external specific limited power source in compliance with the standard EN 62368-1:2014.

The European Community provides some Directives for the electronic equipment introduced on the market. All the relevant information is available on the European Community website:

https://ec.europa.eu/growth/sectors/electrical-engineering_en


9. GLOSSARY

EVB	Evaluation Board
FTDI	Future Technology Devices International
I/O	Input Output
SIM	Subscriber Identification Module
TLB	Translation Board
UART	Universal Asynchronous Receiver Transmitter
USB	Universal Serial Bus

10. DOCUMENT HISTORY

Revision	Date	Changes
0	2021-08-16	First issue
1	2021-10-18	Minor corrections, watermark removed

From Mod.0818 rev.4

A network diagram consisting of various colored nodes (blue, orange, green, yellow, black, grey) connected by thin grey lines, forming a complex web. The nodes are scattered across the page, with a higher density in the top-left and bottom-right corners.

Connect to our site and contact our
technical support team for any question

www.telit.com

The Telit logo features a stylized orange and blue mark above the word "Telit" in a bold, dark blue sans-serif font.

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2021, Telit