



FN980 Family

HW Design Guide

1WV0301603 Rev. 7 – 2021-05-28

A decorative graphic in the top-left corner showing a network of interconnected nodes and lines, with some nodes highlighted in yellow and blue.

APPLICABILITY TABLE


PRODUCTS	Description
FN980	3G / 4G / 5G Sub-6 cellular module
FN980m	3G / 4G / 5G Sub-6 / 5G mmWave cellular module



CONTENTS

APPLICABILITY TABLE	2
CONTENTS	3
1. INTRODUCTION	8
1.1. Scope	8
1.2. Audience	8
1.3. Contact Information, Support	8
1.4. Symbol Conventions	9
1.5. Related Documents	9
2. GENERAL PRODUCT DESCRIPTION	11
2.1. Overview	11
2.2. Frequency Bands and CA / EN-DC Combinations	11
2.2.1. Frequency Bands	11
2.2.2. CA / MIMO / EN-DC	15
2.3. Target Market	15
2.4. Main Features	15
2.4.1. Configurations Pins	16
2.5. Block Diagram	17
2.6. RF Performance	17
2.6.1. Conducted Transmit Output Power	17
2.6.2. Conducted Receiver Sensitivity	18
2.7. Mechanical Specifications	20
2.7.1. Dimensions	20
2.7.2. Weight	21
2.8. Environmental Requirements	21
2.8.1. Temperature Range	21
2.8.2. RoHS Compliance	22
3. PINS ALLOCATION	23
3.1. Pin-out	23
3.2. FN980 Family Signals That Must be Connected	26
3.3. Pin Layout	27

4.	POWER SUPPLY	28
4.1.	Power Supply Requirements	28
4.2.	Power Consumption	28
4.3.	General Design Rules	30
4.3.1.	Electrical Design Guidelines	30
4.3.1.1.	+5V Source Power Supply Design Guidelines	30
4.3.2.	Thermal Design Guidelines	31
4.3.3.	Power Supply PCB Layout Guidelines	31
4.4.	RTC	32
4.5.	Reference Voltage	33
4.6.	Internal LDO for GNSS Bias	33
5.	ELECTRICAL SPECIFICATIONS	34
5.1.	Absolute Maximum Ratings – Not Optional	34
5.2.	Recommended Operating Conditions	34
6.	DIGITAL SECTION	35
6.1.	Logic Levels	35
6.1.1.	1.8V Pins – Absolute Maximum Ratings	35
6.1.2.	1.8V Standard GPIOs	35
6.1.3.	1.8V SIM Card Pins	36
6.1.4.	2.85V Pins – Absolute Maximum Ratings	36
6.1.5.	SIM Card Pins @2.85V	36
6.2.	Power On	37
6.2.1.	Initialization and Activation State	37
6.3.	Power Off	38
6.3.1.	Graceful Shutdown	38
6.3.1.1.	Graceful Shutdown by FULL_CARD_POWER_OFF_N	38
6.3.2.	Fast Shutdown	39
6.3.2.1.	Fast Shutdown by GPIO	39
6.4.	Reset	41
6.4.1.	Unconditional Hardware Reset	41
6.5.	Communication Ports	42
6.5.1.	PCIe Interface	43



6.5.2.	SIM Interface	44
6.5.2.1.	SIM Schematic Example	45
6.5.3.	eSIM Interface	45
6.5.3.1.	W_DISABLE_N_3.3V	46
6.5.3.2.	LED	46
6.5.4.	General Purpose I/O	46
6.5.4.1.	Using a GPIO Pin as Input	47
6.5.4.2.	Using a GPIO Pin as Output	48
6.5.5.	I2C – Inter-integrated Circuit	48
6.5.6.	USB 3.1 Interface	49
7.	RF SECTION	51
7.1.	Antenna Interface	51
7.1.1.	Antenna Configuration	51
7.2.	Antenna Connector	53
7.3.	mmWave Antenna Connector	54
7.3.1.	mmWave IF Connector	54
7.3.2.	Cable for mmWave IF	54
7.3.3.	mmWave Antenna Assembly	55
7.3.3.1.	QTM525	56
7.3.3.2.	QTM527	56
7.4.	Antenna Requirements	58
7.4.1.	Antenna Cable	58
7.4.2.	Antenna Installation Guidelines	59
7.5.	GNSS Receiver	60
7.5.1.	GNSS RF Front End Design	60
7.6.	GNSS Characteristics	61
8.	MECHANICAL DESIGN	62
8.1.	General	62
8.2.	Finishing & Dimensions	62
8.3.	Drawing	62
9.	APPLICATION GUIDE	63
9.1.	Debug of the FN980 Family Module in Production	63

	FN980 Family Hardware Design Guide	
9.2.	Bypass Capacitor on Power Supplies	63
9.3.	EMC Recommendations	64
10.	PACKAGING	65
10.1.	Tray	65
11.	CONFORMITY ASSESSMENT ISSUES	67
11.1.	Approvals	67
11.2.	RED Approval	67
11.2.1.	RED Declaration of Conformity	67
11.2.2.	RED Antennas	67
11.3.	FCC and ISED Approval/FCC et ISDE Approbation	69
11.3.1.	FCC Certificates	69
11.3.2.	ISED Approvals / <i>ISDE Approbation</i>	69
11.3.3.	Applicable FCC and ISED Rules / <i>Liste des Règles FCC et ISDE Applicables</i>	69
11.3.4.	FCC and ISED Regulatory Notices / <i>Avis Réglementaires de FCC et ISDE</i>	69
11.3.5.	Antennas / <i>Antennes</i>	71
11.3.6.	FCC Label and Compliance Information	73
11.3.7.	ISED Label and Compliance Information / <i>ISED Étiquette et Informations de Conformité</i>	73
11.3.8.	Information on Test Modes and Additional Testing Requirements / <i>Informations sur les Modes de Test et les Exigences de Test Supplémentaires</i>	74
11.3.9.	Fcc Additional Testing, Part 15 Subpart B Disclaimer	75
12.	PRODUCT AND SAFETY INFORMATION	76
12.1.	Copyrights and Other Notices	76
12.1.1.	Copyrights	76
12.1.2.	Computer Software Copyrights	76
12.2.	Usage and Disclosure Restrictions	77
12.2.1.	License Agreements	77
12.2.2.	Copyrighted Materials	77
12.2.3.	High Risk Materials	77
12.2.4.	Trademarks	77



FN980 Family Hardware Design Guide

12.2.5.	Third Party Rights	78
12.2.6.	Waiver of Liability	78
12.3.	Safety Recommendations	78
13.	GLOSSARY	80
14.	DOCUMENT HISTORY	81

1. INTRODUCTION

1.1. Scope

This document introduces the Telit FN980 Family module and presents possible and recommended hardware solutions for the development of a product based on this module. All the features and solutions described in this document are applicable to all FN980 Family variants, where 'FN980 Family' refers to the variants listed in the applicability table.

If a specific feature is applicable to a specific product only, it will be clearly marked.



Note: FN980 Family refers to all modules listed in the Applicability Table.

This document covers all the basic functions of a wireless module; a valid hardware solution is suggested for each function, and incorrect solutions and common errors to avoid are reported.

This document cannot include every hardware solution or every product that can be designed. Where the suggested hardware configurations are not to be considered mandatory, the information provided should be used as a guide and a starting point for the proper development of the product with the Telit FN980 Family module.



Note: The integration of the 3G/4G/5G FN980 Family cellular module within a user application must be performed according to the design rules described in this manual.

1.2. Audience

This document is intended for Telit customers, especially system integrators, about to implement their applications using the Telit FN980 Family module.

1.3. Contact Information, Support

For general contact, technical support services, technical questions and report documentation errors contact Telit Technical Support at:

- TS-EMEA@telit.com
- TS-AMERICAS@telit.com
- TS-APAC@telit.com
- TS-SRD@telit.com

Alternatively, use:

<https://www.telit.com/contact-us/>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<https://www.telit.com>

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates the user feedback on our information.

1.4. Symbol Conventions



Danger: This information MUST be followed or catastrophic equipment failure or personal injury may occur.



Warning: Alerts the user on important steps about the module integration.



Note/Tip: Provides advice and suggestions that may be useful when integrating the module.




Electro-static Discharge: Notifies the user to take proper grounding precautions before handling the product.

Table 1: Symbol Conventions

All dates are in ISO 8601 format, i.e YYYY-MM-DD.

1.5. Related Documents

- FN980 Family SW User Guide, 1VW0301615
- FN980 Family AT Commands Reference Guide, 80624ST10996A
- Generic EVB HW User Guide, 1VW0301249



FN980 Family Hardware Design Guide

- FN980 Family Interface Board HW User Guide, 1VV0301651
- FN980 Family Thermal Design Guide, 1VV0301610
- FN980m QTM52x Application Note, 80667NT11888A
- FN980 Family CA / EN-DC list, 30624NT11890A

2. GENERAL PRODUCT DESCRIPTION

2.1. Overview

The aim of this document is to present the possible and recommended hardware solutions useful for developing a product with the Telit FN980 Family M.2 module.

FN980 Family is Telit's platform for the M.2 module for applications, such as M2M applications and industrial IoT device platforms, based on the following technologies:

- 5G mmWave and sub-6/4G/3G networks for data communication
- Designed for industrial grade quality

In its most basic use case, FN980 Family can be applied as a wireless communication front-end for mobile products, offering mobile communication features to an external host CPU through its rich interfaces.

FN980m is available in hardware variants as listed in the [APPLICABILITY TABLE](#)

PRODUCTS	Description
FN980	3G / 4G / 5G Sub-6 cellular module
FN980m	3G / 4G / 5G Sub-6 / 5G mmWave cellular module

The designated RF band sets for each variant are detailed in Section [2.2, Frequency Bands and CA / EN-DC Combinations](#)

2.2. Frequency Bands and CA / EN-DC Combinations

2.2.1. Frequency Bands

Operating frequencies in 5G, LTE and WCDMA modes conform to 3GPP specifications.

Below is the list of operating frequencies on 5G, LTE and WCDMA mode.

5G NR Sub 6 Bands supportive

NR BAND	Duplex Mode	Uplink Frequency (MHz)	Downlink Frequency (MHz)	Channels	SCS (kHz)
n1 - 2100	FDD	1920 - 1980	2110 - 2170	Tx: 384000 - 396000	15

NR BAND	Duplex Mode	Uplink Frequency (MHz)	Downlink Frequency (MHz)	Channels	SCS (kHz)
				Rx: 422000 - 434000	
n2 - 1900 PCS	FDD	1850 - 1910	1930 - 1990	Tx: 370000 - 382000 Rx: 386000 - 398000	15
n3 - 1800	FDD	1710 - 1785	1805 - 1880	Tx: 342000 - 357000 Rx: 361000 - 376000	15
n5 - 850	FDD	824 - 849	869 - 894	Tx: 164800 - 169800 Rx: 173800 - 178800	15
n7 - 2600	FDD	2500 - 2570	2620 - 2690	Tx: 500000 - 514000 Rx: 524000 - 538000	15
n8 - 900	FDD	880 - 915	925 - 960	Tx: 176000 - 183000 Rx: 185000 - 192000	15
n12 - 700 a	FDD	699 - 716	729 - 746	Tx: 139800 - 143200 Rx: 145800 - 149200	15
n20 - 800	FDD	832 - 862	791 - 821	Tx: 166400 - 172400 Rx: 158200 - 164200	15
n25 - 1900+	FDD	1850 - 1915	1930 - 1995	Tx: 370000 - 383000 Rx: 386000 - 399000	15
n28 - 700 APT	FDD	703 - 748	758 - 803	Tx: 140600 - 149600 Rx: 151600 - 160600	15
n38 - 2600	TDD	2570 - 2620		T/Rx: 514000 - 524000	30
n40 - 2300	TDD	2300 - 2400		T/Rx: 460000 - 480000	30
n41 - 2600+	TDD	2496 - 2690		T/Rx: 499200 - 537996	30
n48 - 3600	TDD	3550 - 3700		T/Rx: 636668 - 646666	30
n66 - AWS-3	FDD	1710 - 1780	2110 - 2200	Tx: 342000 - 356000 Rx: 422000 - 440000	15
n71 - 600	FDD	663 - 698	617 - 652	Tx: 132600 - 139600 Rx: 123400 - 130400	15
n77 - 3700	TDD	3300 - 4200		T/Rx: 620000 - 680000	30
n78 - 3500	TDD	3300 - 3800		T/Rx: 620000 - 653332	30
n79 - 4700	TDD	4400 - 5000		T/Rx: 693334 - 733332	30

Table 2: 5G NR Sub 6 Bands supportive

5G NR mmWave Bands supportive (Supported by FN980m)

NR BAND	Duplex Mode	Uplink Frequency (MHz)	Downlink Frequency (MHz)	Channels	SCS (kHz)
n257- 28 GHz	TDD	26500 - 29500		T/Rx: 2054167 - 2104165	120

NR BAND	Duplex Mode	Uplink Frequency (MHz)	Downlink Frequency (MHz)	Channels	SCS (kHz)
n258 - 26 GHz	TDD	24250 - 27500		T/Rx: 2016667 - 2070831	120
n260 - 39 GHz	TDD	37000 - 40000		T/Rx: 2229167 - 2279165	120
n261- 28 GHz US	TDD	27500 - 28350		T/Rx: 2070833 - 2084999	120

Table 3: 5G NR mmWave Bands supportive

LTE Bands supportive

E-UTRA BAND	Duplex Mode	Uplink Frequency (MHz)	Downlink Frequency (MHz)	Channels
B1 - 2100	FDD	1920 - 1980	2110 - 2170	Tx: 18000 - 18599 Rx: 0 - 599
B2 - 1900 PCS	FDD	1850 - 1910	1930 - 1990	Tx: 18600 - 19199 Rx: 600 - 1199
B3 - 1800+	FDD	1710 - 1785	1805 - 1880	Tx: 19200 - 19949 Rx: 1200 - 1949
B4 - AWS-1	FDD	1710 - 1755	2110 - 2155	Tx: 19950 - 20399 Rx: 1950 - 2399
B5 - 850	FDD	824 - 849	869 - 894	Tx: 20400 - 20649 Rx: 2400 - 2649
B7 - 2600	FDD	2500 - 2570	2620 - 2690	Tx: 20750 - 21449 Rx: 2750 - 3449
B8 - 900 GSM	FDD	880 - 915	925 - 960	Tx: 21450 - 21799 Rx: 3450 - 3799
B12 - 700 a	FDD	699 - 716	729 - 746	Tx : 23010 - 23179 Rx : 5010 - 5179
B13 - 700 c	FDD	777 - 787	746 - 756	Tx : 23180 - 23279 Rx : 5180 - 5279
B14 - 700 PS	FDD	788 - 798	758 - 768	Tx : 23280 - 23379 Rx : 5280 - 5379
B17 - 700 b	FDD	704 - 716	734 - 746	Tx: 23730 - 23849 Rx: 5730 - 5849
B18 - 800 Lower	FDD	815 - 830	860 - 875	Tx: 23850 - 23999 Rx: 5850 - 5999
B19 - 800 Upper	FDD	830 - 845	875 - 890	Tx: 24000 - 24149 Rx: 6000 - 6149

E-UTRA BAND	Duplex Mode	Uplink Frequency (MHz)	Downlink Frequency (MHz)	Channels
B20 - 800 DD	FDD	832 - 862	791 - 821	Tx: 24150 - 24449 Rx: 6150 - 6449
B25 - 1900+	FDD	1850 - 1915	1930 - 1995	Tx: 26040 - 26689 Rx: 8040 - 8689
B26 - 850+	FDD	814 - 849	859 - 894	Tx: 26690 - 27039 Rx: 8690 - 9039
B28 - 700 APT	FDD	703 - 748	758 - 803	Tx: 27210 - 27659 Rx: 9210 - 9659
B29 - 700 d	FDD	N/A	717 - 728	Rx: 9660 - 9769
B30 - 2300 WCS	FDD	2305 - 2315	2350 - 2360	Tx: 27660 - 27759 Rx: 9770 - 9869
B32 - 1500 L	FDD	N/A	1452 - 1496	Rx: 9920 - 10359
B34 - 2000	TDD	2010 - 2025		T/Rx: 36200 - 36349
B38 - 2600	TDD	2570 - 2620		T/Rx: 37750 - 38249
B39 - 1900+	TDD	1880 - 1920		T/Rx: 38250 - 38649
B40 - 2300	TDD	2300 - 2400		T/Rx: 38650 - 39649
B41 - 2600+	TDD	2496 - 2690		T/Rx: 39650 - 41589
B42 - 3500	TDD	3400 - 3600		T/Rx: 41590 - 43589
B43 - 3700	TDD	3600 - 3800		T/Rx: 43590 - 45589
B46 - 5200	TDD	5150 - 5925 (DL only)		Rx: 46790 - 54539
B48 - 3600	TDD	3550 - 3700		T/Rx: 55240 - 56739
B66 - AWS-3	FDD	1710 - 1780	2110 - 2200	Tx: 131972 - 132671 Rx: 66436 - 67335
B71 - 600	FDD	663 - 698	617 - 652	Tx: 133122 - 133471 Rx: 68586 - 68935

Table 4: LTE Bands supportive

WCDMA Bands supportive

UTRA BAND	Duplex Mode	Uplink Frequency (MHz)	Downlink Frequency (MHz)	Channels
B1 - 2100	FDD	1920 - 1980	2110 - 2170	Tx: 9612 - 9888 Rx: 10562 - 10838
B2 - 1900 PCS	FDD	1850 - 1910	1930 - 1990	Tx: 9262 - 9538 Rx: 9662 - 9938
B3 - 1800 DCS	FDD	1710 - 1785	1805 - 1880	Tx: 937 - 1288 Rx: 1162 - 1513

B4 - AWS-1	FDD	1710 - 1755	2110 - 2155	Tx: 1312 - 1513 Rx: 1537 - 1738
B5 - 850	FDD	824 - 849	869 - 894	Tx: 4132 - 4233 Rx: 4357 - 4458
B6 - 850 Japan	FDD	830 - 840	875 - 885	Tx: 4162 - 4188 Rx: 4387 - 4413
B8 - 900 GSM	FDD	880 - 915	925 - 960	Tx: 2712 - 2863 Rx: 2937 - 3088
B9 - 1800 Japan	FDD	1750 - 1785	1845 - 1880	Tx: 8762 - 8912 Rx: 9237 - 9387
B19 - 800 Japan	FDD	830 - 845	875 - 890	Tx: 312 - 363 Rx: 712 - 763

Table 5: WCDMA Bands supportive

2.2.2. CA / MIMO / EN-DC

The FN980 Family supports 2CA, 3CA, 4CA, 5CA, 6CA and 7CA for LTE CA combinations and EN-DC for NR FR1 / FR2 configuration.



Note: Refer to the FN980 Family CA / EN-DC list, 30624NT11890A for detailed combinations of CA and EN-DC.

2.3. Target Market

The FN980 Family can be used for telematics applications where tamper-resistance, confidentiality, integrity, and authenticity of end-user information are required, for example:

- Industrial equipment
- Home network
- Internet connectivity

2.4. Main Features

The FN980 Family of industrial grade cellular modules features 5G mmWave/Sub-6, LTE and multi-RAT module together with an on-chip powerful application processor and a rich set of interfaces.

Main functions and features are listed below:

Main Features

Function	Features
Physical	M.2 Type 3050-D2-B
Cellular technology	5G: FR1(Sub 6G), optional FR2(mmWave), Rel 15 4G: CAT. 20 (2Gbps) on DL, CAT. 13 (150Mbps) on UL, Rel 15 3G: HSPA+ Rel9 up to 42/5.7Mbps in DL/UL
4x4 MIMO	5G: n1/n2/n3/n7/n25/n38/n40/n41/n48/n66/n77/n78/n79 4G: B1/B2/B3/B4/B7/B25/B30/B66/B38/B39/B40/B41/B42/B43/B48/B46
Diversity/2 nd Rx	4G: all operating bands 3G: all operating bands
GNSS	Dual-Frequency GNSS Upper L-band: GPS/Glonass/Beidou/Galileo Lower L-band: GPS/Galileo
USIM port – dual voltage	Support for SIM Class B and Class C support Clock rates up to 4 MHz
Application processor	Application processor to run customer application code 32 bit ARM Cortex-A7 up to 1.5 GHz running the Linux operating system 4Gbit NAND Flash + 4Gbit LPDDR4 MCP is supported
Main Interfaces	PCIe Gen3 x 1-lane USB 3.1 Gen 2 Peripheral Ports – GPIOs
Antenna connection	4 x MHF-4 type Cellular/GNSS antenna connectors 1 x MHF-4 type Dedicated GNSS antenna connector 4 x mmWave 2 in 1 IF connectors
Form factor	M.2 Form factor (30 * 50 * 3.4 mm), accommodating the multiple RF bands
Environment and quality requirements	The device is designed and qualified by Telit to satisfy environmental and quality requirements.
Single supply module	The module internally generates all its required internal supply voltages.
RTC	Real-time clock is supported.
Operating temperature	Range -40 °C to +85 °C (conditions as defined in Section 2.8.1, Temperature Range)

Table 6: Main Features

2.4.1. Configurations Pins

Telit M.2 module indicates the main serial interface applicable on the combination of 4 configuration pins. FN980 Family is configured as an USB 3.1 Gen 2.

Pin	Signal	State	Interface Type
21	CONFIG_0	GND	USB 3.1 Gen 2 Port Configuration 0 (Applicable to WWAN only)
69	CONFIG_1	GND	
75	CONFIG_2	GND	

Pin	Signal	State	Interface Type
1	CONFIG_3	NC	

Table 7: Configurations Pins



Note: On the platform side, each of the CONFIG_0 to CONFIG_4 signals must be equipped with a pull-up resistor. Based on the state of the configuration pins on the Add-in Card, being tied to GND or left No Connect (NC), the detected pins will create a 4-bit logic state that required decoding.

For more details, please refer to PCI Express M.2 Specification document.

2.5. Block Diagram

The figure below shows an overview of the internal architecture of the FN980 Family module.

FN980 Family Block Diagram




Figure 1: FN980 Family Block Diagram

2.6. RF Performance

The RF performance in 5G, LTE and WCDMA modes conforms to the 3GPP specifications.

2.6.1. Conducted Transmit Output Power

TX power follows the measurement conditions and specifications defined in 3GPP.

Band	Power class	RF Power (dBm)
5G NR Sub-6 n1, n2, n3, n5, n7, n8, n12, n20, n25, n28, n38, n40, n41, n48, n66, n71, n77, n78, n79	3 (0.2W)	23 (+2dB / -2dB)
5G NR Sub-6 n41 Supports Power Class 2	2 (0.4W)	26 (+2dB / -2dB)
5G NR mmWave (OTA) _ Supported by FN980m n257, n258, n260, n261	3 (0.2W)	23 (+2dB / -2dB)
LTE All Bands B1, B2, B3, B4, B5, B7, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B30, B34, B38, B39, B40, B41, B42, B43, B48, B66, B71	3 (0.2W)	23 (+2dB / -2dB)
LTE B41 Supports Power Class 2	2 (0.4W)	26 (+2dB / -2dB)
3G WCDMA B1, B2, B3, B4, B5, B6, B8, B9, B19	3 (0.2W)	23 (+2dB / -2dB)

Table 8: Conducted Transmit Output Power

2.6.2. Conducted Receiver Sensitivity

The Sensitivity of the receiver follows the measurement conditions and specifications defined in 3GPP.

Technology	3GPP Compliance
5G NR Sub-6	Throughput >95%
5G NR mmWave	Throughput >95%
4G LTE	Throughput >95%
3G WCDMA	BER <0.1% 12.2 Kbps

Table 9: 3GPP compliance for Conducted Receiver Sensitivity

NR Band	Typical Conducted Rx Sensitivity (dBm) *						
	SCS (kHz)	BW (MHz)	PRx	DRx	MIMO 0	MIMO 1	Combined
NR FDD n1	15	20	-94	-95	-94	-97	-100
NR FDD n2	15	20	-94	-95	-94	-97	-100
NR FDD n3	15	20	-94	-95	-94	-95	-100
NR FDD n5	15	20	-94	-95	NA	NA	-96
NR FDD n7	15	20	-92	-95	-94	-94	-99
NR FDD n8	15	20	-94	-95	NA	NA	-96
NR FDD n12	15	15	-92	-97	NA	NA	-97

NR Band	Typical Conducted Rx Sensitivity (dBm) *						
NR FDD n20	15	20	-95	-96	NA	NA	-97
NR FDD n25	15	20	-93	-94	-95	-96	-99
NR FDD n28	15	20	-96	-96	NA	NA	-98
NR TDD n38	30	20	-98	-99	-92	-97	-101
NR TDD n40	30	50	-94	-95	-90	-93	-97
NR TDD n41	30	100	-84	-87	-88	-88	-91
NR TDD n48	30	40	-92	-92	-92	-90	-96
NR FDD n66	15	20	-93	-95	-94	-94	-99
NR FDD n71	15	20	-94	-94	NA	NA	-96
NR TDD n77	30	100	-88	-87	-88	-88	-92
NR TDD n78	30	100	-88	-87	-87	-88	-92
NR TDD n79	30	100	-87	-89	-87	-89	-92

Table 10: Typical Conducted Receiver Sensitivity – NR bands * 3.3 Voltage / Room temperature

E-UTRA Band	Typical Conducted Rx Sensitivity (dBm) *				
	PRx	DRx	MIMO 0	MIMO 1	Combined
LTE FDD B1	-97	-98	-97	-97	-103
LTE FDD B2	-97	-97	-97	-97	-103
LTE FDD B3	-97	-98	-97	-97	-103
LTE FDD B4	-97	-98	-97	-97	-103
LTE FDD B5	-99	-99	NA	NA	-102
LTE FDD B7	-96	-97	-97	-97	-102
LTE FDD B8	-99	-99	NA	NA	-102
LTE FDD B12	-99	-99	NA	NA	-102
LTE FDD B13	-99	-99	NA	NA	-102
LTE FDD B14	-99	-99	NA	NA	-102
LTE FDD B17	-99	-99	NA	NA	-102
LTE FDD B18	-99	-99	NA	NA	-102
LTE FDD B19	-99	-99	NA	NA	-102
LTE FDD B20	-99	-99	NA	NA	-102
LTE FDD B25	-97	-97	-97	-97	-103
LTE FDD B26	-99	-99	NA	NA	-102

E-UTRA Band	Typical Conducted Rx Sensitivity (dBm) *				
LTE FDD B28	-99	-99	NA	NA	-102
LTE FDD B29 (DL only)	-99	-99	NA	NA	-102
LTE FDD B30	-96	-98	-97	-97	-102
LTE FDD B32	-97	-98	-97	-97	-102
LTE TDD B34	-97	-98	NA	NA	-100
LTE TDD B38	-97	-97	-96	-96	-102
LTE TDD B39	-97	-98	-97	-97	-103
LTE TDD B40	-96	-98	-96	-96	-102
LTE TDD B41	-96	-97	-96	-96	-102
LTE TDD B42	-96	-97	-96	-96	-102
LTE TDD B43	-96	-97	-96	-96	-102
LTE TDD B46 (DL only)	-93	-92	-92	-93	-98
LTE TDD B48	-96	-97	-96	-97	-102
LTE FDD B66	-97	-97	-97	-97	-103
LTE FDD B71	-99	-99	NA	NA	-102

Table 11: Typical Conducted Receiver Sensitivity – LTE bands * 3.3 Voltage / Room temperature

UTRA Band	Typical Conducted Rx Sensitivity (dBm) *				
	PRx	DRx	MIMO 0	MIMO 1	Combined
WCDMA FDD B1	-110	-110	NA	NA	NA
WCDMA FDD B2	-110	-110	NA	NA	NA
WCDMA FDD B3	-110	-110	NA	NA	NA
WCDMA FDD B4	-110	-110	NA	NA	NA
WCDMA FDD B5	-110	-110	NA	NA	NA
WCDMA FDD B6	-110	-110	NA	NA	NA
WCDMA FDD B8	-110	-110	NA	NA	NA
WCDMA FDD B9	-110	-110	NA	NA	NA
WCDMA FDD B19	-110	-110	NA	NA	NA

Table 12: Typical Conducted Receiver Sensitivity – WCDMA bands * 3.3 Voltage / Room temperature

Note: The sensitivity level has a deviation of approximately +/- <2dB, device and channel because the level shows a typical value.

The sensitivity level of the NR bands has a deviation of approximately +/- <3dB depending on the EN-DC combinations, but the combined sensitivity performance meets the 3GPP requirements.

LTE level is measured at BW 10 MHz except Band46

B46 BW = 20 MHz



2.7. Mechanical Specifications

2.7.1. Dimensions

FN980 Family module overall dimensions are:

- Length: 50.00 mm, +/- 0.15 mm tolerance
- Width: 30.00 mm, +/- 0.15 mm tolerance
- Thickness: 3.40 mm, +/- 0.15 mm tolerance

2.7.2. Weight

The nominal weight of the FN980 module is 10.4 grams.

The nominal weight of the FN980m module is 10.5 grams.

2.8. Environmental Requirements

2.8.1. Temperature Range

Mode	Temperature	Note
Operating Temperature Range	-20°C ~ +55°C	This range is defined by 3GPP (the global standard for wireless mobile communication). Telit guarantees that its modules comply with all 3GPP requirements and that it has the full functionality of the module in this range.
	-40°C ~ +85°C	Telit guarantees full functionality within this range as well. However, there may possibly be some performance deviations in this extended range related to 3GPP requirements, which means that some RF parameters may deviate from the 3GPP specification on the order of a few dB. For example: the sensitivity of the receiver or the maximum output power may be slightly degraded. Even so, all functionalities, such as connection to calls, SMS, USB communication, UART activation and so on, will

Mode	Temperature	Note
		be maintained, and the effect of such degradations will not lead to malfunctions.
Storage and non-operating Temperature Range	-40°C ~ +85°C	

Table 13: Temperature Range



Warning: The application processor temperature which is in the FN980 Family must be kept below 95°C for the best performance. Depending on the various application, a heat sink, thermal pad or other cooling system may be required to dissipate the heat well. There is the large solder resist opening area on the bottom side of the module. Adding a TIM on that area with a heatsink is one of the best way to dissipate the heat well. The temperature can be read via AT commands. For more details, please refer to SW user guide or thermal design guideline.

2.8.2. RoHS Compliance

As a part of the Telit corporate policy of environmental protection, the FN980 Family complies with the RoHS (Restriction of Hazardous Substances) directive of the European Union (EU directive 2011/65/EU).

3. PINS ALLOCATION

3.1. Pin-out

Pin	Signal	I/O	Function	Type	Comment
USB Communication Port					
7	USB_HS_DP	I/O	USB 2.0 Data Plus	Analog	
9	USB_HS_DM	I/O	USB 2.0 Data Minus	Analog	
29	USB_SS_TX_M	O	USB 3.0 super-speed transmit - Minus	Analog	
31	USB_SS_TX_P	O	USB 3.0 super-speed transmit - Plus	Analog	
35	USB_SS_RX_M	I	USB 3.0 super-speed receive - Minus	Analog	
37	USB_SS_RX_P	I	USB 3.0 super-speed receive - Plus	Analog	
PCIe Communication Port					
43	PCIE_TX0_P	O	PCIe transmit 0 - plus	Analog	
41	PCIE_TX0_M	O	PCIe transmit 0 - minus	Analog	
49	PCIE_RX0_P	I	PCIe receive 0 - plus	Analog	
47	PCIE_RX0_M	I	PCIe receive 0 - minus	Analog	
55	PCIE_REFCLK_P	I	PCI Express differential reference clock - plus	Analog	
53	PCIE_REFCLK_M	I	PCI Express differential reference clock - minus	Analog	
52	PCIE_CLKREQ_N	I/O	PCIe reference clock request signal.	3.3V	
50	PCIE_RESET_N	I	Functional reset to the PCIe bus	3.3V	
54	PCIE_WAKE_N	I/O	PCIe wake-up	3.3V	
SIM Card Interface 1					
36	UIM1_VCC	O	Supply output for an external UIM1 card	1.8V / 2.85V	Power
34	UIM1_DATA	I/O	Data connection with an external UIM1 card	1.8V / 2.85V	
32	UIM1_CLK	O	Clock output to an external UIM1 card	1.8V / 2.85V	
30	UIM1_RESET_N	O	Reset output to an external UIM1 card	1.8V / 2.85V	

Pin	Signal	I/O	Function	Type	Comment
66	UIM1_PRESENT	I	UIM1 Card Present Detect	1.8V	
mmWave control Signal (FN980m Only)					
40	QTM0_PON	O	External mmW module control	1.8V	
42	QTM1_PON	O	External mmW module control	1.8V	
44	QTM2_PON	O	External mmW module control	1.8V	
46	QTM3_PON	O	External mmW module control	1.8V	
48	VREG_S4E_1P904	O	External mmW Voltage	1.9V	Power
Miscellaneous Functions					
6	FULL_CARD_POWER_OFF_N	I	Module On/Off	1.8V/3.3V	Open Drain 3.3V Tolerance
8	W_DISABLE_N	I	RF disable	3.3V	Active Low
10	LED	O	LED control		Open Drain
23	WAKE_ON_WAN	O	Wake Host	1.8V	
65	VDD_1P8_DIG_L6	O	Reference Voltage	1.8V	Power
67	SYS_RESIN_N	I	Reset Input	1.8V	
68	TGPIO_01	I/O	General Purpose I/O	1.8V	
25	TGPIO_02	I/O	General Purpose I/O	1.8V	
62	TGPIO_03	I/O	General Purpose I/O	1.8V	
64	TGPIO_04	I/O	General Purpose I/O	1.8V	
56	I2C_SDA	I/O	I2C Data Can be TGPIO_09	1.8V	
58	I2C_SCL	I/O	I2C Clock Can be TGPIO_10	1.8V	
20	TGPIO_05	I/O	General Purpose I/O Can be I2S_CLK	1.8V	
22	TGPIO_06	I/O	General Purpose I/O Can be I2S_DIN	1.8V	
24	TGPIO_07	I/O	General Purpose I/O Can be I2S_DOUT	1.8V	
28	TGPIO_08	I/O	General Purpose I/O Can be I2S_WS	1.8V	
60	TGPIO_11	I/O	General Purpose I/O	1.8V	
38	TGPIO_12	I/O	General Purpose I/O	1.8V	

Pin	Signal	I/O	Function	Type	Comment
26	TGPIO_13	I/O	General Purpose I/O Can be W_DISABLE2_N	1.8V	
MIPI Control					
63	RFFE0_CLK	0	Clock	1.8V	
61	RFFE0_DATA	I/O	Data	1.8V	
Power Supply					
2	VPH_PWR	I	Power supply	Power	
4	VPH_PWR	I	Power supply	Power	
70	VPH_PWR	I	Power supply	Power	
72	VPH_PWR	I	Power supply	Power	
74	VPH_PWR	I	Power supply	Power	
GROUND					
3	GND	-	Ground	Ground	
5	GND	-	Ground	Ground	
11	GND	-	Ground	Ground	
27	GND	-	Ground	Ground	
33	GND	-	Ground	Ground	
39	GND	-	Ground	Ground	
45	GND	-	Ground	Ground	
51	GND	-	Ground	Ground	
57	GND	-	Ground	Ground	
71	GND	-	Ground	Ground	
73	GND	-	Ground	Ground	
Config					
21	CONFIG_0	-	GND		
69	CONFIG_1	-	GND		
75	CONFIG_2	-	GND		
1	CONFIG_3	-	Floating		
Reserved for Future Use					
59	Reserved	-	-	-	-

Table 14: FN980 Family Pin-out Information



Note: If I2C interfaces are used, pull-up resistors in a customer board are required.



Note: Unless otherwise specified, RESERVED pins must be left unconnected (Floating).

3.2. FN980 Family Signals That Must be Connected

Below table specifies the FN980 Family signals that must be connected for a debugging purpose even if not used by the end application:

Mandatory Signals

Pin	Signal	Notes
2, 4, 70, 72, 74	VBATT	
3, 5, 11, 27, 33, 39, 45, 51, 57, 71, 73	GND	
7	USB_D+	If not used, connect to a test point or an USB connector
9	USB_D-	If not used, connect to a test point or an USB connector

Table 15: Mandatory Signals

3.3. Pin Layout




Figure 2: Pin Layout

4. POWER SUPPLY

The power supply circuitry and board layout are very important parts of the complete product design, with critical a impact on the overall product performance. Please read the following requirements and guidelines carefully to ensure a good and proper design.

4.1. Power Supply Requirements

The FN980 Family power requirements are as follows:

Power Supply Requirements

Power Supply	Value
Nominal supply voltage	3.3V
Supply voltage range	3.1V – 3.6V
Maximum ripple on module input supply	30 mV
Peak current consumption without mmWave antenna module	3.3V @ 4 A

Table 16: Power Supply Requirements

4.2. Power Consumption

The table below provides typical current consumption values of FN980 Family for various operation modes.

FN980 Family Current Consumption

Mode	Average [Typ.]	Mode Description
IDLE Mode		
CFUN=1	35mA	No call connection USB2.0 is connected to a host
Airplane Mode (PSMWDISACFG=1, W_DISABLE_N: Low)		
CFUN=4	< 4mA	Tx and Rx are disabled; module is not registered on the network (Airplane mode) USB is disconnected
Sleep Mode (PSMWDISACFG=1, W_DISABLE_N: Low)		
CFUN=1	< 5mA	Module cycles between wake and sleep USB is disconnected
Operative Mode (WCDMA)		
WCDMA Voice	930mA	WCDMA B1 voice call (Tx=23dBm)
WCDMA HSPA	850mA	WCDAM data call (DC-HSDPA up to 42Mbps, Max through-put)
Operative Mode (LTE)		

Mode	Average [Typ.]	Mode Description
Single mode (1DL/1UL SISO)	800mA	Non-CA ,B2 BW 5MHz, 1 RB, 23dBm, QPSK DL / QPSK UL
2DLCA(4x4MIMO) with 2ULCA(SISO)	1300mA	CA_2A-66A, BW 20MHz, Full RB, 256QAM DL / 256QAM UL(800Mbps DL / 170Mbps UL)
7DLCA(2x2MIMO) with 1UL(SISO)	1500mA	CA_2A-13A-46D-66A-66A, Full RB, 256QAM DL/ 64QAM UL(1300Mbps DL / 75Mbps UL)
5DLCA (4x4MIMO) With 1UL(SISO)	1900mA	CA_1A-3C-7C, Full RB, 256QAM DL/ 64QAM UL(2Gbps DL / 75Mbps UL)
Operative Mode (NR-FR1)		
NSA mode 1CC+1FR1	1000mA	EN-DC_1A(1DL/UL SISO)-n78A(1DL/1UL SISO) LTE : BW 20MHz, 1 RB, QPSK DL / QPSK UL, 23dBm FR1 : BW 100MHz, Inner RB 137(Number)@64(Position), QPSK DL / QPSK UL, 23 dBm
NSA mode 5CC+1FR1	2300mA	EN-DC_1A-3C-7C(5DL 4x4MIMO/1UL SISO)-n78(1DL 4x4MIMO/1UL SISO) LTE : BW 20MHz, Full RB, 256QAM DL / 64QAM UL(2Gbps DL / 75Mbps UL) FR1 : BW100MHz, Full RB, 256QAM DL / 256QAM UL(1.6Gbps DL/118Mbps)
Operative Mode (NR-FR2)****		
NSA mode LTE+FR2(LPM)	3000mA@FN980m/3.3V 300mA@QTM525 x1ea/3.7V	EN-DC_1A-3A-7A-7A(4DL 4x4MIMO/1UL SISO)-n257(DL 8CC 2x2MIMO/UL 2CC 2x2MIMO) LTE : BW 20MHz, Full RB, 256QAM DL / 64QAM UL(1.6Gbps DL / 75Mbps UL), max Power FR2 : DL BW800MHz/UL 200MHz, Full RB, 64QAM DL / Partial RB 64QAM UL(4.4Gbps DL/350Mbps UL), max Power
NSA mode LTE+FR2(HPM)	3500mA@FN980m/3.3V 5000mA@QTM527 x4ea/3.7V	EN-DC_1A-3A-7A-7A(4DL 4x4MIMO/1UL SISO)-n257(DL 8CC 2x2MIMO/UL 2CC 2x2MIMO) LTE : BW 20MHz, Full RB, 256QAM DL / 64QAM UL(1.6Gbps DL / 75Mbps UL), max Power FR2 : DL BW800MHz/UL 200MHz, Full RB, 64QAM DL / Partial RB 64QAM UL(4.4Gbps DL/350Mbps UL), max Power

Table 17: FN980 Family Current Consumption

* Worst/best case current values depend on network configuration - not under module control.

** Loop-back mode in call equipment

*** 3.3 voltage / room temperature

**** It is showing maximum currunt consumption of FN980m and QTM52x.

Note: The current consumption of FN980m can be too different depending on the mmWave antenna module.



The budget of power supply chain should be over 4A@3.3V without mmWave antenna module to operate FN980m without any malfunction caused by the power supply.

The peak current of FN980m with mmWave antenna will be addressed later.

4.3. General Design Rules

The principal guidelines for the Power Supply Design embrace three different design steps:

- Electrical design
- Thermal design
- PCB layout

4.3.1. Electrical Design Guidelines

The electrical design of the power supply is highly dependent on the power source from which the power is drained.

4.3.1.1. +5V Source Power Supply Design Guidelines

- The desired output for the power supply is 3.3V. Being the difference between the input source and the desired output moderate, a linear regulator can be used. A switching power supply is preferred to reduce power consumption.
- When using a linear regulator, a proper heat sink must be provided to dissipate the power generated.
- A low ESR bypass capacitor of adequate capacity must be provided to cut the current absorption peaks close to the FN980 Family module. A 100 μ F tantalum capacitor is usually suitable on VBATT.
- Make sure that the low ESR capacitor on the power supply output (usually a tantalum one) is rated at least 10V.
- A protection diode must be inserted close to the power input to protect the FN980 Family module from power polarity inversion.

4.3.2. Thermal Design Guidelines

The aim of this chapter is to provide thermal design guidelines useful for developing a product with the Telit FN980 Family.

Proper thermal protection design protects against human or component damage under worst-case conditions.

And it reduces the probability of failure and does not adversely affect the use of the module, and greatly extends the operation time with maximum performance.

For more details, please refer to thermal design guideline.



Note: FN980 Family supports various RAT such as 3G, 4G, 5G Sub6 and mmW.

Based on the RF transmission mode, the FN980 Family can consume a lot of current. Therefore proper thermal designs are essential to dissipate heat well.



Note: There is the large solder resist opening area on the bottom side of the module. Adding a TIM on that area with a heatsink is one of the best way to dissipate heat well.

The temperature can be read via AT commands.



Note: The FN980 Family must be connected to the ground and metal chassis of the host board for best RF performance, thermal dispersion and also fixing the module.

- The two holes at the top of the module and the main ground of the host board must be fastened together.
- The module shield and the main board of the host device or the metal chassis of the host device should be connected by means of conductive materials.

4.3.3. Power Supply PCB Layout Guidelines

As described in the electrical design guidelines, the power supply must have a low ESR capacitor on the output to cut current peaks and a protection diode on the input to protect the supply from spikes and polarity inversion. The placement of these components is

crucial for the correct operation of the circuitry: a misplaced component can be useless or can even decrease the power supply performances.

- The bypass low ESR capacitor must be placed close to the FN980 Family power input pins or - if the power supply is of a switching type - it can be placed close to the inductor to reduce ripple, as long as the PCB trace from the capacitor to FN980 Family is wide enough to ensure a drop-less connection even during the 4A current peaks.
- The protection diode must be placed close to the input connector where the power source is drained.
- The PCB traces from the input connector to the power regulator IC must be wide enough to ensure that no voltage drops occur during the 4A current peaks.
- The PCB traces to FN980 Family and the bypass capacitor must be wide enough to ensure that no significant voltage drops will occur when the 4A current peaks are absorbed. This is necessary for the same above-mentioned reasons. These traces should be kept as short as possible.
- The PCB traces connecting the switching output to the inductor and the switching diode must be kept as short as possible by placing the inductor and the diode very close to the power switching IC (only for the switching power supply). This is done to reduce the radiated field (noise) at the switching frequency (usually 100-500 kHz).
- Use a good common ground plane.
- Place the power supply on the board to ensure that the high current return paths in the ground plane do not overlap any noise sensitive circuitry, such as the microphone amplifier/buffer or earphone amplifier.
- The power supply input cables must be kept separate from noise sensitive lines, such as microphone/earphone cables.

4.4. RTC

The RTC within the FN980 Family module does not have a dedicated RTC supply pin. The RTC block is supplied by the VBATT supply.

If the VBATT power is removed, RTC is not maintained so if it is necessary to maintain an internal RTC, VBATT must be supplied continuously.

4.5. Reference Voltage

The 1.8V regulated power supply output is supplied as the reference voltage to a host board. This output is active when the module is turned ON and turns OFF when the module is shut down.

This table lists the VDD_1P8_DIG_L6 signal of FN980 Family.

FN980 Family Reference Voltage

PIN	Signal	I/O	Function	Type	Comment
65	VDD_1P8_DIG_L6	0	Reference Voltage	power	1.8V

Table 18:: FN980 Family Reference Voltage

4.6. Internal LDO for GNSS Bias

The LDO for GNSS bias is applied inside the FN980 Family model.

The voltage supply come from FN980 Family's LDO to GNSS active antenna.

This table lists the LDO for GNSS bias of FN980 Family.

FN980 Family Reference Voltage when VBATT is 3.3

Symbol	Parameter	Min	Typ	Max	Unit
V _{GNSS DC bias}	Voltage of Internal LDO for GNSS bias	2.9	3.1	3.15	[V]
I _{GNSS DC bias}	Current of Internal LDO for GNSS bias	-	-	100	[mA]

Table 19: FN980 Family Reference Voltage when VBATT is 3.3

5. ELECTRICAL SPECIFICATIONS

5.1. Absolute Maximum Ratings – Not Optional



Warning: A deviation from the value ranges listed below could damage the FN980 Family module.

Absolute Maximum Ratings – Not Operational

Symbol	Parameter	Min	Max	Unit
VBATT	Battery supply voltage on pin VBATT	-0.5	+4.2	[V]

Table 20: Absolute Maximum Ratings – Not Operational

5.2. Recommended Operating Conditions

Recommended Operating Conditions

Symbol	Parameter	Min	Typ	Max	Unit
T _{amb}	Ambient temperature	-40	+25	+85	[°C]
VBATT	Battery supply voltage on pin VBATT	3.1	3.3	3.6	[V]
I _{VBATT}	Peak current on pin VBATT Without mmW antenna module	-	-	4	[A]

Table 21: Recommended Operating Conditions

6. DIGITAL SECTION

6.1. Logic Levels

Unless otherwise specified, all FN980 Family interface circuits are 1.8V CMOS logic.

Only USIM interfaces are capable of dual voltage I/O.

The following tables show the logic level specifications used in the FN980 Family interface circuits. The data specified in the tables below are valid throughout all drive strengths and the entire temperature ranges.



Warning: Do not connect FN980 Family's digital logic signal directly to the OEM's digital logic signal with a level higher than 2.3V for 1.8V CMOS signals.

6.1.1. 1.8V Pins – Absolute Maximum Ratings

Absolute Maximum Ratings – Not Functional

Parameter	Min	Max
Input level on any digital pin when on	--	+2.13V
Input voltage on analog pins when on	--	+2.13 V

Table 22: Absolute Maximum Ratings – Not Functional

6.1.2. 1.8V Standard GPIOs

Operating Range – Interface Levels (1.8V CMOS)

Parameter	Min	Max	Unit	Comment	
V _{IH}	Input high level	1.17V	2.1V	[V]	
V _{IL}	Input low level	-0.3V	0.63V	[V]	
V _{OH}	Output high level	1.35V	1.8V	[V]	
V _{OL}	Output low level	0V	0.45V	[V]	
I _{IL}	Low-level input leakage current	-1	--	[uA]	No pull-up
I _{IH}	High-level input leakage current	--	1	[uA]	No pull-down
I _{ILPU}	Low-level input leakage current	-97.5	-27.5	[uA]	With pull-up

Parameter		Min	Max	Unit	Comment
I _{IHPD}	High-level input leakage current	27.5	97.5	[uA]	With pull-down
C _{I/O}	I/O capacitance	--	5	[pF]	

Table 23: Operating Range – Interface Levels (1.8V CMOS)

6.1.3. 1.8V SIM Card Pins

Operating Range – SIM Pins Working at 1.8V

Parameter		Min	Max	Unit	Comment
V _{IH}	Input high level	1.26V	2.1V	[V]	
V _{IL}	Input low level	-0.3V	0.36V	[V]	
V _{OH}	Output high level	1.44V	1.8V	[V]	
V _{OL}	Output low level	0V	0.4V	[V]	
I _{IL}	Low-level input leakage current	--	1000	[uA]	No pull-up
I _{IH}	High-level input leakage current	-20	20	[uA]	No pull-down

Table 24: Operating Range – SIM Pins Working at 1.8V

6.1.4. 2.85V Pins – Absolute Maximum Ratings

Absolute Maximum Ratings – Not Functional

Parameter	Min	Max
Input level on any digital pin when on	--	+3.42V
Input voltage on analog pins when on	--	+3.42 V

Table 25: Absolute Maximum Ratings – Not Functional

6.1.5. SIM Card Pins @2.85V

Operating Range – For SIM Pins Operating at 2.85V

Parameter		Min	Max	Unit	Comment
V _{IH}	Input high level	1.995V	3.15V	[V]	
V _{IL}	Input low level	-0.3V	0.57V	[V]	
V _{OH}	Output high level	2.28V	2.85V	[V]	

Parameter		Min	Max	Unit	Comment
VoL	Output low level	0V	0.4V	[V]	
IIL	Low-level input leakage current	--	1000	[uA]	No pull-up
IiH	High-level input leakage current	-20	20	[uA]	No pull-down

Table 26: Operating Range – For SIM Pins Operating at 2.85V

6.2. Power On

To turn on the FN980 Family, the FULL_CARD_POWER_OFF_N pin must be asserted high.



Note: To turn on the FN980 Family module, the SYS_RESIN_N pin must not be asserted low.

6.2.1. Initialization and Activation State

After turning on the FN980 Family module, the FN980 Family is not yet activated because the SW initialization process takes some time to complete. For this reason, it is recommended not to communicate with the FN980 Family during the Initialization phase. The AT command interface is accessible via USB port, but this does not mean that it works fully. In general, as shown in figure below, the FN980 Family becomes fully operational (in the Activation state) at least 50 seconds after the FULL_CARD_POWER_OFF_N is asserted.

FN980 Family Initialization and Activation




Figure 3: FN980 Family Initialization and Activation

Note: To verify if the FN980 Family has powered up properly, please check through the below explanation:



* Monitoring BOOT_OK(Shutdown indicator) pin. When the status translates to high, the module is completely boot. To use Boot OK (Shutdown indicator), shutdown indication function must be enabled through the AT#SHDNIND command (Refer to the AT Reference guide document).



Note: Active low signals are labeled with a name ending with “_N”



Note: To avoid a back-powering effect, it is recommended to prevent any HIGH logic level signals from being applied to the digital pins of the module when it is powered OFF or during an ON/OFF transition.

6.3. Power Off

Power off the device can be done in two different ways:

- Graceful Shutdown by FULL_CARD_POWER_OFF_N
- Fast Shutdown by GPIO triggered

6.3.1. Graceful Shutdown

To shutdown the FN980 Family module safely, host can use the graceful shutdown function.

The graceful shutdown can be triggered by:

- FULL_CARD_POWER_OFF_N

6.3.1.1. Graceful Shutdown by FULL_CARD_POWER_OFF_N

To gracefully shutdown the FN980 Family module, FULL_CARD_POWER_OFF_N should be asserted to Low.

Once FULL_CARD_POWER_OFF_N should be asserted to Low, the FN980 Family module enters finalization state, terminates active processes and prepares to turn off safely.

As shown in the diagram below, VDD_1P8_DIG_L6 will indicate when the module is ready to be turned off.

Graceful Shutdown by FULL_CARD_POWER_OFF_N




Figure 4: Graceful Shutdown by FULL_CARD_POWER_OFF_N

6.3.2. Fast Shutdown

For a quicker shutdown of the FN980 Family module, the host can use the fast shutdown function.

Fast shutdown can be triggered by:

- GPIO

6.3.2.1. Fast Shutdown by GPIO

If properly configured, one of GPIO lines can be used as Fast Shutdown Trigger.

Once the Fast Shutdown Trigger senses a HIGH to LOW transition, fast shutdown is triggered.

Then the FN980 Family module enters finalization state, terminates active processes and prepares to turn off safely. As shown in the figure below, when the module is ready to be turned off, it will be indicated via VDD_1P8_DIG_L6.

Please refer to the AT User Guide for more detail about enabling the Shutdown Indicator and Fast Shutdown Trigger.

Fast Shutdown by GPIO




Figure 5: Fast Shutdown by GPIO

Note: Using a Fast shutdown without shutdown indicator function, FULL_CARD_POWER_OFF_N pin should be controlled to prevent the FN980 Family module rebooting.



For more information, please refer to the AT Commands Reference Guide and SW User Guide document.

Fast Shutdown by GPIO (*SHDNIND Enable, Optional)




Figure 6: Fast Shutdown by GPIO (*SHDNIND Enable, Optional)

Note: *Shutdown Indicator is an optional function and disabled by default. The Host can verify the module entered OFF state by Shutdown Indicator pin. To turn on the module after using a fast shutdown with shutdown indicator function, it should be re-powered or reboot.



For more information, please refer to AT Commands Reference Guide and SW User Guide document.



Note: Fast shutdown function is disabled by default. To use Fast shutdown function, please refer to the AT Commands Reference Guide and SW User Guide document.



Warning: If the VPH_PWR is to be kept at a high status, the module will be re-booting.(Not Applicable to SHDNIND function)



Warning: Failure to follow recommended shut-down procedures might damage the device and consequently void the warranty.

6.4. Reset

Device reset can be achieved as follows:

- Unconditional Reset using the SYS_RESIN_N

6.4.1. Unconditional Hardware Reset

To unconditionally restart the FN980 Family module, the SYS_RESIN_N pin must be asserted low more than 1 second and then released.

Unconditional Hardware Reset by SYS_RESIN_N Pad




Figure 7: Unconditional Hardware Reset by SYS_RESIN_N Pad



Note: *Shutdown Indicator is an optional function. If SHDNIND is enabled, it can verify the status via SHDNIND function.

Please refer to the AT commands user guide document.



Note: Unconditional Hardware Reset must be used only as an emergency exit procedure, and not as a normal power-off operation.



Note: Do not use any pull-up resistor on the RESET_N line or any totem pole digital output. Using a pull-up resistor may cause latch-up problems on the FN980 Family power regulator and improper functioning of the module.

The RESET_N line must be connected only in an open-collector configuration.

Below figure shows a simple circuit for this action.

Circuit for RESET by SYSTEM_RESET_N




Figure 8: Circuit for RESET by SYSTEM_RESET_N

6.5. Communication Ports

The below table summarizes all the hardware interfaces of the FN980 Family module.

FN980 Family Hardware Interfaces

Interface	FN980 Family
PCIe	Peripheral Component Interconnect Express Gen 3.0
USB	USB3.1 Gen 2 interface
USIM	x1 dual voltage each (1.8V/2.85V)
eSIM	Embedded SIM
I2C	I2C

Interface	FN980 Family
I2S	I2S
mmWave	x4 mmWave antenna interface
Antenna ports	x4 Cellular, 1 for GNSS

Table 27: FN980 Family Hardware Interfaces


6.5.1. PCIe Interface

The FN980 Family module includes PCIe interface.

PCIe needs AC coupling series capacitors on the TX lines in both directions. In order to interface PCIe with the application board that controls the modem, 0.22uF capacitors should be installed on PCIE_RX_P/M lines of the FN980 Family. The series capacitors are already placed on PCIE_TX_P/M lines inside FN980 Family module.

The PCIe interface suggested connection is the following:

Connection for PCIe Interface



*CUSTOMER : Need to series capacitor (0.22uF) at PCIE_TX_P/M Lines

Figure 9: Connection for PCIe Interface



Note: The PCIe signal traces must be routed carefully : minimize trace lengths, number of vias, and capacitive loading. The impedance value should be as close as possible to 90 Ohms differential.

Below table lists the PCIe interface signals.

PCIe Interface Signals

PIN	Signal	I/O	Function	Type	Comment
43	PCIE_TX0_P	O	PCIe transmit 0 - plus	Analog	
41	PCIE_TX0_M	O	PCIe transmit 0 - minus	Analog	
49	PCIE_RX0_P	I	PCIe receive 0 - plus	Analog	
47	PCIE_RX0_M	I	PCIe receive 0 - minus	Analog	
52	PCIE_CLKREQ_N	I/O	PCIe reference clock request signal.	3.3V	
53	PCIE_REFCLK_M	I	PCI Express differential reference clock - minus		
55	PCIE_REFCLK_P	I	PCI Express differential reference clock - plus		
50	PCIE_RESET_N	I	Functional reset to the PCIe bus	3.3V	
54	PCIE_WAKE_N	I/O	PCIe wake-up	3.3V	

Table 28: PCIe Interface Signals



Note: Consider placing a low-capacitance ESD protection component to protect FN980 Family against ESD strikes



Warning: FN980 Family Add-in Card are not designed or intended to support Hot-Swap or Hot-Plug connections. Performing Hot-Swap or Hot-Plug may pose danger to the FN980 Family Add-in Card, to the system Platform, and to the person performing this act.

6.5.2. SIM Interface

The FN980 Family supports an external SIM interfaces (1.8V or 2.85V).

Below table lists the SIM interface signals.

SIM Interface Signals

PIN	Signal	I/O	Function	Type	Comment
SIM Card Interface 1					
36	UIM1_1P8	O	Supply output for an external UIM1 card	1.8V / 2.85V	Power
34	UIM1_DATA	I/O	Data connection with an external UIM1 card	1.8V / 2.85V	

PIN	Signal	I/O	Function	Type	Comment
SIM Card Interface 1					
32	UIM1_CLK	O	Clock output to an external UIM1 card	1.8V / 2.85V	
30	UIM1_RESET_N	O	Reset output to an external UIM1 card	1.8V / 2.85V	
66	UIM1_PRESENT	I	SIM detect signal	1.8V	

Table 29: SIM Interface Signals

6.5.2.1. SIM Schematic Example

The following Figures illustrate in particular how the application interface should be designed.

SIM Schematics




Figure 10: SIM Schematics



Note: FN980 Family contains an internal pull-up resistor on SIMIO. It is not necessary to install external pull – up resistor.

6.5.3. eSIM Interface

There is an embedded SIM on FN980 Family.

If you want to use the embedded SIM which is mounted on FN980 Family, please contact Telit Technical Support at

- TS-EMEA@telit.com
- TS-AMERICAS@telit.com
- TS-APAC@telit.com

6.5.3.1. W_DISABLE_N_3.3V

The W_DISABLE_N_3.3V signal is provided to trigger the FN980 Family to switch to airplane mode:

- Enter into the airplane mode: Low
- Normal operating mode: High or Leave the W_DISABLE_N not connected

6.5.3.2. LED

The LED signal drives the LED output.

The recommended LED connection is the following:

Recommended LED connection




Figure 11: Recommended LED connection

R1 and VDD determine the brightness of LED and forward current.

When VDD is 3.3V and LED's forward voltage is 2.0V, it is recommended to use the value of R1 from 66 ohm to 250 ohm.

However, the resistor value must be calculated considering the specification of the LED to be use.



Note: If enable the LED function and connect the LED to the LED_N pin, the current consumption may be increased.

6.5.4. General Purpose I/O

The general-purpose I/O pins can be configured to act in three different ways:

- Input

- Output
- Dedicate Function (Customer Requirement)

Input pins can only be read and report digital values (high or low) present on the pin at the read time.

Output pins can only be set or the pin level can be queried.

PIN	Signal	I/O	Function	Type	Comment
General Purpose I/O					
68	TGPIO_01	I/O	TGPIO_01	1.8V	
25	TGPIO_02	I/O	TGPIO_02	1.8V	
62	TGPIO_03	I/O	TGPIO_03	1.8V	
64	TGPIO_04	I/O	TGPIO_04	1.8V	
20	TGPIO_05	I/O	It Can be I2S_CLK	1.8V	
22	TGPIO_06	I/O	It Can be I2S_DIN	1.8V	
24	TGPIO_07	I/O	It Can be I2S_DOUT	1.8V	
28	TGPIO_08	I/O	It can be I2S_WS	1.8V	
56	I2C_SDA	I/O	It can be TGPIO_09	1.8V	
58	I2C_SCL	I/O	It can be TGPIO_10	1.8V	
60	TGPIO_11	I/O	TGPIO_11	1.8V	
38	TGPIO_12	I/O	TGPIO_12	1.8V	
26	TGPIO_13	I/O	It can be W_DISABLE2_N	1.8V	

Table 30: General Purpose I/O

6.5.4.1. Using a GPIO Pin as Input

GPIO pins, when used as inputs, can be tied to a digital output of another device and report its status, provided the device interface levels are compatible with the GPIO 1.8V CMOS levels.

If a digital output of a device is tied to GPIO input, the pin has interface levels different than 1.8V CMOS. It can be buffered with an open collector transistor with a 47 kΩ pull-up resistor to 1.8V.

6.5.4.2. Using a GPIO Pin as Output

GPIO pins, when used as outputs, can drive 1.8V CMOS digital devices or compatible hardware. When set as outputs, the pins have a push-pull output, and therefore the pull-up resistor can be omitted.

GPIO Output Pin Equivalent Circuit




Figure 12: GPIO Output Pin Equivalent Circuit

6.5.5. I2C – Inter-integrated Circuit

The FN980 Family supports an I2C interface on the following pins:

Below table lists the I2C signals of FN980 Family.

Module I2C Signal

PIN	Signal	I/O	Function	Type	Comment
56	I2C_SDA	I/O	I2C Data	CMOS 1.8V	
58	I2C_SCL	O	I2C Clock	CMOS 1.8V	

Table 31: Module I2C Signal

The I2C interface is used for controlling peripherals inside the module (such as codec, etc.).



Note: If I2C interface are used, pull-up resistors are required in the customer board.


6.5.6. USB 3.1 Interface

The FN980 Family module includes super-speed USB3.1 Gen2 with high-speed USB2.0 backward compatibility. It complies with the Universal Serial Bus Specification, Revision 3.0 and can be used for control and data transfers as well as for diagnostic monitoring and firmware update.

The USB port is typically the main interface between the FN980 Family module and OEM hardware. USB 3.1 needs AC coupling series capacitors on the TX lines in both directions. To interface USB3.1 with the application board controlling the modem, it is necessary to install 0.1uF capacitors on the USB_SS_RX_P/M lines of the FN980 Family. The series capacitors are already placed on USB_SS_TX_P/M lines inside FN980 Family Module.

The USB interface suggested connection is the following:

Connection for USB Interface



*CUSTOMER : Need series capacitors (0.1uF) on USB_SS_RX_P/M

Figure 13: Connection for USB Interface



Note: The USB signal traces must be carefully routed: minimize trace lengths, number of vias, and capacitive loading. The impedance value should be as close as possible to 90 Ohms differential.

Below table lists the USB interface signals.

USB Interface Signals

PIN	Signal	I/O	Function	Type	Comment
7	USB_HS_DP	I/O	USB 2.0 DATA Plus	Analog	
9	USB_HS_DM	I/O	USB 2.0 DATA Minus	Analog	
29	USB_SS_TX_M	O	USB3.0 super-speed transmit-Minus	Analog	

PIN	Signal	I/O	Function	Type	Comment
31	USB_SS_TX_P	O	USB3.0 super-speed transmit-Plus	Analog	
35	USB_SS_RX_M	I	USB3.0 super-speed receive-Minus	Analog	
37	USB_SS_RX_P	I	USB3.0 super-speed receive-Plus	Analog	

Table 32: USB Interface Signals



Note: Consider placing a low-capacitance ESD protection component to protect FN980 Family against ESD strikes

7. RF SECTION

7.1. Antenna Interface

The antenna connection is one of the most important aspect in the whole application design as it strongly affects the overall radio performance. Hence, please read carefully and follow the requirements and the guidelines as much as possible.

FN980 Family provides four MHF-4 type RF connectors covering the 5G FR1/LTE/WCDMA bands including GNSS, one MHF-4 type RF connector for dedicated GNSS and four 2in1mmWave IF connectors for 5G FR2.



Warning: Be careful cables and RF connectors assembly not to damage when Antenna cables for LTE/FR1/FR2/GNSS are connected.

7.1.1. Antenna Configuration

See the picture on the below for their position on the interface.




Figure 14: Antenna Configuration

Refer to the following antenna configuration assigned.

Antenna port	Technology	Tx	Rx	GNSS
ANT 0	WCDMA	B1, B2, B3, B4, B5, B6, B8, B9, B19	B1, B2, B3, B4, B5, B6, B8, B9, B19	-
	LTE	B1, B2, B3, B4, B5, B7, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B30, B34, B38, B39, B40, B41, B66, B71	B1, B2, B3, B4, B5, B7, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B29, B30, B32, B34, B38, B39, B40, B41, B42, B43, B46, B48, B66, B71	-
	5G NR FR1	n1, n2, n3, n5, n7, n8, n12, n20, n28, n38, n40, n41, n66, n71	n1, n2, n3, n5, n7, n8, n12, n20, n25, n28, n38, n40, n41, n48, n66, n71, n77, n78, n79	-
ANT 1	WCDMA	-	B1, B2, B3, B4, B5, B6, B8, B9, B19	-
	LTE	B5, B20, B42, B43, B48, B71	B1, B2, B3, B4, B5, B7, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B29, B30, B32, B34, B38, B39, B40, B41, B42, B43, B46, B48, B66, B71	-
	5G NR FR1	n5, n48, n77, n78, n79	n1, n2, n3, n5, n7, n8, n12, n20, n25, n28, n38, n40, n41, n48, n66, n71, n77, n78, n79	-
ANT 2	WCDMA	-	-	-
	LTE	B1, B2, B3, B4, B7, B41, B66	B1, B2, B3, B4, B7, B25, B30, B32, B34, B38, B39, B40, B41, B42, B43, B46, B48, B66	GPS L5, Galileo E5a
	5G NR FR1	n1, n2, n3, n7, n25, n41, n66, n77, n78, n79	n1, n2, n3, n7, n25, n38, n40, n41, n48, n66, n77, n78, n79	-
ANT 3	WCDMA	-	-	-
	LTE	-	B1, B2, B3, B4, B7, B25, B30, B32, B34, B38, B39, B40, B41, B42, B43, B46, B48, B66	GPS L1, Galileo E1, Beidou B1, Glonass G1
	5G NR FR1	-	n1, n2, n3, n7, n25, n38, n40, n41, n48, n66, n77, n78, n79	-
ANT 4	GNSS	-	-	GPS L1, Galileo E1, Beidou B1, Glonass G1

Table 33: Antenna Configuration

7.2. Antenna Connector

The FN980 Family is equipped with a set of 50 Ω RF MHF-4 Receptacle from I-PEX 20449-001E.

For more information about mating connectors, please <https://www.i-pex.com>





Figure 15: MHF-4 RF connector



- * MATING HEIGHT
- 1.2 MAX. WITH 20611-001R, 20572-001R-08,
20448-00*R-081, 20448-001R-081E
- 1.4 MAX. WITH 20565-001R-**
- 1.7 MAX. WITH 20632-001R-37

MATING CONDITION
WITH MHF 4/MHF 4L PLUG

Figure 16: MHF-4 Receptacle

7.3. mmWave Antenna Connector

The FN980m provides intermediate-frequency(IF) signal to use external 5G mmWave antenna modules.



Note: Refer to 80667NT11888A FN980m_QTM52x_Application_Note when FR2 has to be supported in your device.

For more detail schematic or question, please contact Telit technical support as reported in Chapter “[Contact Information, Support](#)”.

7.3.1. mmWave IF Connector

The FN980m is equipped with a set of 50 Ω RF Multi Line Connectors(MLC) of Murata, MM3929-2701A03.

For more information about Multi line connectors, please <https://www.murata.com>




Figure 17: RF Multi Line Connector Construction

7.3.2. Cable for mmWave IF

The connecting cables between the FN980m and the antenna modules must use mating cables from the Murata, MXCG series.

For more information about mating connectors, please <https://www.murata.com>

Mating state




Figure 18: Completion of engagement

Mating Height




Figure 19: Completion of engagement

7.3.3. mmWave Antenna Assembly

FN980m supports Low Power mode (7.3.3.1. QTM525) and High Power mode (7.3.3.2. QTM527)



Note: Please refer to the FN980 QTM52x Application Note, 80667NT11888A for detailed information about FN980m QTM52x operation and reference design.



Warning: Because mmWave has a wavelength that is too short, several characteristics are affected by the surrounding environments and device position.

7.3.3.1. QTM525

We recommend 3.3 Vdc for FN980m and 3.7 Vdc for QTM525 modules from customer’s main board. The 2in1 cable between the FN980m and QTM525 modules carries the intermediate frequency signal of approximately 8GHz. Customers should use MURATA MXCG series 2in1 cable and for more details, please refer to 7.3.2. Cable for mmWave IF. Total loss with 2in1 cable and FPCB between FN980m to QTM525 must be under 4dB.




Figure 20: Interface TLB with QTM525 ANT modules

FPCB assembly to QTM525 modules, design and routing with related signals as below table for FN980m IF connector.

FN980m IF connector	IF1	IF2	IF3	IF4
Pin No.	QTM525#0	QTM525#2	QTM525#3	QTM525#1
1	IFV4	IFV3	IFV2	IFV1
3	IFH1	IFH2	IFH3	IFH4
mmWave Control pin No.	PON_0 (M.2 pin40)	PON_2 (M.2 pin44)	PON_3 (M.2 pin46)	PON_1 (M.2 pin42)

Table 34: IF connector and control pin connection

7.3.3.2. QTM527

QTM527 carrier board has to be connected via the FPCB using the 30-pin connector we recommend.

GND	1	2	GND
GND	3	4	1V9_QTM_527_M2
QTM0/3_PON_527	5	6	N.C
GND	7	8	GND
GND	9	10	GND
DCJACK_QTM_M2	11	12	DCJACK_QTM_M2
DCJACK_QTM_M2	13	14	DCJACK_QTM_M2
DCJACK_QTM_M2	15	16	DCJACK_QTM_M1
DCJACK_QTM_M1	17	18	DCJACK_QTM_M1
DCJACK_QTM_M1	19	20	DCJACK_QTM_M1
GND	21	22	GND
GND	23	24	GND
QTM1/2_PON_527	25	26	N.C
1V9_QTM_527_M1	27	28	GND
GND	29	30	GND

Recommended vendor/model:
 IPEX MPN 20865-030E-01: 2.1 x 7.2 x 0.58 mm
(receptacle mounted on module)
 IPEX MPN 20864-030E-01: 2.1 x 7.9 x 0.65 mm

Figure 21: 30 pin assignment (Top view)

QTM527 modules on the carrier board are assembled with 2in1 cable and FPCB.

Total loss with 2in1 cable between FN980m to QTM527 must be under 1dB.




Figure 22: 5G EVB with QTM527 ANT carrier board

Customers need to design and route related signals as below table.



Note: IF connector configuration between QTM525 and QTM527 is different from PON and IF port.

FN980m IF connector	IF1	IF2	IF3	IF4
Pin No.	QTM527#1	QTM527#2	QTM527#3	QTM527#4
1	IFV4	IFV3	IFV2	IFV1
3	IFH1	IFH2	IFH3	IFH4
mmWave Control pin No.	PON_0 (M.2 pin40)	PON_1 (M.2 pin42)	PON_2 (M.2 pin44)	PON_3 (M.2 pin46)

Table 35: 5G EVB IF connector and control pin connection

7.4. Antenna Requirements

The antenna for the FN980 Family device must meet the following requirements:

WCDMA / LTE / 5G Sub-6 Antenna Requirements

Item	Value
Frequency range	Depending on the frequency band(s) provided by the network operator, the customer shall use the most suitable antenna for that/those band(s) The bands supported by the FN980 Family are provided in Section 2.2, Frequency Bands and CA / EN-DC Combinations
Impedance	50 Ohm
Input power	> 24 dBm average power in WCDMA & LTE & 5G Sub-6
VSWR absolute max	<= 10:1
VSWR recommended	<= 2:1

Table 36: WCDMA / LTE / 5G Sub-6 Antenna Requirements

7.4.1. Antenna Cable

Connecting cables between the module and the antenna of LTE/SUB6 must have 50 Ω impedance.

If the impedance of the module does not match, RF performance is significantly reduced.

Minimize Antenna Cable Recommendations

Item	Value
Impedance	50 Ohm

Item	Value
Max cable loss	Less than 0.5 dB
Avoid coupling with other signals.	

Table 37: Minimize Antenna Cable Recommendations



Warning: Impedence of RF connector and RF cable must be matched to 50 ohm, mismatching will cause negative RF performance, especially high insertion loss of RF cable affects on Tx power and Rx sensitivity.

7.4.2. Antenna Installation Guidelines

- Each antenna must be installed with 20dB isolation.
- Install the antenna in a location with access to the network radio signal.
- The antenna must be installed in such a way as to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.
- The antenna must not be installed inside metal cases.
- The antenna must be installed according to the antenna manufacturer’s instructions.

Furthermore, if the device is developed for the US and/or Canada market, it must comply with the FCC and/or ISED approval requirements.



Note: This device is to be used only for mobile and fixed application. The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antennas or transmitters. End-Users must be provided with transmitter operation conditions to meet RF exposure compliance. OEM integrators must ensure that the end user does not have manual instructions to remove or install the FN980 Family module. The antennas used for this OEM module must not exceed the gain in the table below for mobile and fixed operating configurations.

In the event that these conditions cannot be met (for example certain laptop configurations or co-location with another transmitter), then the FCC/ISED authorization is no longer considered valid and the FCC/ISED ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for re-

evaluating the final product (including the transmitter) and obtaining a separate FCC/ISED authorization.



Note: Manual Information to the End User The OEM integrator should be aware not to provide end user information on how to install or remove this RF module in the end product user manual which integrates this module. The end user manual shall include all required regulatory information/warning as shown in this manual.

7.5. GNSS Receiver

The FN980 Family integrates a GNSS receiver that could be used in Standalone mode and in A-GPS (assisted GPS), according to the different configurations.

FN980 Family supports an active antenna.

Item	Value
Frequency range	<ul style="list-style-type: none"> • Wide-band GNSS: 1559–1606 MHz recommended • GPS: 2.046 MHz BW NB GPS (centered on 1575.42 MHz) • Glonass (GLO): ~ 8.3 MHz BW (1597–1606 MHz) • BeiDou (BDS): 4.092 MHz BW (1559.05 – 1563.14 MHz) • Galileo (GAL): 4.092 MHz BW (centered on 1575.42 MHz)
Gain	1.5 dBi < Gain < 3 dBi
Impedance	50 Ohm
Amplification	14 dB < Gain < 26 dB
Supply Voltage	3.1 V

Table 38: GNSS Receiver

7.5.1. GNSS RF Front End Design

The FN980 Family contains an integrated LNA and pre-select SAW filter.

This allows the module to work well with a passive GNSS antenna. If the antenna cannot be located near the FN980 Family, then an active antenna (that is, an antenna with a low noise amplifier built in) can be used with an external dedicated power supply circuit.

GNSS receive path uses either the dedicated GNSS connector #4 or the shared antenna connector #3.



Note: Please refer to the FN980 Family AT Commands Reference Guide, 80624ST10996A for detailed information about GNSS operating modes and GNSS Antenna selection.

7.6. GNSS Characteristics

The table below specifies the GNSS characteristics and expected performance:

Parameters		Typical Measurement	Notes
Sensitivity	Tracking Sensitivity	-161 dBm	Standalone or MS based
	Acquisition	-148 dBm	
	Cold Start	-146 dBm	
TTFF	Hot	1 sec	Open Sky, mean TTFF
	Warm	27 sec	Open Sky, mean TTFF
	Cold	28 sec	Open Sky, mean TTFF
Min update rate		1Hz	
CEP		<2m	Open sky conditions. Standalone

Table 39: GNSS characteristics

8. MECHANICAL DESIGN

8.1. General

The FN980 Family module was designed to be compliant with a standard lead-free SMT process.

8.2. Finishing & Dimensions

The FN980 Family module's overall dimensions are:

- Length: 50.00 mm
- Width: 30.00 mm
- Thickness: 3.40 mm

8.3. Drawing

This figure shows the mechanical dimensions of the FN980 Family module.




Figure 23: FN980 Family Module Mechanical Dimensions

9. APPLICATION GUIDE

9.1. Debug of the FN980 Family Module in Production

To test and debug the FN980 Family module integration, we strongly recommend to add several test pins on the host PCB for the following purposes:

- Checking the connection between the FN980 Family itself and the application
- Testing the performance of the module by connecting it with an external computer

Depending on the customer application, these test pins include, but are not limited to the following signals:

- SYSTEM_RESET_N, W_DISABLE_N, PCIE_WAKE_N
- VBATT, GND
- VREG_L6_1P8
- USB_D-, USB_D+
- USB_SS_TX_M, USB_SS_TX_P, USB_SS_RX_M, USB_SS_RX_P
- PCIE_TX_M, PCIE_TX_P, PCIE_RX_M, PCIE_RX_P

9.2. Bypass Capacitor on Power Supplies

When a sudden voltage step is asserted to or a cut from the power supplies, the steep transition causes effects such as overshoot and undershoot. This abrupt voltage transition can affect the device causing it to fail or to malfunction.

Bypass capacitors are needed to alleviate this behavior, which can appear differently depending on the various applications. Customers must pay special attention to this issue when they design their application board.

The length and width of the power lines must be considered carefully, and capacitors value must be selected accordingly.

The capacitor will also prevent power supplies ripple and the switching noise caused in TDMA systems, such as GSM.

Most important, a suitable bypass capacitor must be mounted on the following lines on the application board:

- VBATT

Recommended values are:

- 100uF for VBATT

It must be taken into account that the capacitance mainly depends on the application board.

Generally, additional capacitance is required when the power line is longer. And if the fast power down function is used, additional bypass capacitors should be mounted on the application board.

9.3. EMC Recommendations

EMC protection on all the pins of FN980 Family should be designed by application side according to the customer's requirement.

ESD rating on all pins of FN980 Family :

Human Body Model (HBM): ± 1000 V

Charged Device Model (CDM): ± 250 V

All Antenna pins up to ± 4 kV



Warning: Do not touch without proper electrostatic protective equipment. The product must be handled with care, avoiding any contact with the pins because electrostatic discharge may damage the product itself.

10. PACKAGING

10.1. Tray

The FN980 Family modules are packaged on trays of 20 pieces each. These trays can be used in SMT processes for pick & place handling.





Figure 24: Tray Packaging

This paper must not be passed on, copied or reported without permission from Telit S.p.A. Offenders will be prosecuted. Telit S.p.A. reserves all rights concerning patent and design.

MOD. 046 rev.5 11/13



Note:
Per quote mancanti fare riferimento a modello 3D
For missing dimension please see 3D Model

INSPECTION

Telit Communication S.p.A.	Design by: W. Gregori Approved by: B. Vittori	Date: 6-07-12 Rev: 7-08-12 Draw: 8-08-12
PS 7110 Conductive/Dissipative Surface	Description: Vassoio per XE 910 Mini PCI con e senza sim	Material: PS 7110
General Tolerances	Resistance 10 ⁻³ - 10 ⁻⁵ Ohms per square	PS 7110
Up to 1		±0.1
Over 1 Up to 100		±0.2
Over 100		±0.5
Draft angle		±1°
Radius		±0.1
Diameters		±0.2
All Dimension are in mm.		

REV	Modify	By	Date
01			26-11-13
02			

Figure 25: Tray Construction

11. CONFORMITY ASSESSMENT ISSUES

11.1. Approvals

Module	EU RED	US FCC	CA ISED
FN980	Yes	Yes	Yes
FN980m	Yes	Yes	Yes

Table 40: Approvals Summary

11.2. RED Approval

11.2.1. RED Declaration of Conformity

Hereby, Telit Communications S.p.A declares that the FM980 and FN980m Modules are in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://www.telit.com/red>

Text of 2014/53/EU Directive (RED) can be found here:

<https://eur-lex.europa.eu/legal-content/EN/TXT/?uri=CELEX:32014L0053>

11.2.2. RED Antennas

This radio transmitter has been approved under RED to operate with the antenna types listed below with the maximum permissible gain indicated. The usage of a different antenna in the final hosting device may need a new assessment of host conformity to RED.

Model	Antenna Type
FN980	Omnidirectional Dipole Antenna
FN980m	

Table 41: RED Antenna Type

Max Gain for RED (dBi)				
UMTS	Ant Gain to meet CE MPE limit	Max Gain to consider same Frequency with LTE	Max Gain to consider EN-DC Transmit with WLAN	Max gain allowed
B1	11.1	8.8	8.5	8.5

Max Gain for RED (dBi)				
UMTS	Ant Gain to meet CE MPE limit	Max Gain to consider same Frequency with LTE	Max Gain to consider EN-DC Transmit with WLAN	Max gain allowed
B3	10.6	8.3	8.0	8.0
B8	7.8	5.4	5.0	5.0

Table 42: Max Gain for RED – WCDMA bands

Max Gain for RED (dBi)				
LTE	Ant Gain to meet CE MPE limit	Max Gain to consider EN-DC Active	Max Gain to consider EN-DC Transmit with WLAN	Max gain allowed
B1	11.8	8.8	8.5	8.5
B3	11.3	8.3	8.0	8.0
B7	12.0	9.0	8.6	8.6
B8	8.5	5.4	5.0	5.0
B20	8.2	5.1	4.8	4.8
B28	7.5	4.4	4.0	4.0
B38	12.0	9.0	8.6	8.6
B40	12.0	9.0	8.6	8.6
B42	12.0	9.0	8.6	8.6
B43	15.0	12.0	11.0	11.0

Table 43: Max Gain for RED – LTE bands

Max Gain for RED (dBi)				
NR	Ant Gain to meet CE MPE limit	Max Gain to consider EN-DC Active	Max Gain to consider EN-DC Transmit with WLAN	Max gain allowed
n1	11.84	8.8	8.5	8.5
n3	11.33	8.3	8	8.0
n7	12.01	9	8.6	8.6
n8	8.5	5.4	5.0	5.0
n20	8.2	5.1	4.8	4.8
n28	7.5	4.4	4.0	4.0
n38	12.0	9.0	8.6	8.6
n40	12.0	9.0	8.6	8.6
n41	9.0	6.0	5.6	5.6
n77	12.0	9.0	8.6	8.6

Max Gain for RED (dBi)				
NR	Ant Gain to meet CE MPE limit	Max Gain to consider EN-DC Active	Max Gain to consider EN-DC Transmit with WLAN	Max gain allowed
n78	90.1	6.0	5.6	5.6

Table 44: Max Gain for RED – NR bands

11.3. FCC and ISED Approval/FCC et ISDE Approbation

11.3.1. FCC Certificates

The FCC Certificate is available here: <https://www.fcc.gov/oet/ea/fccid>

11.3.2. ISED Approvals / ISDE Approbation

The ISED Certificate is available here/ *Le certificat ISDE est disponible ici:*

<https://sms-sgs.ic.gc.ca/equipmentSearch/searchRadioEquipments?execution=e1s1&lang=en>

11.3.3. Applicable FCC and ISED Rules / *Liste des Règles FCC et ISDE Applicables*

Model <i>Modèle</i>	Applicable FCC Rules	Applicable ISED Rules <i>Règles ISDE applicables</i>
FN980	47 CFR Part 2, 22, 24, 27, 90,96	RSS: 130 Issue 2, 132 Issue 3, 133 Issue 6, 139 Issue 3, 140 Issue 1, 195 Issue 2, 199 Issue 3; RSS-Gen Issue 5
FN980m		

Table 45: Applicable FCC and ISED Rules

11.3.4. FCC and ISED Regulatory Notices / *Avis Réglementaires de FCC et ISDE*

Modification statement / *Déclaration de modification*

Telit has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user’s authority to operate the equipment.

Telit n’approuve aucune modification apportée à l’appareil par l’utilisateur, quelle qu’en soit la nature. Tout changement ou modification peuvent annuler le droit d’utilisation de l’appareil par l’utilisateur.

Interference statement / *Déclaration d'interférence*

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Wireless notice / *Wireless Avis*

This device complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The antenna should be installed and operated with minimum distance of 20 cm between the radiator and your body.

Le présent appareil est conforme à l'exposition aux radiations FCC / ISED définies pour un environnement non contrôlé et répond aux directives d'exposition de la fréquence de la FCC radiofréquence (RF) et RSS-102 de la fréquence radio (RF) ISED règles d'exposition. L'émetteur ne doit pas être colocalisé ni fonctionner conjointement avec à autre antenne ou autre émetteur. L'antenne doit être installée de façon à garder une distance minimale de 20 centimètres entre la source de rayonnements et votre corps.

FCC Class B digital device notice (Fcc Only)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B) / NMB-3 (B) (ISED only) / ISDE seulement)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de classe B est conforme à la norme canadienne ICES-003.

11.3.5. Antennas / Antennes

FCC

This radio transmitter has been approved by FCC and ISED to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio a été approuvé par ISDE pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

ISED / ISDE

This radio transmitter has been approved by ISED to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio a été approuvé par ISDE pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

(le tabelle ISED sono comprese nelle tabelle FCC)

Model Modèle	Antenna Type Type d'Antenne
FN980	Omnidirectional Dipole Antenna
FN980m	Antenne dipolaire omnidirectionnelle

Table 46: FCC Antenna Type

Max Gain for FCC (dBi) Gain maximum pour ISED (dBi) / Gain maximum pour ISDE (dBi)				
UMTS	Max Gain to meet FCC ERP/EIPP and MPE limit	Max Gain to meet IC ERP/EIPP and MPE limit	Max Gain to consider the same Frequency	Max gain allowed
B2	8.0	8.0	5.9	5.9
B4	5.0	5.0	5.5	5.0
B5	9.9	6.6	3.5	3.5

Table 47: Max Gain for FCC – WCDMA bands

Max Gain for FCC (dBi) Gain maximum pour ISED (dBi) / Gain maximum pour ISDE (dBi)				
LTE	Max Gain to meet FCC ERP/EIRP and MPE limit	Max Gain to meet IC ERP/EIRP and MPE limit	Max Gain to consider EN-DC Transmit with WLAN	Max gain allowed
B2	9.5	9.5	5.9	5.9
B4	6.5	6.5	5.5	5.5
B5	10.4	7.1	3.5	3.5
B7	9.5	9.5	4.9	4.9
B12	9.2	6.1	2.6	2.6
B13	9.7	6.4	2.9	2.9
B14	9.7	6.5	3.0	3.0
B17	9.2	6.2	2.6	2.6
B25	9.5	9.5	5.9	5.9
B26	10.9	7.6	4.1	4.1
B30	0.5	0.5	0.5	0.5
B38	9.5	9.5	4.9	4.9
B41	7.0	7.0	4.9	4.9
B42	0.5	0.5	0.5	0.5
B43	1.0	Not applicable	1.0	1.0
B48	0.5	0.5	0.5	0.5
B66	6.5	6.5	5.5	5.5
B71	9.0	6.0	2.6	2.6

Table 48: Max Gain for FCC – LTE bands

Max Gain for FCC (dBi) Gain maximum pour ISED (dBi) / <i>Gain maximum pour ISDE (dBi)</i>				
NR	Max Gain to meet FCC ERP/EIRP and MPE limit	Max Gain to meet IC ERP/EIRP and MPE limit	Max Gain to consider EN-DC Transmit with WLAN	Max gain allowed
n2	9.0	9.0	5.9	5.9
n5	10.4	6.0	3.5	3.5
n7	9.0	9.0	4.9	4.9
n12	9.7	6.6	2.6	2.6
n25	11.3	10.0	5.9	5.9
n41	7.0	7.0	4.7	4.7
n66	6.5	9.8	5.5	5.5
n71	9.5	6.5	2.6	2.6

Table 49: Max Gain for FCC – NR bands

11.3.6. FCC Label and Compliance Information

The product has a FCC ID label on the device itself. Also, the OEM host end product manufacturer will be informed to display a label referring to the enclosed module. The exterior label will read as follows: “Contains Transmitter Module FCC ID: RI7FN980” or “Contains FCC ID: RI7FN980M”.

Below list of all the models and related FCC ID:

Model	FCC ID
FN980	RI7FN980
FN980m	RI7FN980M

Table 50: FCC ID

11.3.7. ISED Label and Compliance Information / *ISED Étiquette et Informations de Conformité*

The host product shall be properly labelled to identify the modules within the host product.

The ISED certification label of a module shall be clearly visible at all times when installed in the host product; otherwise, the host product must be labelled to display the ISED certification number for the module, preceded by the word “contains” or similar wording expressing the same meaning, as follows:

Contains IC: XXXXXX-YYYYYYYYYY

In this case, XXXXXX-YYYYYYYYYYY is the module's certification number.

Le produit hôte devra être correctement étiqueté, de façon à permettre l'identification des modules qui s'y trouvent.

L'étiquette d'homologation d'un module d'ISDE devra être apposée sur le produit hôte à un endroit bien en vue, en tout temps. En l'absence d'étiquette, le produit hôte doit porter une étiquette sur laquelle figure le numéro d'homologation du module d'ISDE, précédé du mot « contient », ou d'une formulation similaire allant dans le même sens et qui va comme suit :

Contient IC : XXXXXX-YYYYYYYYYYY

Dans ce cas, XXXXXX-YYYYYYYYYYY est le numéro d'homologation du module.

Model Modèle	ISED Certification Number Num. de certification ISDE
FN980	5131A-FN980
FN980m	5131A-FN980

Table 51: ISED Certification Number

11.3.8. Information on Test Modes and Additional Testing Requirements */ Informations sur les Modes de Test et les Exigences de Test Supplémentaires*

The module has been evaluated in mobile stand-alone conditions. For different operational conditions from a stand-alone modular transmitter in a host (multiple, simultaneously transmitting modules or other transmitters in a host), additional testing may be required (collocation, retesting...)

If this module is intended for use in a portable device, you are responsible for separate approval to satisfy the SAR requirements of FCC Part 2.1093 and IC RSS-102.

Le module a été évalué dans des conditions autonomes mobiles. Pour différentes conditions de fonctionnement d'un émetteur modulaire autonome dans un hôte (plusieurs modules émettant simultanément ou d'autres émetteurs dans un hôte), des tests supplémentaires peuvent être nécessaires (colocalisation, retesting...)

Si ce module est destiné à être utilisé dans un appareil portable, vous êtes responsable de l'approbation séparée pour satisfaire aux exigences SAR de la FCC Partie 2.1093 et IC RSS-102.

11.3.9. Fcc Additional Testing, Part 15 Subpart B Disclaimer

The modular transmitter is only FCC authorized for the specific rule parts (i.e., FCC transmitter rules) listed on the grant, and that the host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. If the grantee markets their product as being Part 15 Subpart B compliant (when it also contains unintentional-radiator digital circuitry), then the grantee shall provide a notice stating that the final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed. The end product with an embedded module may also need to pass the FCC Part 15 unintentional emission testing requirements and be properly authorized per FCC Part 15.

12. PRODUCT AND SAFETY INFORMATION

12.1. Copyrights and Other Notices

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

Although reasonable efforts have been made to ensure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from the use of the information contained herein. The information contained in this document has been carefully checked and is believed to be reliable. Telit reserves the right to make changes to any of the products described herein, to revise it and to make changes from time to time without any obligation to notify anyone of such revisions or changes. Telit does not assume any liability arising from the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

This document may contain references or information about Telit's products (machines and programs), or services that are not announced in your country. Such references or information do not necessarily mean that Telit intends to announce such Telit products, programming, or services in your country.

12.1.1. Copyrights

This instruction manual and the Telit products described herein may include or describe Telit copyrighted material, such as computer programs stored in semiconductor memories or other media. The laws in Italy and in other countries reserve to Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any of Telit's or its licensors' copyrighted material contained herein or described in this instruction manual, shall not be copied, reproduced, distributed, merged or modified in any way without the express written permission of the owner. Furthermore, the purchase of Telit products shall not be deemed to grant in any way, neither directly nor by implication, or estoppel, any license.

12.1.2. Computer Software Copyrights

Telit and the Third Party supplied Software (SW) products, described in this instruction manual may include Telit's and other Third Party's copyrighted computer programs stored in semiconductor memories or other media. The laws in Italy and in other countries reserve to Telit and other Third Party, SW exclusive rights for copyrighted computer programs, including – but not limited to – the exclusive right to copy or

reproduce in any form the copyrighted products. Accordingly, any copyrighted computer programs contained in Telit's products described in this instruction manual shall not be copied (reverse engineered) or reproduced in any manner without the express written permission of the copyright owner, being Telit or the Third Party software supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or in any other way, any license under the copyrights, patents or patent applications of Telit or other Third Party supplied SW, except for the normal non-exclusive, royalty free license to use arising by operation of law in the sale of a product.

12.2. Usage and Disclosure Restrictions

12.2.1. License Agreements

The software described in this document is owned by Telit and its licensors. It is furnished by express license agreement only and shall be used exclusively in accordance with the terms of such agreement.

12.2.2. Copyrighted Materials

The Software and the documentation are copyrighted materials. Making unauthorized copies is prohibited by the law. The software or the documentation shall not be reproduced, transmitted, transcribed, even partially, nor stored in a retrieval system, nor translated into any language or computer language, in any form or by any means, without prior written permission of Telit.

12.2.3. High Risk Materials

Components, units, or third-party goods used in the making of the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: operations of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems ("High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness eligibility for such High Risk Activities.

12.2.4. Trademarks

TELIT and the Stylized T-Logo are registered in the Trademark Office. All other product or service names are property of their respective owners.

12.2.5. Third Party Rights

The software may include Third Party's software Rights. In this case the user agrees to comply with all terms and conditions imposed in respect of such separate software rights. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License, shall apply to the Third Party Rights software as well.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESSED OR IMPLIED FROM ANY THIRD PARTY REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODES"), AND THE USE OF ANY OR ALL OTHER CODES IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODES MUST BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST OF PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODES OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

12.2.6. Waiver of Liability

IN NO EVENT WILL TELIT AND ITS AFFILIATES BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY INDIRECT DAMAGE OF ANY KIND WHATSOEVER, INCLUDING BUT NOT LIMITED TO REIMBURSEMENT OF COSTS, COMPENSATION OF ANY DAMAGE, LOSS OF PRODUCTION, LOSS OF PROFIT, LOSS OF USE, LOSS OF BUSINESS, LOSS OF DATA OR REVENUE, WHETHER OR NOT THE POSSIBILITY OF SUCH DAMAGES COULD HAVE BEEN REASONABLY FORESEEN, CONNECTED IN ANY WAY TO THE USE OF THE PRODUCT/S OR TO THE INFORMATION CONTAINED IN THE PRESENT DOCUMENTATION, EVEN IF TELIT AND/OR ITS AFFILIATES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

12.3. Safety Recommendations

Make sure the use of this product is allowed in your country and in the environment required. The use of this product may be dangerous and has to be avoided in areas where:



- it can interfere with other electronic devices, particularly in environments such as hospitals, airports, aircrafts, etc.
- there is a risk of explosion such as gasoline stations, oil refineries, etc. It is the responsibility of the user to enforce the country regulation and the specific environment regulation.

Do not disassemble the product; any mark of tampering will compromise the warranty validity. We recommend following the instructions of the hardware user guides for correct wiring of the product. The product has to be supplied with a stabilized voltage source and the wiring has to be conformed to the security and fire prevention regulations. The product has to be handled with care, avoiding any contact with the pins because electrostatic discharges may damage the product itself. Same cautions have to be taken for the SIM, checking carefully the instruction for its use. Do not insert or remove the SIM when the product is in power saving mode.

The system integrator is responsible for the functioning of the final product. Therefore, the external components of the module, as well as any project or installation issue, have to be handled with care. Any interference may cause the risk of disturbing the GSM network or external devices or having an impact on the security system. Should there be any doubt, please refer to the technical documentation and the regulations in force. Every module has to be equipped with a proper antenna with specific characteristics. The antenna has to be installed carefully in order to avoid any interference with other electronic devices and has to guarantee a minimum distance from the body (20 cm). In case this requirement cannot be satisfied, the system integrator has to assess the final product against the SAR regulation.

The equipment is intended to be installed in a restricted area location.

The equipment must be supplied by an external specific limited power source in compliance with the standard EN 62368-1:2014.

The European Community provides some Directives for the electronic equipment introduced on the market. All of the relevant information is available on the European Community website:

https://ec.europa.eu/growth/sectors/electrical-engineering_en

13. GLOSSARY


CA	Carrier aggregation
CLK	Clock
CMOS	Complementary Metal – Oxide Semiconductor
DTE	Data Terminal Equipment
EN-DC	E-UTRA-NR Dual Connectivity
ESR	Equivalent Series Resistance
E-UTRA	Evolved UMTS Terrestrial Radio Access
FDD	Frequency division duplex
GPIO	General Purpose Input Output
HS	High Speed
HSDPA	High Speed Downlink Packet Access
HSUPA	High Speed Uplink Packet Access
I/O	Input Output
I2C	Inter-integrated circuit
I2S	Inter-IC Sound
LTE	Long term evolution
NR	New Radio
PCB	Printed Circuit Board
PCIE	Peripheral Component Interconnect Express
RTC	Real Time Clock
SIM	Subscriber Identification Module
SOC	System-on-Chip
TDD	Time division duplex
TTSC	Telit Technical Support Centre
UART	Universal Asynchronous Receiver Transmitter
UMTS	Universal Mobile Telecommunication System
USB	Universal Serial Bus
VNA	Vector Network Analyzer
VSWR	Voltage Standing Wave Ratio
WCDMA	Wideband Code Division Multiple Access

14. DOCUMENT HISTORY

Revision	Date	Changes
7	2021-05-28	<ul style="list-style-type: none"> Minor changes on the language Minor changes on the layout Legal Notices updated Section 1.5 – Updated Related Documents Section 2.2 – Updated Frequency Bands and CA / EN-DC combinations Section 2.2.2 – Updated CA / MIMO / EN-DC Section 2.4 – Updated Main features Section 2.6.2 – Updated Conducted Receiver Sensitivity Section 4.2 – Updated Power Consumption Section 6.5.1 – Added Information Section 7.1 – Added Information Section 7.1.1 – Updated Antenna Configuration Section 7.3 – Added Information Section 7.3.3 – Added Information Section 7.4.1 – Updated Antenna Cable Section 7.5 – Updated GNSS Receiver Section 7.6 – Added GNSS Characteristics
6	2020-11-13	<ul style="list-style-type: none"> Section 1.5 – Updated Related Documents Section 3.1 – Updated Pin-out Section 3.3 – Updated Pin Layout Section 4.1 – Updated Power Supply level Section 4.2 – Updated Power Consumption Section 6.1 – Updated Logic levels Section 6.5.1 – Updated PCIe Interface Signal table Section 11 – Updated Conformity Assessment Issues
5	2020-06-29	<ul style="list-style-type: none"> Section 6.5.6 – Updated USB pin number Section 7.5.1 – Updated GNSS antenna #
4	2020-06-22	<ul style="list-style-type: none"> Section 3.1 – Updated Pin-out comments Separated FN980 and FN980m
3	2020-04-29	<ul style="list-style-type: none"> Section 3.1 – Updated Pin-out
2	2020-02-19	<ul style="list-style-type: none"> Section 2.4 – Updated Main features Section 3.1 – Updated Pin-out Section 3.3 – Updated Pin Layout Section 6.2.1 – Updated Initialization and Active Status

Revision	Date	Changes
1	2019-12-13	<p>Section 6.3.1 – Updated Graceful Shutdown by FULL_CARD_POWER_OFF_N</p> <p>Section 6.3.1.2 – Removed Graceful Shutdown by AT command</p> <p>Section 6.3.2.1 – Removed Fastshutdown by AT command, Updated figure and Added Warning comment</p> <p>Section 6.4.1 – Removed Graceful Reset and Updated Unconditional Hardware Reset</p> <p>Section 6.5.4 – Updated General Purpose I/O</p> <p>Section 7.3.4 – Updated Antenna Installation Guidelines</p>
0	2019-07-03	First draft

From Mod.0818 rev.4

A network diagram consisting of various colored nodes (blue, orange, green, yellow, black, grey) connected by thin grey lines, forming a complex web. The nodes are scattered across the page, with a higher density in the top-left and bottom-right corners.

Connect to our site and contact our
technical support team for any question

www.telit.com

The Telit logo features a stylized orange and yellow diagonal line above the word "Telit" in a bold, dark blue sans-serif font.

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2021, Telit